




LANCOM GS-3528XUP Multi-Gigabit Ethernet Access Switch User Guide

[Home](#) » [LANCOM](#) » LANCOM GS-3528XUP Multi-Gigabit Ethernet Access Switch User Guide 


LANCÔME SYSTEMS Hardware Quick Reference GS-3528XUP



Contents

- [1 Mounting & connecting](#)
- [2 LED description & technical details](#)
- [3 Hardware](#)
- [4 Interfaces](#)
- [5 Package Content](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)
- [7 Related Posts](#)

Mounting & connecting



1. Configuration interface (Console)


Connect the configuration interface via the included serial configuration cable to the serial interface of the device you want to use for configuring/monitoring the switch.

2. TP Ethernet interfaces 10M / 100M / 1G PoE+

Use Ethernet cables to connect interfaces 1 to 12 to your PC or a LAN switch.

3. TP Ethernet interfaces 100M / 1G / 2.5G PoE++

Use Ethernet cables to connect interfaces 13 to 24 to your PC or a LAN switch.





4. SFP+ interfaces 1G / 10G

Insert suitable LANCOM SFP modules into the SFP+ interfaces 25 to 28. Choose cables that are compatible with the SFP modules and connect them as described in the module's documentation.

5. Power connector (device back side)

Supply power to the device via the power connector. Please use the IEC power cable supplied or a country-specific LANCOM Power Cord.

6. **ATTENTION:** High touch current possible! Connect to earth before connecting the power supply.



Before initial startup, please make sure to take notice of the information regarding the intended use in the enclosed installation guide!


Operate the device only with a professionally installed power supply at a nearby power socket that is freely accessible at all times.



Please observe the following when setting up the device

- The power plug of the device must be freely accessible.
- For devices to be operated on the desktop, please attach the adhesive rubber footpads
- Do not rest any objects on top of the device
- Keep all ventilation slots on the side of the device clear of obstruction
- Mount the device into a 19" unit in a server cabinet using the provided screws and mounting brackets.
- Please note that support service for third-party accessories is excluded.

LED description & technical details



① System / Link/Act/Speed / PoE

System: off	Device switched off
System: green	Device operational
System: red	Hardware error
Link/Act/Speed:	Port LEDs show link / activity status or
green	port speed
PoE: green	Port LEDs show PoE status

② Mode- / Reset button

Short press	Port LED mode switch
~5 sec. pressed	Device restart
7~12 sec. pressed	Configuration reset and device restart

③ TP Ethernet ports 10M / 100M / 1G PoE+ LEDs switched to Link/Act/Speed mode

Off	Port inactive or disabled
Green	Link 1000 Mbps
Green, blinking	Data transfer, link 1000 Mbps
Orange	Link < 1000 Mbps
Orange, blinking	Data transfer, link < 1000 Mbps

LEDs switched to PoE mode

Off	Port inactive or disabled
Green	Port enabled, power supply to connected device
Orange	Hardware error

④ TP Ethernet ports 100M / 1G / 2.5G PoE++ LEDs switched to Link/Act/Speed mode

Off	Port inactive or disabled
Green	Link 2500 – 1000 Mbps
Green, blinking	Data transfer, link 2500 – 1000 Mbps
Orange	Link < 1000 Mbps
Orange, blinking	Data transfer, link < 1000 Mbps

LEDs switched to PoE mode

Off	Port inactive or disabled
Green	Port enabled, power supply to connected device
Orange	Hardware error

⑤ SFP+ ports 1G / 10G

Off	Port inactive
Blue	Link 10 Gbps
Green	Link 1000 Mbps

Hardware

Power supply
Power consumption Environment
Housing
Number of fans
Number of fans

Interfaces

ETH	12 TP Ethernet ports 10 / 100 / 12 TP Ethernet ports 10 / 100 / 4 SFP+ ports 1 / 10 Gbps 28 concurrent Ethernet ports in
-----	---

Package Content

Mounting brackets	Two 19" brackets for rack mounting
Cable	1 IEC power cord, 1 serial configuration cable 1.5 m

This product contains separate open-source software components which are subject to their own licenses, in particular the General Public License (GPL). The license information for the device firmware (LCOS) is available on the device's WEBconfig interface under "Extras > License information". If the respective license demands, the source files for the corresponding software components will be made available on a download server upon

request.



Hereby, LANCOM Systems GmbH | Adenauerstrasse 20/B2 | D-52146 Wuerselen, declares that this device is in compliance with Directives 2014/30/EU, 2014/35/EU, 2011/65/EU, and Regulation (EC) No. 1907/2006. The full text of the EU Declaration of Conformity is available at the following Internet address:

www.lancom-systems.com/doc

LANCOM, LANCOM Systems, LCOS, LAN community, and Hyper Integration are registered trademarks. All other names or descriptions used may be trademarks or registered trademarks of their owners. This document contains statements relating to future products and their attributes. LANCOM Systems reserves the right to change these without notice. No liability for technical errors and/or omissions.

111675/0622

Documents / Resources

	LANCOM GS-3528XUP Multi-Gigabit Ethernet Access Switch [pdf] User Guide GS-3528XUP, Multi-Gigabit Ethernet Access Switch, GS-3528XUP Multi-Gigabit Ethernet Access Switch
	LANCOM GS-3528XUP Multi-Gigabit Ethernet Access Switch [pdf] User Guide GS-3528XUP Multi-Gigabit Ethernet Access Switch, GS-3528XUP Multi-Gigabit Ethernet Access Switch, Ethernet Access Switch

References

- [L Business-Netzwerklösungen „Made in Germany“: LANCOM Systems GmbH](#)
- [L DoC - LANCOM Systems GmbH](#)
- [L Business-Netzwerklösungen „Made in Germany“: LANCOM Systems GmbH](#)
- [L DoC - LANCOM Systems GmbH](#)
- [L lancom.de/garantiebedingungen](#)
- [L Software Lifecycle Management: LANCOM Systems GmbH](#)
- [L Business-Netzwerklösungen „Made in Germany“: LANCOM Systems GmbH](#)
- [L DoC - LANCOM Systems GmbH](#)