



Lightware HDMI-TPS-TX86 Extender User Guide

[Home](#) » [LIGHTWARE](#) » [Lightware HDMI-TPS-TX86 Extender User Guide](#) 

Lightware HDMI-TPS-TX86 Extender User Guide



Contents

- [1 Important Safety Instructions](#)
- [2 Front and Rear View \(HDMI-TPS-TX86\)](#)
- [3 Connecting Steps](#)
- [4 Power Supply Options](#)
- [5 Maximum Extension Distances](#)
- [6 Application diagram](#)
- [7 Wiring Guide for RS-232 Data Transmission](#)
- [8 Specification](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)
- [10 Related Posts](#)

Important Safety Instructions

Please read the supplied safety instruction document before using the product and keep it available for future reference.

Introduction

HDMI-TPS-TX86 and -RX86 twisted pair HDBaseTTM extenders provide extension of uncompressed 4K/UHD video with embedded audio for long distances over a single CATx cable. The extender offers uni-directional RS-232 and IR pass-through on the same CATx cable that carries the video signal. The TPS extenders support full HDCP and EDID compliance and work on all standard AV resolutions and also 120 Hz 3D signals. 12V remote powering is available through the single CATx cable, but a local power supply can also be used.


Compatible Devices

It is not recommended to be used with third-party HDBaseTTM devices due to the special remote powering feature of the device.

Box Contents

- Extender unit
- Safety and Warranty info, Quick Start Guide
- 12V DC adaptor with interchangeable plugs
- Phoenix combicon 3-pole connector
- Twist 90° clockwise to lock.

Front and Rear View (HDMI-TPS-TX86)



1. RS-232 port:

Local RS-232 port for bi-directional serial data connection and performing firmware update (programming).

2. RS-232 switch

Normal: serial data is passed through the device. Prog: RS-232 pass-through function is disabled, the device is ready for the firmware update

3. **Status LEDs :**

See the next section

4. **TPS mode switch:**

LR: Long reach TPS mode; lower resolution (max 1080p), longer distances; Auto: TPS mode is determined automatically

5. **IR input:**

IR signal input connector (for 3.5 mm Jack, 3-pole, TRS plug).

6. **IR output :**

IR signal output connector (for 3.5 mm Jack, 2-pole, TS plug).

7. **DC input :**

12V DC input for local power supply

8. **TPS port :**

TPS port to the other compatible device (extender/ matrix /board). Remote power is always enabled, 12V present on TPS












Remote power is always enabled, 12V present on TPS connector. Check the compatibility before connecting devices


9. **HDMI port**

Video port for HDMI signal.

Status LEDs

HDCP		
	OFF	Video output signal is not encrypted with HDCP.
	ON	Video output signal is encrypted with HDCP.
SIGNAL		
	OFF	No video signal transmission.
	ON	Video signal transmission.
LINK		
	OFF	TPS connection failed between the devices.
	BLINKING	TPS connection is detected and LPPF link mode is active.
	ON	TPS connection is detected and HDBT or LR link mode is active.
LIVE		
	OFF	No power supply or out of order.
	BLINKING	Device is powered and ready to use.

Connecting Steps



CATx: Connect the TPS output port of the Transmitter to the TPS input port of the Receiver by a CATx cable.

HDMI: Connect a source to the HDMI (DVI-D) input port of the transmitter.

IR: Connect an IR emitter unit to the IR output port of the transmitter

RS-232: Connect a controller device to the local RS-232 port of the transmitter. Make sure the RS-232 switch is in Normal position.

HDMI: Connect a sink device to the HDMI (DVI-D) output port of the receiver.

RS-232: Connect a serial cable between the sink device and the RS-232 port of the receiver.

IR: Connect an IR detector unit to the IR input port of the receiver.

Power: First connect the power adaptor to the DC input of the power injector, then to the AC power socket.

Infrared emitter and detector units are optionally available accessories.


Mounting the Device (with optionally available accessories)

- Under Desk Mounting Kit (UD-kit): to mount one extender under any flat surface (e.g. furniture)
- UD Mounting Kit Double (UD-kit double): to mount two extenders under any flat surface (e.g. furniture).
- Rack Shelf: 1U high rack shelf provides mounting holes for the fastening of up to four extenders



Always use the fixing screws that are supplied with the mounting accessory. If you insert screws longer than 6 mm, the device can be damaged.

1. Unplug all the cables connected to the device(s).
2. Turn the device(s) upside down.
3. Put the shelf upside down on the device(s). Position it to get the mounting holes aligned.
4. Fasten the device on the shelf with the provided screws.
5. Fix the shelf to the desired place (screws are not supplied).



Power Supply Options

The extenders can be powered by any of the following ways:

1. **Local adaptor:** 12V DC input for local power supply.
2. **Remote power:** The extender pair can power each other when one of them is locally supplied with 12V DC adaptor. The extender sends remote power via the TPS IN (on the receiver) or the TPS OUT (on the transmitter) RJ45 connector to other device.



Carefully read all the detailed instructions about remote powering devices! Never use remote powering with third-party units!

Maximum Extension Distances

The values below are valid when the transmitter is powered by a local adaptor; distances may decrease depending on the powering mode (local or remote) and cable quality.

Resolution	Pixel clock rate	Cable lengths(Auto / Long reach TPS mode)		
		CAT5e AWG24	CAT7 AWG26	CAT7 AWG23
1024×768@60Hz	65 MHz	100 m / 130 m*	90 m / 120 m*	120 m / 170 m*
1280x720p@60Hz	73.8 MHz	100 m / 130 m*	90 m / 120 m*	120 m / 170 m*
1920x1080p@60Hz (24bpp)	148.5 MHz	100 m / 130 m*	90 m / 120 m*	120 m / 170 m*
1920×1200@60Hz	152.9 MHz	100 m / NA	90 m / NA	120 m / NA
1600×1200@60Hz	162 MHz	100 m / NA	90 m / NA	120 m / NA
1920×1080@60Hz (36bpp)	222.75 MHz	70 m / NA	70 m / NA	120 m / NA
3840×2160@30Hz UHD **	297 MHz	70 m / NA	70 m / NA	100 m / NA
4096×2160@30Hz 4K **	297 MHz	70 m / NA	70 m / NA	100 m / NA

* Long reach TPS mode supports pixel clock frequencies up to 148.5 MHz.
CAT7 SFTP AWG23 cable is always recommended


TPS Link Modes

The TPS working mode between the transmitter and the receiver parties is determined by the mode set in them. Both parties influence the setting that determines the final TPS transmission mode. The following TPS modes are defined:

- **Long reach (LR):** Longer CATx cable length, less bandwidth (limited resolution). TheLPPF mode is not available in LR TPS link mode.
- **HDBaseTTM (HDBT):** more bandwidth (higher resolutions), shorter CATx cable length. Ifno video is present, the units change to LPPF mode automatically.
- **Low Power Partial Functionality (LPPF):** Only RS-232 and IR are extended.


Toggling Between TPS Link Modes

The toggle switch on the extenders can be used to toggle between the LR and Auto TPS modes. If both units have Auto state and there is valid video signal on the transmitter, the common mode will be HDBT. If the video signal disappears, devices go into LPPF mode.



TPS mode between an extender and a port of a matrix board

If an extender and a TPS matrix board are paired, the board forces the extender to use the settings of the matrix. The extender’s TPS mode switch has no effect.

 Always use the Auto mode with third-party devices!

The negotiated TPS working mode		Selected mode (RX)	
		LR	Auto
Selected mode (TX)	LR	LR	LR
	Auto	LR	HDBT



Bi-directional Pass-through Data Lines

The direction of the video extension is fixed from TX towards RX, but the pass-through data lines are bi-

directional. It means the RS-232 and IR source and sink devices can be connected either to the TX or the RX.

Infra-Red (IR)

One emitter and one detector is enough for remote controlling one IR sink device. If there is an IR sink device to be controlled next to the TX and the other one is next to the RX, two emitter- detector pairs are needed. The IR emitter and the detector have standard 3.5 mm TRS (jack) connectors. The emitter's plug has two poles (mono) and the detector's plug has three poles (stereo).

 Detector – 3-pole-TRS		 Emitter – 2-pole-TS	
1 Tip	Signal (active low)	1 Tip	+5V
2 Ring	GND	2 Ring	Signal (active low)
3 Sleeve	+5V	3 Sleeve	

IR extension is available only with point-to-point connection of the extenders

RS-232


Third-party devices with standard RS-232 port are supported, as the extenders work in passthrough mode. TX and RX provide a 3-pole Phoenix connector. Use straight-serial cable to connect a DTE device to an extender and use a cross serial cable in case of pairing a DCE device to the other TPS extender. The RS-232 options – the baud rate and the parity bits – are set on the third party devices and they can be anything.

The extenders support any kind of serial settings. The signal levels are the following:

	Output voltage (V)
Logic low level	3 – 15
Logic high level	-15 – 3


RS-232 connector and plug pin assignment

Pin nr.	Signal
1	Ground
2	TX data
3	RX data




Please read the user's manual of the RS-232 device to get its type. The extenders operate as a DCE unit according to its pin-out.

Application diagram





Mechanical Drawings (HDMI-TPS-RX86)

Dimensions are in mm. Both the transmitter and the receiver have the same sized enclosure.



Wiring Guide for RS-232 Data Transmission

HDMI-TPS-86 series are built with a 3-pole Phoenix connector. See the examples below of connecting to a DCE (Data Circuit-terminating Equipment) or a DTE (Data Terminal Equipment) type device:



For more information about the cable wiring, see the Cable Wiring Guide on our website.

Video and Remote Powering Compatibility Table

This device	Remote device	Video / HDBaseTTM	Remote Powering
TPS '86 series	'90 series TPS extender	Not recommended	Not compatible
	'96 series TPS extender	Compatible	Available
	'95 series TPS extender	Compatible	Available
	'97 series TPS extender	Compatible	none
	Other TPS extender	Compatible	none
	MX-TPS IB / OB	Compatible	With external PSU
	MX-TPS2 IB / OB	Compatible	none
	MX-TPS2 IB / OB -P	Compatible	none
	25G TPS IO boards	Compatible	none
	MMX TPS series	Compatible	none
	Third-party HDBaseTTM	Not recommended	Not compatible

Specification

General

- **Compliance** CE, UKCA
- **EMC(Emission)** EN 55032:2015+A1:2020
- **EMC (Immunity)** EN 55035:2017+A11:2020
- **Electrical safety**..... EN 62368-1:2020
- **RoHS**EN 63000:2018
- **Operatingtemperature**0° to +50°C (+32° to +122°F)
- **Operating humidity** 10% to 90%, non-condensing
- **Cooling**..... passive

Power

- **Power supply** external power adaptor / remote power via TPS
- **Power adaptor** Input 100-240 V AC 50/60 Hz, Output 12V DC, 2.5 A
- **Power consumption (TX)**3.6 W (no signal) / 4.5 W (max. signal) / 13 W (with remote power)
- **Power consumption (RX)**5.5 W (no signal) / 6.5 W (max. signal) / 12.3 W (with remote power)

Enclosure

- **Enclosure material** 1 mm steel
- **Dimensions in mm** 100.4 W x 100x4 D x 26 H
- **Weight (TX)**287 g
- **Weight (RX)**300 g

Connectors

- **TX input, RX output**HDMI connector
- **TX output, RX input**RJ45 (TPS interface)
- **IR input, output** 3.5 mm (1.8") jack connector
- **Serial port**3-pole Phoenix connector
- **Power**locking DC connector (2.1 / 5.5 mm pin)

Digital Video Signal

- **Supported signals** DVI 1.0, HDMI 1.4
- **Signal standard** DVI and HDMI standard which supports embedded audio
- **Supported resolution**.....1920x1080@120 Hz, 24 bi.
- **3D support** yes
- **HDCP compliant** yes
- **Control over CEC**transparent
- **EDID support**transparent
- **Cable length HDMI input port (1080p)**max. 20 m
- **Equalization** adaptive, automatic

TPS port (HDBaseTTM-compatible)

- **RS-232 pass-through** yes
- **IR pass-through** yes


Lightware Visual Engineering PLC. Budapest, Hungary

sales@lightware.com
support@lightware.com
+36 1 255 3800+36
1 255 3810©2023

2023 Lightware Visual Engineering. All rights reserved. All trademarks mentioned are the property of their respective owners. Specifications are subject to change without notice.
Further information on the device is available at www.lightware.com.

visual engineering
LIGHTWARE

Documents / Resources



[Lightware HDMI-TPS-TX86 Extender](#) [pdf] User Guide
HDMI-TPS-TX86 Extender, HDMI-TPS-TX86, Extender

References

- [Lw Lightware Visual Engineering](#)
- [User Manual](#)