





# **LOGIC DART PRO MIDI Black USB C Case Instruction Manual**

Home » Logic » LOGIC DART PRO MIDI Black USB C Case Instruction Manual



#### Contents


- 1 LOGIC DART PRO MIDI Black USB C
- 2 Features
- 3 Accessory Kit
- 4 Panel I/O
- **5 Specification**
- 6 Removing side panels
- 7 Installing motherboard
- 8 Installing the GPU
- 9 Installing the Power Supply
- 10 Quick start guide/installation
- 11 Documents / Resources
  - 11.1 References



LOGIC DART PRO MIDI Black USB C Case




### **Features**



- 1. Left Side Panel
- 2. J PSU Dust Filter


- 3. Toolless Retention Bracket
- 4. Top Dust Filter
- 5. SSD Tray / Tacka na SSD
- 6. Right Side Panel
- 7. HDD/SSD cage

## **Accessory Kit**




- 1. Motherboard screws
- 2. HDD screws
- 3. PSU screws
- 4. Standoffs
- 5. Cable ties
- 6. Screws for installing fans on the PSU shroud

#### Panel I/O




- 1. Power
- 2. Reset
- 3. USB 3.C
- 4. Headphones + Microphone
- 5. USB 3.0
- 6. USB Type-C

## **Specification**




<sup>\*</sup> Installing 3 x 140 mm fans on the front of the case is possible only from the inside of the case.


## Removing side panels





## Installing motherboard




Installing 3.5" HDDs












Installing 2.5" SSDs












## Installing the GPU








## **Installing the Power Supply**





## Quick start guide/installation

- 1. Open the housing.
- 2. Install all computer components following the instructions in the individual assembly instructions for each component.

- 3. Mount in the housing and connect the power supply to the required com- ponents, following the installation instructions of the power supply and the instructions of the components that require its connection. The power supply is mounted in a tunnel, in the lower part of the case, with the fan facing outside the case (down).
- 4. Check the correct assembly of components and the connection of power plugs.
- 5. Close the housing.
- 6. Connect the monitor, keyboard and other accessories to the computer.
- 7. Connect the power cord to the socket in the power supply and to the 230V mains socket.
- 8. Set the power switch on the PSU housing to the I position (if present).

This device was designed and • made of high-quality reusable materials and components. If the de-vice, its packaging, user's manual, etc. are marked with crossed waste container, it means they are subject to segregated household waste collection in compliance with the Directive 2012/19/UE of the European Parliament and of the Council. This marking informs that electric and electronic equipment shall not be thrown away together with household waste after it's been utilised. The user is obliged to bring the used equipment to an electric and electronic waste collection point. Those running such collection points, including local collection points, shops or commune units, provide a convenient system enabling the scrapping of such equipment. Appropriate waste management aids in avoiding consequences which are harmful for people and the environment and result from dangerous materials used in the device, as well as improper storage and processing. Segregated household waste collection aids in recycling materials and components of which the device was made. A household plays a crucial role in contributing to recycling and reusing waste equipment. This is the stage where the basics are shaped, which largely in- influence the environment being our common good. Households are also one of the biggest users of small electrical equipment. Reasonable management at this stage aids and favours recycling. In the case of improper waste management, fixed penalties may be imposed in accordance with national legal regulations.

#### **Documents / Resources**



LOGIC DART PRO MIDI Black USB C Case [pdf] Instruction Manual DART PRO MIDI Black USB C Case, DART PRO MIDI, Black USB C Case, USB C Case, Case

#### References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.