



# Logitech F310 Console Style Gamepad User Guide

[Home](#) » [Logitech](#) » Logitech F310 Console Style Gamepad User Guide 

## Logitech F310 Console Style Gamepad User Guide



### Contents


- [1 Instruction](#)
- [2 Using game interface modes](#)
- [3 Documents / Resources](#)
  - [3.1 References](#)
- [4 Related Posts](#)

## Instruction

### Package Contents




1.



2.

Gamepad F310 features		
Control	X In put games	DirectInput games
1. Left butt on/ trigger	Button is digital; trigger is analog	Button and trigger are digital and programmable*
2. Right bu tton/ trigger	Button is digital; trigger is analog	Button and trigger are digital and programmable*
3. D-pad	8-way D-pad	8-way programmable D-pad`
4. Two ana log mini-sti cks	Clickable for button function	Programmable* (clickable for button function)
5. Mode b utton	Selects flight or sports mode. Flight mode: analog sticks control action and D pad controls POV; S tatus light is off. Sports mode: D pad controls action and analog sticks control POV; Status light is on.	
6. Mode/st atus light	Indicates sports mode (left analog stick and D-pad are swapped); controlled by Mode button	
7. Four act ion buttons	A, B, X, and Y	Programmable*
8. Start but ton	Start	Secondary programmable action button*
9. Logitech button	Guide button or keyboard's Home key	No function
10. Back b utton	Back	Secondary programmable action button'





\* Requires Logitech Profiler software installation

## Using game interface modes

Your new Logitech gamepad supports both XInput and DirectInput interface modes. You can switch between these two modes by sliding a switch on the bottom of the gamepad. It's recommended that you leave the gamepad in XInput mode, which is marked "X" (1) on the gamepad bottom.

In XInput mode, the gamepad uses standard Windows XInput gamepad drivers. It is not necessary to install the included software CD unless you will be using the gamepad in DirectInput mode.

XInput is the most current input standard for games on the Windows operating system. Most newer games that support gamepads use XInput. If your game supports XInput gamepads and your gamepad is in XInput mode all gamepad controls should operate normally. If your game supports XInput gamepads and your gamepad is in DirectInput mode, the gamepad will not function in the game unless it is switched to XInput mode or the gamepad is configured using the Logitech Profiler software.

DirectInput is an older input standard for games on the Windows operating system. Most older games that support gamepads use DirectInput. If your game supports DirectInput gamepads and your gamepad is in XInput mode, most features on the gamepad will function except that the left and right trigger buttons act as a single button, not independently. For best support in DirectInput games, try putting the gamepad in DirectInput mode, marked "D" on the gamepad bottom (2).

Some games do not support either DirectInput or XInput gamepads. If your gamepad doesn't work in either XInput or DirectInput modes in your game, you can configure it by switching it to DirectInput mode and using the Logitech Profiler software.

The Logitech Profiler software cannot be used to configure the gamepad when it is in XInput mode.

Help with Setup

### The gamepad doesn't work

- Check the USB connection.

- The gamepad works best plugged into a full-powered USB port.  
If you use a USB hub, it must have its own power supply.
- Try plugging the gamepad into a different USB port.
- In the Windows® Control Panel/Game Controllers screen, gamepad = “OK” and controller ID = 1.
- Restart the computer.

### The gamepad controls do not work as expected

- Refer to “Using game interface modes” and “Features” in this guide to learn more about how XInput and DirectInput interface modes affect gamepad functioning.

### What do you think?

Please take a minute to tell us. Thank you for purchasing our product.

[www.logitech.com](http://www.logitech.com)

© 2010 Logitech. Logitech, the Logitech logo, and other Logitech marks are owned by Logitech and may be registered. Microsoft, Windows Vista, Windows, and the Windows logo are trademarks of the Microsoft group of companies. Mac and the Mac logo are trademarks of Apple Inc., registered in the U.S. and other countries. All other trademarks are the property of their respective owners. Logitech assumes no responsibility for any errors that may appear in this manual.

Information contained herein is subject to change without notice.

620-002601.006  
+353-(0)1 524 50 80



[www.logitech.com/support](http://www.logitech.com/support)



### Documents / Resources

A small thumbnail image showing the first page of the Logitech F310 Console Style Gamepad User Guide PDF document.	<p><a href="#">Logitech F310 Console Style Gamepad</a> [pdf] User Guide F310 Console Style Gamepad, F310, Console Style Gamepad, Style Gamepad, Gamepad</p>
--	---

### References

-  [Logitech Customer Support & Business Support](#)
-  [Logitech | Official Online Store](#)
- [User Manual](#)

## **Manuals+. Privacy Policy**

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.