

Lumens CamConnect PTZ Camera User Manual

Home » Lumens CamConnect PTZ Camera User Manual



Contents

- 1 Chapter 1 System Requirements
- 2 Chapter 2 System Connection and

Application

- 3 Chapter 3 Support Devices
- **4 Chapter 4 Operation Interface Description**
- **5 Chapter 5 Troubleshooting**
- **6 Copyright Information**
- 7 Documents / Resources
- **8 Related Posts**

Chapter 1 System Requirements

1.1 Operating System Requirements


- Windows 10
- Windows 11

1.2 System Hardware Requirements


Item	Requirements
CPU	CPU: Intel i5 / i7 above
Memory	Memory: 4GB RAM
Free Disk Space	1GB Free Disk Space
Ethernet	Min Screen Resolution: 1920×1080

Chapter 2 System Connection and Application

2.1 System Connection



2.2 Scenario



Chapter 3 Support Devices


3.1 Shure Microphone System

- Shure MXA310 Table Array Microphone
- Shure MXA910 Ceiling Array Microphone
- Shure MXA920 Ceiling Array Microphone


3.2 Sennheiser Microphone System

• Sennheiser TeamConnect Ceiling 2 (TCC2) Ceiling Microphone <Note> When using TCC2 with CamConnect, please set and configure the channels on the Sennheiser Control Cockpit software first.

CamConnect is divided into 8 equal parts according to Senheisser's horizontal angle of view. They correspond to CamConnect Array Azimuth 1 to 8.




If the forbidden area is enabled on the Sennheiser Control Cockpit software, the corresponding position of CamConnect will also be affected. Example: If the forbidden area is set to 0° to 60°, the audio signal from 0° to 45° of CamConnect Array Azimuth 1 and 45° to 60° of Array Azimuth 2 will be ignored.



Chapter 4 Operation Interface Description

4.1 Main Screen



No	Item	Function Descriptions	
1	Microphone Device	 1.1 Support Device: The following brands and models are supported • Shure: MXA910_ MXA920_MXA310 • Sennhiser: TCC2 1.2 Device IP: IP location of the microphone device 1.3 Link: On/Off 	
2	Preset setting	After the microphone device is connected, the camera can be controlled to turn to the corresponding position according to the microphone detection position. There will be a green light at the front of the detection position. Array POS: For Shure microphones Array Azimuth: For Sennheiser microphones Click the camera preset and modify Sennheiser microphone Array Azimuths manu ally. Then click [Apply] when completed.	

3	Searching	The connected USB cameras will be displayed 3.1 When disconnected, click [Link] to connect the camera and perform PT rol. Model Name Connected VC-R30,V1 Link 3.2 When connected, click [Disconnect] to stop the connection. Model Name Connected VC-R30,V1 Disconnect	Z cont	
4	PTZ Control	Click to enable PTZ control Refer to 4.2 PTZ Control for function description		
5	About	Displaying software version information For technical support, please scan the QRcode on the page for assistance		

4.2 PTZ Control



No	Item	Function Descriptions	
1	Preview window	Display the screen currently captured by the camera	
2	L/R Direction	L/R Direction / Normal	
3	Mirror / Flip	Set image mirroring/flip	
4	Pan/Tilt/Home	Adjust the Pan/Tilt position of the camera screen Click [Home] key	
5	Preset setting	Click the number keys directly to call the preset • Save preset: Click [Set] first and then a number key • Clear preset: Click first and then a number key	
6	AF/MF	Switch to Auto Focus/Manual Focus. Focus can be adjusted in Manual.	
7	Zoom	Zoom In/Zoom Out ratio	
8	Exit	Exit the PTZ Control page	

Chapter 5 Troubleshooting

This chapter describes problems you may encounter while using Lumens CamConnect. If you have questions, please refer to related chapters and follow all the suggested solutions. If the problem still occurred, please contact your distributor or the service center.

NO	Problems	Solutions
1.	Unable to search camera devices	 Check the power supply of camera or PoE power supply is sta ble. Make sure the PC is connected to the camera with the USB ca ble Replace the cables and make sure they are not faulty
2.	No response from the microphone detection position	Make sure the microphone device is connected (Link)
3.	When using with a Sennhesier mi crophone, no response at the spe cific angle	Make sure the Array Azimuth settings in the CamConnect softw are include that angle position Make sure if the angle is set as the forbidden area on Sennhesier Control Cockpit software. Refer to 3.2 Sennhesier Microphone System for details.

Copyright Information

Copyrights © Lumens Digital Optics Inc. All rights reserved.

Lumens is a trademark that is currently being registered by Lumens Digital Optics Inc.

Copying, reproducing or transmitting this file is not allowed if a license is not provided by Lumens Digital Optics Inc. unless copying this file is for the purpose of backup after purchasing this product.

In order to keep improving the product, the information in this file is subject to change without prior notice.

To fully explain or describe how this product should be used, this manual may refer to names of other products or companies without any intention of infringement.

Disclaimer of warranties: Lumens Digital Optics Inc. is neither responsible for any possible technological, editorial errors or omissions, nor responsible for any incidental or related damages arising from providing this file, using, or operating this product.



Documents / Resources



<u>Lumens CamConnect PTZ Camera</u> [pdf] User Manual CamConnect PTZ Camera, CamConnect, PTZ Camera, Camera

Manuals+,