

For more details on operating this timepiece please refer to the enclosed booklet or visit:

AVI-8.COM



HAWKER HUNTER

ATLAS GMT AUTOMATIC

For more infomation Pour plus d'informations Para más información Per maggiori informazioni Für mehr Informationen 想要查询更多资讯 詳細については



Instruction Manual

Vol. 1.122 EN

AV-4122


GMT AUTOMATIC

This timepiece is equipped with a GMT dual time movement. It incorporates an individually controlled 4th hand that records time in a separate timezone using the 24 hour markings found on the turning bezel.

For more details on operating this timepiece please refer to the enclosed booklet or visit:

AVI-8.COM





Before you use this watch, it is recommended that you manually wind the mainspring to start it moving.

This watch is an automatic watch equipped with a manual winding mechanism.

WINDING THE MAINSPRING




When it is in position [0], turn the crown clockwise to wind. Wind 5-10 times and it will start to move naturally after shaking slightly. * This watch MUST be worn for at least 8 (Eight) hours each day to ensure it is fully wound. An automatic watch will only wind when the watch is on your wrist and your arm moves. Winding the watch by the crown will put power on the spring but not enough to allow the watch to function fully. If your watch stops overnight or loses time it means it is not being fully wound.

IMPORTANT NOTE

- If your watch is running smoothly, please do not wind the crown to avoid overwinding the movement. Provided you are wearing the watch frequently, your watch should have sufficient power to operate without any fuss.
- 2. If your watch has stopped running after a period of not wearing the watch, gently move the watch side to side 20 to 30 times to move the rotor or gently turn the crown 5 to 10 times to get the second hand run at its normal speed.


HOW TO SET THE TIME

- 1. Pull the crown out to position [2]-(2nd click).
- 2. Turn the crown clockwise to set the correct time
- 3. Push the crown in.



HOW TO SET THE DATE


- 1. Pull the crown out to position [1]-(1st click).
- 2. Turn the crown anti-clockwise to set the correct date.
- 3. Push the crown in.




* Do not set the date between 9:00 P.M. and 4:00 A.M.

HOW TO SET THE SECOND TIME ZONE

- 1. Pull the crown out to position [1]-(1st click).
- Turn the crown clockwise to set the correct time zone indication. (refer to the 24Hrs. marking on the dial).
- 3. Push the crown in.





HOW TO READ A THIRD TIME ZONE

Your watch is equipped with a turning bezel calibrated with a 24 hour time zone marking.

With this, you can in fact read off a third timezone at a glance.

Time zone 1 or home time

This would be the normal time read off by the main hour and minute hands



Time zone 2

By setting the independent GMT hand, you can read off a second time zone - off the 24 hour markings on the turning bezel.



9

Time zone 3

By turning the BEZEL that operates the 24 hour ring you can align another time zone.



Example:

You are in LONDON where the time is 3pm (15:00)


You would like your GMT hand to read the time in DUBAI (+4 from LONDON)

Simply adjust your GMT hand to align it at the 19 position (19:00)

You would also like to keep an instant view of the time in HONG KONG (+4 from DUBAI)

Turn the outer bezel so that the 23 marker aligns with the GMT Hand.

The time in HONG KONG will then be visible at a glance.



WATER RESISTANCE

Note that the water resistance chart serves only as a guide (please refer to the water resistance chart on the next page). Actual water resistance may vary depending on a number of factors including water temperature, water salinity and use under water. The water resistance of your timepiece may eventually be compromised over time with general wear and tear and use of your timepiece under adverse conditions.

Note that you should **NEVER** wear your watch in a jacuzzi, hot shower or steam room where steam may enter the case despite the watertight seals used to protect your watch. This may cause condensation inside your watch, which may affect and damage the inner workings of your watch

WATER RESISTANCE CHART	50M/ 5ATM
SPLASH/ SHOWERING	\bigcirc
SWIMMING/ BATHING	\bigcirc
BRIEF SWIMMING/ WATER SPORTS	\otimes
PROLONGED SWIMMING/ FREE DIVING	\otimes
SCUBA DIVING	\otimes
PROFESSIONAL DEEP SEA DIVING	\otimes