

## Pairing and Connection


### Method 1:

- ① Press and hold the crown for 3 seconds to power on the watch and switch to the QR code interface.
- ② Open the App and go to My > My Device.
- ③ Select the scanning icon to pair the watch.



### Method 2:

- ① Press and hold the crown for 3 seconds to power on the watch.
- ② Open the App and go to My > My Device.
- ③ Select the Add Device icon, find "KOSPET MAGIC P10" from nearby devices, and tap to pair the device.



## Create and Customize Training Plans

You can create your own training plans in the App with a few simple steps.

### Step 1:

Open the App and go to the Workouts page. Click "Training Plans" to enter the plan creation page.



### Step 2:

On the plan creation page, click "Training Programs" to create your program. Select workout and step types and set duration and intensity goals for each workout step to create a single training program.



### Step 3:

Click "Create Plan" on the plan creation page. Set up the name and starting date of the plan to create a training plan. After setting weekly training programs, the App will automatically generate training templates according to your training cycle.



### Step 4:

Once the training plans are synced successfully, you can check your daily training programs and training progress on the watch, which helps you to achieve your training goals.



## Gesture Operations



**Swipe Down:**  
Swipe down on the home screen to access the Shortcut Menu. Tap the + icon to customize it.



**Swipe Up:**  
Swipe up on the home screen to access the Notification Center. Tap the Edit icon below to customize it.




**Swipe Right:**  
Swipe right on the home screen to view unread notifications.



**Swipe Left:**  
Swipe left on the home screen to access the Widgets.

## Button Operations



### 1. Rotate the Crown:

- a. on the App List and other pages to scroll up/down through options.
- b. on the watch face editing page to switch between watch faces.
- c. on the brightness adjustment page to increase/decrease screen brightness.
- d. during music playback/BT calls to adjust the volume.

### 2. Press the Crown once:

- a. to wake the watch screen when the screen is off.
- b. on the home screen to enter the App List.
- c. on other pages to return to the home screen.
- d. in Timer/Stopwatch to pause/resume the countdown/timing.
- e. during a workout to pause/start the workout
- f. during water activities to unlock the screen.

### 3. Press and hold the Crown:

- a. for 3 seconds when the watch is powered off to power it on.
- b. for 3 seconds when the watch is powered on to access the Power off/Restart page.
- c. for over 8 seconds when the watch is powered on to force a restart.
- d. for 5 seconds in the power saving mode to exit the mode.

### 4. Press the BACK button once:

- a. on the home screen to access Workout. You can customize features for the BACK button in Settings.
- b. to wake the watch screen when the screen is off.
- c. on other pages to return to the upper-level page.
- d. in Stopwatch to start split timing or reset timing when the stopwatch stops.
- e. on the workout preparation page to start the workout.