

XView M4 Selfie Monitor

User Manual


Thank you for choosing SYNCO product. Please read this manual carefully before use
follow all instructions mentioned herein.



Caring For Your SYNCO Product

- Please keep the product in a dry, clean, dust-free environment.
- Keep corrosive chemicals, liquids and heat source away from the product to prevent mechanics damage.
- Use only a soft and dry cloth for cleaning the product.
- Malfunction may be caused by dropping, impact of external force.
- Do not attempt to disassemble the product. Doing so voids warranty.
- Please have the product checked or repaired by authorized technicians if any malfunctions happened.
- Failure to follow all the instructions may result in mechanics damage.
- Warranty does not apply to human errors.


Product Introduction



1. Wireless Shutter / Aspect Ratio Adjustment Button
2. Screen Mirror / Rotation Button
3. Volume / Brightness + Button
4. Volume / Brightness - Button
5. Power On/Off Toggle
6. TYPE-C Charging Port
7. Speaker

Installation

Attach the magnetic ring to the back of your phone. Align the magnet area on the back of the M4 with the magnetic ring and let it attach into place.



Operations


1. Charging

Use a Type-C cable to charge the device. (5V=2A)

2. Power On/Off


Power On: Slide the power switch to "On".

Power Off : Slide the power switch to "OFF".



3. Phone Pairing

Swipe down from the top-right corner of your phone screen to open the control center.



3.1 Screen Projection



- (1). Enable the screen projection function (Android: Wireless Projection, iOS: Screen Mirroring) on your phone.
- (2). Click to connect the device (SYNCO-XXXX).

* Some phones may require the PIN code (1234) for the first-time connection.

3.2 Camera Control


- (1). Enable Bluetooth on your phone.
- (2). Click to connect the device (Photo-xxxxxx).

***Some phones require changing the M4's channel to connect. Please:**

Long press both the  and  on the M4 and wait for the **Channel Switched** message, then reconnect your phone.


4. Wireless Shooting

Connect your phone via Bluetooth, open the camera, and short press the shutter button to shoot or record.




5. Aspect Ratio Adjustment

Long press the aspect ratio adjustment button to switch between full-screen and standard aspect ratios.




6. Screen Mirroring

Short press the mirror button to flip the screen horizontally.




7. Screen Rotation

Long press the rotation button to rotate the screen 180° clockwise.




8. Volume Adjustment

Short press the volume + / - button to increase or decrease the volume (3 levels).



9. Brightness Adjustment

Long press the brightness + / - button to increase or decrease brightness (3 levels).



Specification

Transmission Range	50m
Battery	3.7V / 1300mAh
Display	3.97 inches
Charging Port	Type-C
Case Material	Plastic
Runtime	3H

Packing List



M4 Selfie Monitor x1



Magsafe Ring Sticker x1



Charging Cable x1

Warranty

Warranty Period

Thank you for purchasing SYNCO products.

1. Customers are entitled to free replacement or repair service in case of quality defect(s) found in the product under normal use within 30 days upon receipt of the product.
2. Original SYNCO products are entitled to 12-month limited warranty service. The warranty period begins on the date of purchase of brand new, unused products by the first end-user.

Within the warranty period, if product defect or failure is attributable to material defection or technological problem, the defective product or defective part will be repaired or replaced without charge (service and materials fee).

Warranty Exclusions and Limitations

Faults resulted from inappropriate use of a product without following its operation specification

1. Artificial damage, e.g. crash, squeeze, scratch, or soaking
2. Modifications to a product by its user or a third party without prior written consent of SYNCO, e.g. replacement of element or circuit, label alteration
3. The code on product is inconsistent with that of warranty certificate, or the code on the product or warranty certificate is altered or torn off
4. All consumable accessory attached to a product, like cable, wind muff, battery
5. Faults as a result of force majeure, such as fire, flood, lightning, etc.

Warranty Claim Procedure

1. If failure or any problem occurs to your product after purchase, please contact a local agent for assistance, or you can always contact SYNCO's customer service through email at support@syncoaudio.com.
2. Please retain your sales receipt and warranty certificate as proof of purchase. If any of these documents is missing, only sales return or chargeable service will be provided.
3. If the SYNCO product is out of the warranty coverage, the service and the parts cost will be charged.

Guangzhou Zhiying Technology Co., Ltd

📍 Room 2401, 24 / F, South Tower, Lisheng Plaza, No. 68 Huadi Avenue, Liwan District, Guangzhou, China, 510000

✉ support@syncoaudio.com

🌐 www.syncoaudio.com