

GPS SMART WATCH



APP:GloryFitPro User Manual

retrieve the latest GPS ephemeris data for the day. When the watch is connected to Bluetooth, it will obtain the latest GPS ephemeris data.
4.3 If the GPS positioning time is too long and the GPS trajectory drifts, it will be greatly affected by environmental factors. Choosing a location or staying away from high-rise buildings will help GPS quickly locate and reduce trajectory deviation.
4.4 After the exercise is completed, save the data and the app will synchronize the exercise data. You can query exercise trajectories and exercise data on the app.


5. GPS user interface




Bluetooth call and APP disconnection
APP Connection
Bluetooth call disconnected
Bluetooth call connection

6. APP connection

Scan the QR code of the watch or enter the main app market to download and install the 'GloryFitPro' app. When you first open the app, a pop-up window will appear reminding you of your permissions. Please click 'Allow' to ensure that the app can obtain the corresponding permissions.



1.产品介绍和按钮定义



按钮定义

按钮1:

短按:在表盘界面短按一次关闭屏幕, 在应用列表界面短按一次返回表盘界面再次短按关闭屏幕。

长按3秒:电源开/关、重新启动、SOS

转动按钮:在表盘界面转动按钮更换表盘

按钮2:

返回按钮/快捷键:
短按:

- 其他页面返回到上一层/自定义快捷方式功能。
- 屏幕关闭时短按以点亮屏幕。
- 运动时暂停/继续。
- 来电时短按, 静音。

长按3秒:打开语音助手/自定义快捷方式功能
补充说明:您可以在返回按钮/快捷键按钮之间进行选择。如果未设置快捷键功能轻按返回上一级, 长按语音助手, 如果已设置快捷键功能, 请按照设置项执行。

按钮3 (运动按钮):

短按键:

- 进入运动模式列表
- 屏幕关闭时, 短按即可点亮屏幕。
- 运动时长按按钮; 停止和结束运动。

按钮4 (LED灯):

- 屏幕关闭时, 短按即可点亮屏幕。
- 长按3秒: 打开LED灯/长按3秒关闭LED灯。


2.触摸屏控制定义

↓向下滑动:在表盘界面向下滑移, 打开状态栏。

↑向上滑动:在表盘界面向上滑动, 进入卡片快捷功能。

→向右滑动:在表盘界面向右滑动, 进入通知信息界面。

←向左滑动:在表盘界面向左滑移, 进入主菜单界面。



to follow the instructions, the company will not provide free warranty.

8.4 Do not place the product in direct sunlight, such as on a car dashboard or window sill.

8.5 Do not place the device near heat sources or exposed fire sources, such as induction cookers, microwaves, ovens, water heaters, fire sources, candles, or other places that may generate high temperatures.

8.6 Do not let children or pets swallow the product or its accessories to avoid injury or product malfunction.

8.7 This product is not a toy and children should use it under adult supervision.

8.8 This product is equipped with a non removable built-in battery. Please do not replace the battery by yourself.

8.9 If the watch has come into contact with water, please dry the water stains on the surface of the watch promptly after leaving the water source. If there are too many water stains left in the speaker chamber and they are not drained in time, it may affect the sound effect. Please locate the speaker outlet and promptly shake off any residual water stains inside.

7. Unbind the APP

IOS: Search for "Unbind" in the "Device" interface of the APP, click Unbind to enter the "Settings - Bluetooth" interface of the mobile system, click on the right side of the device, and then select "Forget this device" to unbind from the mobile system to ensure that it is no longer connected to the phone, otherwise it will not be able to connect again next time.

Android: Find "Unbind" on the "Device" interface of the APP, click on "Unbind", and disconnect from the phone.

8. Precautions

- Do not charge in areas with water stains.
- This product does not belong to medical devices, and the data and information provided are for reference only.
- Do not wear it in hot showers or saunas to prevent steam from entering. If the watch is damaged by water due to failure

3.充电

3.1 手表提示电量不足时, 请及时充电, 充电时间为2-3小时,

3.2 手表已进行磁性充电, 请将充电线缆的充电触点与手表的充电端口对齐进行充电, 直到手表屏幕显示充电提示。

3.3 在充电时, 为了保证充电稳定, 手表会关闭屏幕进行充电。点击按钮醒手表。当手表电量过低时, 需要3-5分钟唤醒手表, 这是正常现象。请在5分钟后检查手表的充电状态。


3.4 请使用额定输出电压为5V、额定输出电流为0.5A-2A的充电器或电脑USB端口为手表充电。

3.5 手表长时间不使用时, 请将其充满电并关闭存放。电量低时, 不要长时间存放。避免因长期低电量储存而损坏电池。



4.GPS的使用

4.1 为了获得更好的体验, 请在首次使用GPS功能时连接绑定APP。在绑定后约3分钟内, "GloryFitPro" 应用程序将通过蓝牙在后台将GPS星历轨道和其他数据发送到手表。在星历成功发送后, GPS定位时间可以大大缩短。如果未成功发送, 当您首次打开带有GPS功能的运动时, 手表将弹出 "AGPS已过期" 提醒。AGPS过期会导致定位



1.Введение продукта и определение кнопки

1.Другие страницы возвращаются на верхний уровень / настраивается функция комбинаций клавиш.

2.При закрытии экрана нажмите кнопку, чтобы зажечь экран.

3.Приостановление / продолжение занятий спортом.

4.При входящих звонках короткий нажатие, тишина. **Нажмите 3 секунды:**Включить голосовой помощник / настроить комбинации клавиш

Дополнительные пояснения: Вы можете выбрать между кнопками возврата / комбинации клавиш. Если функция комбинаций клавиш не установлена, нажмите кнопку « Возвращение» на верхний уровень и нажмите голосового помощника, если функция комбинаций клавиш установлена, выполните ее в соответствии с параметром настройки.

Кнопка 3 (кнопка движения):
Короткая кнопка:

1.Войдите в список режимов движения

2.Когда экран закрыт, короткий нажатие может зажечь экран.

3.Длительное время движения при нажатии кнопки; Остановить и прекратить движение

Кнопка 4 (светодиодный свет):

1.1.Когда экран закрыт, короткий нажатие может зажечь экран.

2.Длинный щелчок 3 секунды: Включите светодиодный свет / Длинный щелчок 3 секунды, чтобы выключить светодиодный свет.

2. Определение управления сенсорным экраном

1.1.Когда экран закрыт, короткий нажатие может зажечь экран.

2.Длинный щелчок 3 секунды: Включите светодиодный свет / Длинный щелчок 3 секунды, чтобы выключить светодиодный свет.

3. Зарядка

3.1 Часы подсказывают, что, когда батареи недостаточно, заряджайте их вовремя, время зарядки составляет 2 - 3 часа.

3.2 Часы были магнитно заряжены, и зарядные контакты зарядного кабеля должны быть выровнены с зарядным портом часов до тех пор, пока на экране часов не появится подсказка для зарядки.

3.3 Во время зарядки, чтобы гарантировать, что зарядка стабильна, часы закрывают экран для зарядки. Нажмите кнопку, чтобы разбудить часы. Когда заряд часов слишком низок, требуется 3 - 5 минут, чтобы разбудить часы,


время过长, 影响定位体验。您可以尝试重新绑定和解除绑定手表APP。尝试使用GPS功能前等待2分钟。如果成功发送AGPS, 则首次打开GPS功能时不会弹出 "AGPS已过期" 提醒。

4.2 每天早上09:00, "GloryFitPro" 应用程序将重新获取当天最新的GPS星历数据。当手表连接蓝牙时, 它将获取最新的GPS星历数据。

4.3 如果GPS定位时间过长且GPS轨迹漂移, 会受到环境因素的影响很大。选择开的地方或远离高层建筑将有助于GPS快速定位并减少轨迹偏差。

4.4 锻炼结束后保存数据, APP将同步锻炼数据。可以在APP端查询锻炼轨迹和锻炼数据。

5.GPS用户界面



7.APP解除绑定

IOS: 在APP "设备" 界面中查找 "解除绑定", 点击解除绑定进入手机系统的 "设置-蓝牙" 界面, 点击设备右侧, 然后选择 "忘记此设备" 来从手机系统中解除绑定, 以确保它不再与手机连接, 否则下次将无法再次连接。

Android:在APP "设备" 界面找到 "解除绑定", 点击解除绑定, 断开与手机的连接。

8.注意事项

8.1 不要在有水渍的地方充电。

8.2 本产品不属于医疗器械, 所提供的数据和信息仅供参考。

8.3 不要在热水淋浴或桑拿时佩戴, 以防止蒸汽侵入。如果手表因未按照说明使用而被水损坏, 公司将不提供免费保修。

8.4 不要将产品放在直射阳光下, 如汽车仪表盘或窗台。

8.5 不要将设备放在热源或暴露的火源附近, 如电炉灶、微波炉、烤箱、热水器、火源、蜡烛或其他可能产生高温的地方。


8.6不要让孩子或宠物吞下产品或其附件, 以免造成伤害或产品故障。

↓Скользите вниз: скользите вниз по интерфейсу циферблата, откройте строку состояния

↑**Продвижение вверх:** скользите вверх по интерфейсу циферблата и входите в функции комбинации клавиш карт.

→**Скользите вправо:** скользите вправо по интерфейсу циферблата и входите в интерфейс уведомлений.

←**Переместить вверх:** переместите налево в интерфейсе циферблата и войдите в интерфейс главного меню.




3. Зарядка

3.1 Часы подсказывают, что, когда батареи недостаточно, заряджайте их вовремя, время зарядки составляет 2 - 3 часа.

3.2 Часы были магнитно заряжены, и зарядные контакты зарядного кабеля должны быть выровнены с зарядным портом часов до тех пор, пока на экране часов не появится подсказка для зарядки.

3.3 Во время зарядки, чтобы гарантировать, что зарядка стабильна, часы закрывают экран для зарядки. Нажмите кнопку, чтобы разбудить часы. Когда заряд часов слишком низок, требуется 3 - 5 минут, чтобы разбудить часы,

在连接过程中, 会出现一个弹出窗口, 提示您确认手表与手机的配对连接。请单击确认配对。连接成功后, 手表状态栏中的通话图标和数据连接图标将变为绿色。灰色表示未连接。



7.APP解除绑定

IOS: 在APP "设备" 界面中查找 "解除绑定", 点击解除绑定进入手机系统的 "设置-蓝牙" 界面, 点击设备右侧, 然后选择 "忘记此设备" 来从手机系统中解除绑定, 以确保它不再与手机连接, 否则下次将无法再次连接。

Android:在APP "设备" 界面找到 "解除绑定", 点击解除绑定, 断开与手机的连接。

8.注意事项

8.1 不要在有水渍的地方充电。



8.2 本产品不属于医疗器械, 所提供的数据和信息仅供参考。

8.3 不要在热水淋浴或桑拿时佩戴, 以防止蒸汽侵入。如果手表因未按照说明使用而被水损坏, 公司将不提供免费保修。

8.4 不要将产品放在直射阳光下, 如汽车仪表盘或窗台。

8.5 不要将设备放在热源或暴露的火源附近, 如电炉灶、微波炉、烤箱、热水器、火源、蜡烛或其他可能产生高温的地方。


8.6不要让孩子或宠物吞下产品或其附件, 以免造成伤害或产品故障。



4.Использование GPS

4.1 Чтобы получить лучший опыт, подключите связанное приложение при первом использовании функции GPS. Примерно через 3 минуты после привязки приложение GloryFitPro будет отправлять GPS - орбиты и другие данные на часы через Bluetooth в фоновом режиме. После успешной отправки календаря время позиционирования GPS может быть значительно сокращено. Если отправка не удалась, когда вы впервые включаете движение с функцией

8.7 本产品并非玩具, 儿童应在成人监护下使用本产品。
8.8 本产品配备不可拆卸的内置电池, 请勿自行更换电池。
8.9 如果手表接触过水, 请在离开水源后及时擦干手表表面的水渍。如果扬声器腔内残留的水渍过多且未及时排出, 可能会影响音效。请找到扬声器出口, 及时抖落内的残留水渍。



7.APP解除绑定

IOS: 在APP "设备" 界面中查找 "解除绑定", 点击解除绑定进入手机系统的 "设置-蓝牙" 界面, 点击设备右侧, 然后选择 "忘记此设备" 来从手机系统中解除绑定, 以确保它不再与手机连接, 否则下次将无法再次连接。

Android:在APP "设备" 界面找到 "解除绑定", 点击解除绑定, 断开与手机的连接。

8.注意事项

8.1 不要在有水渍的地方充电。



8.2 本产品不属于医疗器械, 所提供的数据和信息仅供参考。

8.3 不要在热水淋浴或桑拿时佩戴, 以防止蒸汽侵入。如果手表因未按照说明使用而被水损坏, 公司将不提供免费保修。

8.4 不要将产品放在直射阳光下, 如汽车仪表盘或窗台。

8.5 不要将设备放在热源或暴露的火源附近, 如电炉灶、微波炉、烤箱、热水器、火源、蜡烛或其他可能产生高温的地方。

8.6不要让孩子或宠物吞下产品或其附件, 以免造成伤害或产品故障。




4.Использование GPS

4.1 Чтобы получить лучший опыт, подключите связанное приложение при первом использовании функции GPS. Примерно через 3 минуты после привязки приложение GloryFitPro будет отправлять GPS - орбиты и другие данные на часы через Bluetooth в фоновом режиме. После успешной отправки календаря время позиционирования GPS может быть значительно сокращено. Если отправка не удалась, когда вы впервые включаете движение с функцией



1.Product Introduction and Button Definition



Button Definition

Button1:

Short press:Short press once on the dial interface to close the screen, short press once on the application list interface to return to the dial interface and short press again to close the screen.

Long press for 3 seconds:Power on/off, restart SOS

Rotate button:Rotate the button on the dial interface to replace the dial

Button2:

Return button/shortcut key:
Short press:

1.Return to the previous page/customize shortcut function for other pages.

2.Short press when the screen is turned off to light up the screen.

3.Pause/resume during exercise.

4.Short press when calling to mute.

Long press for 3 seconds:Open the voice assistant/custom shortcut function

Additional note: You can choose between the return button/shortcut button. If the shortcut key function is not set, lightly press to return to the previous level, long press the voice assistant. If the shortcut key function has been set, please follow the settings.

Button 3 (motion button):
Short button:

1.Enter the sports mode list

2.When the screen is turned off, short press to light up the screen.

3.Press and hold the button during exercise; Stop and end the movement.

Button 4 (LED light):


1.When the screen is turned off, short press to light up the screen.

2.Long press for 3 seconds: Turn on the LED light/Long press for 3 seconds to turn off the LED light.

2. Definition of Touch Screen Control

↓**Slide down:** Slide down on the dial interface to open the status bar.

↑**Slide up:** Slide up on the dial interface to enter the card shortcut function.



→**Swipe right to:**Swipe right on the dial interface to enter the notification information interface.
←**wipe up:**Swipe left on the dial interface to enter the main menu interface.



3. Charging

3.1 When the watch indicates that the battery is low, please charge it in a timely manner. The charging time is 2-3 hours.

3.2 The watch has undergone magnetic charging. Please align the charging contact of the charging cable with the charging port of the watch for charging until the charging prompt is displayed on the watch screen.

3.3 During charging, in order to ensure stable charging, the watch will turn off the screen for charging. Click the button to wake up the watch. When the battery level of the watch is too low, it takes 3-5 minutes to wake up the watch, which is a normal phenomenon. Please check the charging status of the watch after 5 minutes.

3.4 Please use a charger or computer USB port with a rated output voltage of 5V and a rated output current of 0.5A-2A to charge the watch.

4.2 Every morning at 09:00, the "GloryFitPro" application will

4.1 For a better experience, please connect and bind the app when using the GPS function for the first time. Within about 3 minutes after binding, the "GloryFitPro" application will send GPS ephemeris orbit and other data to the watch via Bluetooth in the background. After the ephemeris is successfully sent, the GPS positioning time can be greatly shortened. If the transmission is not successful, the watch will pop up a "AGPS expired" reminder when you first turn on the sport with GPS function. AGPS expiration can result in prolonged positioning time, affecting the positioning experience. You can try to rebind and unbind the watch app. Wait for 2 minutes before attempting to use the GPS function. If AGPS is successfully sent, there will be no prompt saying "AGPS has expired" when the GPS function is first turned on.

4.2 Every morning at 09:00, the "GloryFitPro" application will

4.2 Every morning at 09:00, the "GloryFitPro" application will

4.2 Every morning at 09:00, the "GloryFitPro" application will

4.2 Every morning at 09:00, the "GloryFitPro" application will

4.2 Every morning at 09:00, the "GloryFitPro" application will

4.2 Every morning at 09:00, the "GloryFitPro" application will

4.2 Every morning at 09:00, the "GloryFitPro" application will

4.2 Every morning at 09:00, the "GloryFitPro" application will

4.2 Every morning at 09:00, the "GloryFitPro" application will

4.2 Every morning at 09:00, the "GloryFitPro" application will

4.2 Every morning at 09:00, the "GloryFitPro" application will

4.2 Every morning at 09:00, the "GloryFitPro" application will

4.2 Every morning at 09:00, the "GloryFitPro" application will

4.2 Every morning at 09:00, the "GloryFitPro" application will

4.2 Every morning at 09:00, the "GloryFitPro" application will

4.2 Every morning at 09:00, the "GloryFitPro" application will

4.2 Every morning at 09:00, the "GloryFitPro" application will

4.2 Every morning at 09:00, the "GloryFitPro" application will

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.