

InFocus • Roku TV

Model: IN-45FA40PR



Read these instructions for correct use before installation.

It is recommended to keep this instructions for future reference.

The images in this instructions are for reference only.

Payment required for some channels and content. Channels can change and vary by region.

Contents

1. Package Contents	2
2. Warnings	3
3. Attach the TV stand or wall mount bracket	5
4. Buttons and Ports	7
5. Using your TV remote control	11
6. Power on the TV	13
7. Complete the guided setup	14
8. Product Specifications	15
9. Quick guide to solve problems	16
10. Certifications and Compliance	17
11. LIMITED WARRANTY	18


1. Package Contents

Your new TV contains the following accessories:

- Two AAA batteries
- Quick Start Guide
- 4 screws (M4 x 18)
- 2 legs that form the TV stand
- Remote control

IMPORTANT:

To prevent accidentally discarding items that came with your TV, be sure to **check ALL the foam** in the carton box.



- Please check foam for accessories before discarding.

Required tools and devices:

- Wireless router (not included) for Internet connectivity.
- Phillips screwdriver (not included) to secure the TV stand.
- HDMI cable and other cables (not included) to connect external devices to the TV.
- Wall mount bracket (not included) if you prefer to mount the TV to the wall.
- Computer or mobile device (not included) needed for setup.

2. Warnings



TO REDUCE THE RISK OF ELECTRIC SHOCK.
DO NOT REMOVE THE REAR COVER.
IT DOES NOT CONTAIN SPARE PARTS INSIDE IT.
CONTACT QUALIFIED SERVICE PERSONNEL.



This symbol indicates the risk of electric shock to the equipment. Only qualified personnel should open and disassemble this appliance.




This symbol indicates the presence of important instructions for the use and maintenance of the equipment, included in the user manual that comes with your equipment.

Security instructions:


1. Do not place the unit in direct sunlight on the screen. Total darkness or reflections on the screen can cause eye discomfort. It is recommended to have a soft and indirect light to see the screen.
2. Leave enough space between the unit and the wall to allow air circulation and ventilation of the equipment.
3. Avoid extremely hot locations to prevent possible unit damage or premature component failure.
4. The unit can operate on the following voltage:
120 V ~ 60 Hz 80 W
5. Do not install the unit near heat sources such as radiators, air ducts, direct sunlight, or inside closed compartments. Do not cover the ventilation openings when the unit is in use.
6. Do not use this apparatus near water or in humid places. To clean your television use a soft cloth, do not use chemicals to clean it and prevent liquid substances from entering the apparatus.
7. Do not apply pressure to the product or throw objects at it.
8. If the product is dropped and the cabinet is damaged, the internal components may not function normally.

Cautions




Caution

High voltages are used in the operation of this product. Do not remove the rear cover of the unit. For service, contact qualified service personnel.




Caution

Never stand on the equipment or push it violently. Make sure the equipment is out of the reach of children.




Caution

To prevent fire or electric shock, do not expose the unit to moisture. Do not place objects filled with water on or near the equipment, such as vases, glasses, etc.




Caution

When you do not use the product for long periods of time, it is recommended to disconnect the power cord from the power outlet.



Caution

Do not insert or drop objects into the ventilation slots on the unit. Never spill liquid of any kind on the equipment.



Caution

The display on this product is made of glass and can break. Therefore this product should not be dropped or struck with force. If the screen breaks, be careful not to get hurt by the broken glass.

3. Attach the TV stand or wall mount bracket (not included)


Attach TV stand (For steps to attach the wall mount see page 6)

CAUTION:

- Be sure to disconnect the A/C power cord before installing a stand or Wall-mount brackets.
- The LED display is very fragile and must be protected at all times while installing the stand. Be sure to protect the TV screen from getting scratched or damaged by any hard objects. In addition, NEVER PRESS the front of the TV at any time because it could crack.

To attach the left and right leg that forms the stand:

1. Carefully place your TV face down on a soft, flat surface to prevent objects from scratching and damaging it.




2. Place the stands into each of the bottom slots, insert and tightened the screws (included in the accessory bag) in the circled area with the screw-driver (not included) until the bases are secure.

3. The TV is ready to use.

Secure the mounting bracket to the wall (not included)

Before you begin with the instructions from the vendor that you have decided to purchase the VESA mount, be sure to start with the following steps:


1. Place the TV face down on a clean, padded surface.
2. Remove the stands if you have previously placed them.
3. Place the spacers (not included) in the 4 mounting holes.



CAUTION:

- When securing the VESA mount bracket, verify that you have used the spacers (included by the vendor you have decided to purchase the wall mount bracket from) between the TV and the mounting holes.

- To prevent internal damage to the TV and to ensure that it is properly mounted to the wall, you can use fixing screws (not included) that are 10 mm long between the back of the TV and the mounting hook.



VESA mounting pattern

VESA mount (mm): 400 x 300

M6, VESA mount screw length = 10 mm


Follow the instructions of the supplier from which you have decided to purchase the VESA mounting bracket.

- To complete the installation, you can ask for help from qualified personnel. Improper mounting can cause an accident.
- The indicated 10mm screws correspond to the length from the mounting bracket to the depth of the holes in your TV.

NOTE: The diameter and length of the screws may differ depending on the VESA mounting bracket model you have decided to purchase.

4. Buttons and Ports

Back view of the TV















Connect devices to your TV



















Your TV has several options for connecting different devices. The method in which you connect will be based upon the type of cables you have and the available outputs on your device.

Check the jacks for position and type before making any connections to your TV. An incorrect or loose connection can cause problems with color and image. Make sure all connections are tight and secure.

The TV may not be compatible with all external devices. To check compatibility, please refer to the user manual of the external device you want to connect.

Do not connect external equipment while TV's power cord is plugged in, it may cause an electric shock.

TV Label	Port	Cable	External Equipment	Brief Description
AIR/CABLE			 Antenna  VHF/UHF Antenna Cable ANT OUT RF Out	Antenna connection. Using your remote control, press the [] button to display input list and select the TV as the input source.
 USB 2.0				Connect a USB 2.0 device to browse photos, music and movies on your TV. *Live TV Pause can pause content received on the antenna TV input for up to 90 minutes and requires a 16GB or larger USB drive and a valid Roku account. All data on the USB drive will be deleted prior to use.
HDMI 1/2			 Game Console	Connect an HDMI cable (not included) from an AV device. Using your remote control, press the [] button to display input list and select the HDMI option as the input source.

TV Label		Port	Cable	External Equipment	Brief Description
HDMI 3 /ARC				 Digital Sound Bar	Connect an HDMI cable (not included) from a digital sound bar, to use Audio Return Channel (ARC) feature. By using this feature, you can control the soundbar's volume with your TV remote instead of having to use multiple remotes for each device. Review the specific steps for this operation in page 10.
AV IN	VIDEO		 Yellow	 DVD Player/Recorder  Set-up Box	Connect a composite video cable (not included) and left-right audio cables (not included) from an external AV device. Using your remote, press the [🏠] button to display the input list and select the AV option as the input source.
	AUDIO-L		 White		
	AUDIO-R		 Red		
OPTICAL				 Audio Amplifier  Speaker	Connect an optical cable (not included) from an external digital audio system. When a digital audio system is connected to the [OPTICAL] jack, decrease the TV and system volume.
					Connect headphones (not included) to hear audio from the TV.
RESET		Press and hold for factory reset. Consider that all your custom settings will be lost.			

Connecting a digital soundbar to use Audio Return Channel (ARC)

To connect a digital sound bar with HDMI cable proceed with the following steps:

1. Connect the cable that's attached to the digital soundbar to the **[HDMI / ARC]** port on the TV.
2. Turn on the digital soundbar by pressing the Power button.
3. Press the **[Home]** button on your remote to display the full menu settings and then use the **UP** and **DOWN** arrows on the **[D-pad]** of your remote to select **Settings**.
4. Press the **RIGHT** arrow to navigate to **System > Control other devices (CEC)**.
5. Highlight **HDMI ARC**.
6. Press **OK** to enable or disable the feature.

Notes:

- Only digital soundbars that require a wired connection are compatible with the Smart TV.
- If the device has an Input Selector feature then make sure to change it to TV option.
- Enabling HDMI ARC also enables System audio control. After enabling HDMI ARC, you can disable System audio control if you prefer.

Connecting to a wireless network

Connect your TV to your wireless network, for this you need a wireless router or modem. See the illustration below.

The TV's built-in Wireless LAN Adapter supports the IEEE 802.11 b/g/n communication protocols. We recommend using the IEEE 802.11 b/g/n router.




Notes:

- You must use the built-in Wireless LAN Adapter in order to use a wireless network, because the set doesn't support an external USB network adapter.
- If the wireless router supports DHCP, your TV can connect more easily to the wireless network.
- If you apply a security system other than the systems listed below, it will not work with the TV.
Security systems: WPA, WEP, WPA2.


5. Using your TV remote control

Begin using your remote


1. Slide the back cover to open the battery compartment of your remote control.



Gently push and slide



Insert the batteries




Gently push and slide

2. Insert two AAA size batteries. Make sure to match the "+" and "-" ends of the batteries with the "+" and "-" ends inside the battery compartment.
3. Replace the battery compartment cover.

Important information about your remote control and batteries:

- Discard batteries in a designated disposal area. Do not throw them into the fire.
- Remove old batteries immediately to prevent them from leaking into the battery compartment.
- If you do not intend to use the remote control for a long time, remove the batteries.
- Batteries chemicals can cause rash. If the batteries leak, clean the battery compartment with a cloth. If chemicals touch your skin then wash immediately.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (NiCd, NiMH, etc.) batteries.
- Do not continue using the remote if it gets warm or hot.

Remote control range information



- The remote control can operate at a distance of up to 26 feet in front of the TV.
- It can work at a 30 degrees horizontal angle.

Buttons on your TV remote



Disclaimer:

Remotes may vary. The images in this manual are for reference only.

* Live TV Pause can pause content received on the antennaTV input for up to 90 minutes and requires a 16GB or larger USB drive and a valid Roku account. All data on the USB drive will be deleted prior to use.

Universal remote setup instructions :


Using your cable set-top box or satellite receiver remote as a universal remote. If you prefer to use your cable set-top box or satellite receiver remote as a universal remote, please refer to the manual that your cable or satellite service provided. It will include instructions on how to program their remote to your television. You can find codes that work with your InFocus•Roku TV and the most common cable and satellite provider's universal remote controls at www.roku.com/universalremote.


IMPORTANT NOTICE:

Depending on the country where the TV is installed, some of the Roku® channels may not be available. The quick launch buttons on the remote control associated with those channels will not work. All other functionalities of the remote will work as designed.

6. Power on the TV

Plug the power cord into a power outlet.



Press the **Power button**  on the remote to turn on the TV.
A splash screen appears that displays the Roku TV™ logo.




Choose Set up for home use to access all TV features and maximize Eco Save.

NOTE: Only retailers that need to set up the TV for display should select Set up for store use.

7. Complete the guided setup

Tip: Have your wireless network name and password handy.
Follow the on-screen instructions that will appear on your Roku TV.



Activate your Roku TV using your computer, smartphone or tablet to set up your Roku account. You need a Roku account to activate your Roku TV and access entertainment across thousands of streaming channels.



Note: Roku does not charge for activation support – beware of scams.

Roku accounts are free and while a valid credit card number is not required to create a Roku account, saving your credit card information makes renting, purchasing, and subscribing to entertainment from the Roku Channel Store fast and convenient.

Once connected to your account, your TV will automatically update with the latest software, and you can start streaming immediately.

If you aren't ready to connect your TV to a wireless network, you can still use it as a regular TV.


8. Product specifications

Model Name		IN-45FA40PR
Dimension (W x H x D)	Without stand	40.03 x 22.96 x 3.49 inches
	With stand	40.03 x 25 x 7.71 inches
Weight	Without stand	17.2 lbs (7,8 kg)
	With stand	17.6 lbs (8 kg)
Active Screen Size (Diagonal)		45 inches
Screen Resolution		1080 x 1920
Audio Power		8 W + 8 W
Rated Power Consumption		80 W (0.5 W Standby mode)
Power Supply		120 V ~ 60 Hz
HDMI Input		480p, 720p, 1080i, 1080p.
Receiving Systems	Analog	NTSC
	Digital	ATSC, QAM
Ports		3 HDMI ports, 1 USB port, 1 Optical Output, 1 RF Input, 1 Earphone Audio Output, 1 RCA Composite Video Input, 1 left/right Audio Input for Composite
Other Features		Smart TV, Dynamic contrast Picture, VESA standard wall mount support

Disclaimer: All product, product specifications, and data are subject to change without notice to improve reliability, function, design or otherwise.

9. Quick guide to solving problems

When you experience an issue with your TV, turn it off and on again. If this does not solve the problem, then refer to the following list of possible solutions. If the problem is still resolved, then contact Manufacturer Customer Care.

Issues	Possible Solutions
You do not see a picture when turning on the TV	<ul style="list-style-type: none">• Check if the LED light is on. If it is, then there is power to the TV.• The TV may be in Standby mode. Press the [] button on the remote control to activate the unit from Standby.• Check if the power cord is plugged into an active electrical outlet.
You have connected an external source to your TV but can not find it on the Home screen	<ul style="list-style-type: none">• Make sure your external device is turned on.• Check to see if the correct input tile is selected in the Home screen for the external source you want to view.• Check to see if the external source device connection is snug and fully inserted into the TV port.• The HDMI port might be hidden from Home screen. Go to Settings> TV Input > to set up the HDMI input on the Home screen.
When you turn on your TV, there is a display for a few seconds before the picture appears	<ul style="list-style-type: none">• This is normal. If you have already set up your TV, it is initializing and searching for previous setting information.
You see normal picture but do not hear any sound	<ul style="list-style-type: none">• Check that volume is turned on.• Check if the Mute mode is On. Turn off mute by pressing the Mute button again, or pressing volume up.• Make sure there is nothing plugged into headphones jack on the TV.• Connecting headphones to the TV will mute the main speakers.
You hear sound but the picture color is faded or in black and white	<ul style="list-style-type: none">• Check that the Color value is set to 50 or greater.• Check the color on another channel or input tile.
Your sound or picture is distorted and appears wavy	<ul style="list-style-type: none">• Turn off and/or remove electrical appliance that may be nearby the TV panel.• Insert the power plug of the TV set into another power outlet.
The sound or picture is blurry or cuts out	<ul style="list-style-type: none">• If you are using an external antenna, check the connections for a snug and tight fit.• Adjust or reposition the antenna placement.
You see horizontal/vertical stripe on the picture, or it is shaking	<ul style="list-style-type: none">• Turn off and/or remove electrical appliance that may be nearby the TV panel.• Insert the TV power cord into another electrical outlet.
You cannot connect to your wireless network	<ul style="list-style-type: none">• Make sure you have selected the correct wireless network name on the Choose Wireless Network screen.• Make sure you have entered your wireless network password correctly (passwords are case sensitive).• If you have the SSID broadcast on your wireless router, add your network by selecting Add Private Network from the Select Wireless Network screen.• To check if it is a password problem, temporarily disable security on the wireless router.• If you are not getting 3 or more signal strength bars above the wireless network icon, adjust the position of the TV (if possible) or the wireless router. Even a few inches in one direction or another may help.
Your remote control is not responding to button presses	<ul style="list-style-type: none">• Check that the TV is still on.• Check that the batteries are good and inserted properly.• Check that there are no obstacles between the remote control and the front of the TV.• Try moving closer to the TV. If the LED on the TV flashes when you press any button on the remote control, the issue is not with the remote control.

10. Certifications and Compliance

Roku, Roku TV and the Roku logo are trademarks or registered trademarks of Roku, Inc. All other trademarks and logos mentioned are the property of their respective owners.

The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. in the United States and other countries.

Manufactured under license from Dolby Laboratories. Dolby, Dolby Audio and the double-D symbol are trademarks of Dolby Laboratories.



FCC Notice

This device has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the device and receiver.
- Connect the device into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

The Wi-Fi Module complies with FCC radiation exposure limits set forth for an uncontrolled environment. This device should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

11. LIMITED WARRANTY

U.S. and Canada only – One (1) year

InFocus TV solely for purchases made in the United States and Canada (collectively “InFocus”) warrants this product against defects in material or workmanship for the original owner and any subsequent end user owner(s) (“You” or “Your”) for the time period set forth above as set forth herein. Pursuant to this Limited Warranty, InFocus will, at its option, (i) repair the product using new or refurbished parts or (ii) replace the product with a new or recertified/refurbished product of the same (or similar) model. For purposes of this Limited Warranty, “recertified” or “refurbished” means a product or part that has been returned to its original specifications. **In the event of a defect, these are Your exclusive remedies.** InFocus does not warrant that the operation of the product will be uninterrupted or error-free.

Term: For the time period set forth above from the original date of purchase of the product when purchased directly from InFocus or InFocus authorized dealer, InFocus will, at its option, repair or replace with a new, recertified or refurbished product or part, any product or part determined to be defective.

This Limited Warranty covers only the hardware components packaged with the product. It does not cover separate accessories, technical assistance for hardware or software usage and it does not cover any software products whether or not contained in the product, and other included content; any such software or other included content is provided “AS IS” unless expressly provided for in any enclosed software Limited Warranty or End User License Agreement. Please refer to the End User License Agreement(s) included with the product for Your rights and obligations with respect to the software or other included content. If You purchased an extended service plan, please refer to the service plan for the coverage, duration and terms of service. Extended service plans are not governed by this Limited Warranty.

To obtain warranty service, You must deliver the product, in either its original packaging or packaging affording an equal degree of protection to the InFocus service center together with a dated purchase receipt in order to obtain warranty service. InFocus cannot guarantee that it will be able to repair any product under this warranty or make a product exchange without risk to or loss of software or data. It is your responsibility to remove or backup any removable media or parts, data, software or other materials You may have stored or preserved on Your product. It is likely that any media, parts, data, software or other materials (like pictures, music, videos, etc.) will be lost or reformatted during service and InFocus will not be responsible for such damage or loss. Contact the following for specific instructions on how to obtain warranty service for Your product:

For Purchases made in the United States & Canada:

Visit InFocus TV Website: www.infocustvs.com

Or call the Customer Service Center: **1-844-446-3628**

To register Your product or for contact information to purchase accessories or parts please contact Customer Service Center.
On-site service for televisions may be available through case by case basis arranged through Customer Service Center.

Repair / Replacement Warranty: This Limited Warranty shall apply to any repair, replacement part or replacement, recertified or refurbished product for the remainder of the original Limited Warranty period or for ninety (90) days, whichever is longer. Any parts or product replaced under this Limited Warranty will become the property of InFocus. Any replacement, recertified or refurbished product provided under this Limited Warranty may, at InFocus' option, vary in color and/or cosmetic design from the original product and may not include any original engraving or similar customization/personalization.

InFocus is not responsible for, and this Limited Warranty does not cover, any damage arising from a failure to operate the product within its intended uses, or otherwise follow the owner's manual and safety instructions relating to the product's use and installation. This Limited Warranty only covers product issues caused by defects in material or workmanship during ordinary consumer use. This Limited Warranty does not cover products purchased from sources other than InFocus or a InFocus authorized dealer (including non-authorized online auctions), or issues due to: (i) outdoor exposure and other acts of nature; (ii) power surges; (iii) accidental damage; (iv) abuse; (v) limitations of technology; (vi) cosmetic damage; (vii) contact with liquid, heat, humidity or perspiration, sand, smoke, or foreign materials; (viii) use of parts or supplies not sold or authorized by InFocus; (ix) servicing not authorized or performed by InFocus or a InFocus authorized service center; (x) computer or internet viruses, bugs, worms, or Trojan Horses; (xi) malfunctions due to peripherals/accessories; (xii) modifications of or to any part of the product, including "rooting" or other modifications to control the behavior of the product or any factory installed operating system; (xiii) consumable parts such as batteries; or (xiv) any product where the factory-applied serial number has been altered or removed from the product. Further, to the extent this product incorporates use of a display, please note that a display contains hundreds of thousands of individual pixels, and displays typically contain a small number of pixels that do not function properly. This Limited Warranty does not cover up to .01% pixel outages (small dot picture elements that are dark or incorrectly illuminated).

This Limited Warranty does not cover InFocus products sold "AS IS" or "WITH ALL FAULTS" or consumables (such as fuses or disposable batteries). InFocus will not replace missing components from any package purchased "Open Box" or "AS IS". This Limited Warranty is valid only in the United States and Canada (as applicable).

LIMITATIONS ON DAMAGES: INFOCUS SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY OR CONDITION ON THIS PRODUCT. NOR SHALL RECOVERY OF ANY KIND AGAINST INFOCUS BE GREATER THAN THE ORIGINAL PURCHASE PRICE OF THE PRODUCT FROM INFOCUS OR AN AUTHORIZED INFOCUS DEALER.

DURATION OF IMPLIED WARRANTIES AND CONDITIONS: EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THIS LIMITED WARRANTY.

Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, or allow limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to You. This Limited Warranty gives You specific legal rights and You may have other rights which vary from jurisdiction to jurisdiction.

For Purchases made in the U.S.: Read the following Dispute Resolution/Arbitration provision carefully. It details Your rights and instructions should a dispute related to the product arise.

What happens if we have a dispute: Should a dispute or claim arise related to the product, Your purchase and/or use of the product, the terms of this Limited Warranty, or any service provided under the terms of this Limited Warranty (including any repair or replacement) ("Dispute"), You and InFocus agree that the Dispute shall be resolved exclusively through binding arbitration. YOU UNDERSTAND AND ACKNOWLEDGE THAT BY AGREEING TO ARBITRATION, YOU ARE GIVING UP THE RIGHT TO LITIGATE (OR PARTICIPATE IN AS A PARTY OR CLASS MEMBER) IN ANY DISPUTES IN COURT. You also agree the ANY DISPUTE RESOLUTION PROCEEDING WILL ONLY CONSIDER YOUR INDIVIDUAL CLAIMS, AND BOTH PARTIES AGREE NOT TO HAVE ANY DISPUTE HEARD AS A CLASS ACTION, REPRESENTATIVE ACTION, CONSOLIDATED ACTION, OR PRIVATE ATTORNEY GENERAL ACTION. Despite the above, You have the right to litigate any Dispute on an individual basis in small claims court or other similar court of limited jurisdiction, to the extent the amount at issue does not exceed \$15,000, and as long as such court has proper jurisdiction and all other requirements (including the amount in controversy) are satisfied.

Arbitration Instructions: To begin Arbitration, either You or InFocus must make a written demand to the other for arbitration. The Arbitration will take place before a single arbitrator. The arbitration will be administered in keeping with the Expedited Procedures of the Commercial Arbitration Rules and the Supplementary Proceedings for Consumer-Related disputes ("Rules") of the American Arbitration Association ("AAA"), when applicable and in effect when the claim is filed. You may get a copy of AAA's Rules by contacting AAA at (800) 778-7879 or visiting www.adr.org. The filing fees to begin and carry out arbitration will be shared between You and InFocus, but in no event shall Your fees ever exceed the amount allowable by the special rules for Consumers Disputes provided for by AAA, at which point InFocus will cover all additional administrative fees and expenses. This does not prohibit the Arbitrator from giving the winning party their fees and expenses of the arbitration when appropriate pursuant to the Rules. Unless You and InFocus agree differently, the arbitration will take place in the county and state where You live, and applicable federal or state law shall govern the substance of any Dispute during the arbitration. However, the Federal Arbitration Act, 9 U.S.C. § 1, et seq., will govern the arbitration itself and not any state law on arbitration. The Arbitrator's decision will be binding and final, except for a limited right of appeal under the Federal Arbitration Act.

Opt-Out Instructions: IF YOU DO NOT WISH TO BE BOUND BY THE BINDING ARBITRATION PROVISION, THEN: (1) You must notify InFocus in writing within 30 days of the date that You purchased the product; (2) Your written notification must be mailed to InFocus TV, 6880 Commerce Blvd, Canton, MI. 48187, Attn: Legal Department; AND (3) Your written notification must include (a) Your NAME, (b) Your ADDRESS, (c) the DATE You purchased the product, and (d) a clear statement that "YOU DO NOT WISH TO RESOLVE DISPUTES WITH ANY INFOCUS COMPANY ENTITY THROUGH ARBITRATION AND/OR BE BOUND BY THE CLASS ACTION WAIVER." Opting out of this dispute resolution procedure will not affect the coverage of the Limited Warranty in any way, and You will continue to enjoy the benefits of the Limited Warranty.

