

aiwa

Prodigy Clear Plus


Noise Cancelling Earphones




Item: AI1202

Quick Start Guide


WHAT'S INCLUDED



AI1202 Earphones and Charging Case




Eartips



USB-C Cable


A CLOSER LOOK

Charging Case




LED Indicator

Front View




Earbud Charge
Status Button


Rear View



USB-C




Eartips



Microphone (ANC)

Microphone (Voice)

CHARGING



First Use


Before first use remove the insulation film from the charging pads on both earbuds.

Place them in the case, they will start to charge, then at the same time charge the case fully. This can take up to 3 hours.

Charging the Earbuds

Place them in the case. Make sure the charging contacts of the earbuds are touching the charging contacts inside the case. Charging the earbuds fully from flat takes 30 mins.

The case indicator LED will turn on green when charging the earbuds and go off when they are charged. When you open the case or press the rear button the LED will also light up green for 8s and then either go off if they are charged or stay on if they are charging.




Charging (Indicator is solid **Green**)



Charged (Indicator is **Off**)

Charging the Case

Connect one end of the included USB-C cable into the Type-C port on the case. Plug the other end into a suitable 5V/1A USB charging adapter. Charging the case fully from flat takes 3 hours.




Charging (Indicator is Amber & Flashing)





Charging Complete (Indicator is Amber)

POWERING ON/OFF

When first using your earphones place them into the case. Remove them from the case and they will automatically turn on. Place them back into the case and close the lid and they will automatically turn off.



You can also turn the earbuds on/off by holding the touch button for 8S




BLUETOOTH PAIRING

When removed from the case the earbuds will find each other and pair together (TWS pairing).

On first use this might take 15S.

Once they have paired together they are ready to pair to your phone.



Go to the Bluetooth settings menu on your phone. Make sure that Bluetooth is turned on. Connect to the device listed as "AIWA Prodigy Clear Plus."


Troubleshooting

If for some reason the earbuds do not pair together you can reset the TWS pairing.

'Forget' the earbuds in your phones Bluetooth Settings. Place them back in the case (which must be charged). Now take them out and wait at least 15S for them to pair together.

Only once they have paired together pair them to your phone.

USING YOUR EARPHONES




LEFT EARPHONE

Decrease Volume: Press
Previous Track: Double Press
Voice Assistant: Press and Hold for 2-3 Seconds
Answer Call: Press
Low Latency ON/Off: Triple Press

RIGHT EARPHONE

Increase Volume: Press
Next Track: Double Press
Play/Pause: Press and Hold for 2-3 Seconds
ANC ON/Ambient ON/ Sound Modes OFF: Triple Press



ANC (Active Noise Canceling)

ANC actively cancels noise around you so that you hear more clearly with less distraction.

Ambient Mode

Ambient Mode turns off ANC and instead amplifies sound around you to counteract the passive noise reduction of the earphones. This is best for situations where you want to hear speech or traffic noise or other ambient sounds.

Clear Calling

The Clear Calling feature uses two microphones to cancel noise pickup in your microphone channel on calls. Clear calling is always enabled when a call is made and can be used with ANC.

Low Latency Mode

This mode reduces the latency (time delay) inherent in Bluetooth connections. This mode gives best lip-sync performance for movies and fastest audio response for mobile gaming.

SPECIFICATIONS

BLUETOOTH VERSION: 5.3

BATTERY CAPACITY (EARPHONES): 40 mAH

PLAY TIME (ANC ON): UP TO 4.5 HOURS AT 50% VOLUME

PLAY TIME (ANC OFF): UP TO 7 HOURS AT 50% VOLUME

CHARGE TIME (EARPHONES): ~30 MINS

CHARGING CASE CHARGE TIME (via cable): ~AROUND 3 HOURS

FAST CHARGING: 5 MINUTES = 50 MINS PLAYTIME

CHARGES IN CASE: 3

CHARGING PORT: USB-C

SAFETY PRECAUTIONS

When using your earphones, basic safety precautions should always be followed including:

1. READ ALL INSTRUCTIONS BEFORE USING YOUR EARPHONES AND CHARGING CASE.
2. Do not use the product near water. Do not put on wet surfaces.
3. Only clean using a clean cloth.
4. Do not allow children to play with this product. This product contains small pieces that can be a choking hazard. Parental supervision is advised.
5. Do not expose this product to excessive heat or fire.
6. Do not expose this product to temperatures above 100°F. Keep out of direct sunlight.
7. Do not attempt to repair this product yourself. Contact a qualified service center if the product is in need of service.
8. Do not drop, crush, or expose this product to excessive physical force.
9. This product is not intended for commercial use.
10. When charging, keep all charging cables well ventilated. Do not keep your charging cable in contact with flammable materials such as bedding, linens or synthetic fabrics.

Maintenance and Care

- Use a soft cloth or paper towel to clean your earphones. Never use any harsh chemicals or detergents for cleaning. Make sure your earphones are dry before charging.
- When your earphones are not in use, they should be stored in a cool, dry place.
- Never tug or yank on a cable while it is connected to your charging case. Connect and disconnect cables as carefully as possible.
- Never expose your earphones to high temperatures, extreme cold.
- Please recycle or dispose of your earphones properly based on the laws and rules of your municipality. Contact local recycling facilities and/or the manufacturer of your earphones for further information.

FCC STATEMENT

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARRANTY

This warranty covers the original consumer purchaser only and is not transferable.

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

What Is Not Covered By Warranty

Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.

To Obtain Warranty Service and Troubleshooting Information:

Call (877) 397-8200 or visit our website at www.aiwa.co.

To receive Warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable Warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address of the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepai red.



©2022 Sakar International
195 Carter Drive
Edison, NJ 08817
www.sakar.com
Support: (877)-397-8200
support@sakar.com