

# USE & CARE MANUAL

## Porch Swing

Thank you for choosing our porch swing!

To ensure years of relaxation and enjoyment, please read this guide carefully before use and refer to it when performing regular maintenance.

### 1. SAFETY INSTRUCTIONS

**Weight Limit:** Always check your specific model's weight capacity.

**Even Installation:** Mount only on sturdy, level structures capable of supporting the swing and its load.

**Hardware Check:** Periodically inspect all bolts, chains, and hooks to prevent wear or failure.

**Children:** Never leave children unattended. Do not allow standing or jumping on the swing.

**Use as Intended:** Porch swings are for seating only — not for sleeping, climbing, or swinging aggressively.

### 2. ASSEMBLY & INSTALLATION

Tools Needed (may vary by model):

Wrench set or socket

Power drill (if installing into beams)

Measuring tape

Stud finder (if mounting to ceiling)

## Assembly Tips:

Assemble on a flat surface.

Do not overtighten bolts during assembly. Tighten fully only once all parts are in place.

Double-check that the seat and backrest are secured and level.

## Mounting:

**Chains or Ropes:** Secure to ceiling joists, a strong beam, or porch frame using rated eye bolts or swing hangers.

**Height:** Seat height should be 17–20 inches from the ground for optimal comfort.

## 3. USAGE GUIDELINES

Sit evenly to prevent tilting or excess stress on one side.

Avoid swinging in extreme weather (wind, rain, snow).

Use cushions designed for outdoor use if included or added.

## 4. CLEANING & MAINTENANCE

**Swings:** Wipe with a damp cloth.

## 5. SEASONAL CARE

**Spring:** Inspect hardware and touch up finishes.

**Summer:** Regular cleaning and shade exposure are ideal.

**Fall:** Clean thoroughly before storing or covering.

**Winter:** Store indoors or use a breathable waterproof cover to prevent moisture damage.