


# **M-Cube Laser Measure**

User Manual


## Basic



## Main Menu



## Laser Measure



## Pro Cases



### Area Mode

Measure the length of sides A and B. The device will automatically calculate the area of the top rectangle.



### Continuous Wall Area

Start by measuring the height (H). Then, measure the lengths of sides A, B, C, D, and more. The device will sum up the total area of all four vertical walls.



### Volume Mode

Measure the height (H), and then measure the lengths of sides A and B. The device will add up the total volume of the space.



### Pythagorean Height

Measure the horizontal length A, and tilted length C. Calculate the height H.



### Indirect Pythagorean Height

Measure the tilted length B, and tilted length C. Calculate the height H.



### Pythagorean Length

Measure the vertical length H, and tilted length C. Calculate the horizontal length B.



### Angle Mode

To calculate the length (L) of any triangle shape, measure adjacent sides (A, B). Then, measure the third side (C).



### Stake Out

Measure the single segment, and get multiple segments.



### Single Segment Length



### Laser/Keypad mode Switch



### Next Step



### Previous Segment



### Current Segment mark



### Next Segment

## Level



### 1) Single Axis Level

Place the device with one side facing upward. The product will enter single axis level mode.



### 2) Dual Axis Level

Place the device with the screen facing upward. The product will switch to dual axis level mode.

## Tech Specs

<b>Battery</b>	900mAh, Input 5V-1A
<b>Materials</b>	ABS Plastic, PC Plastic
<b>Display</b>	1.89" IPS LCD Display with Tempered Glass
<b>Resolution</b>	240ppi
<b>Accuracy</b>	± 1/16in (± 2mm) in Ideal Circumstances
<b>Range</b>	164ft (50m)
<b>APP</b>	Bluetooth Connection With MEAZOR APP



FCC warning:

1. This device should be installed and operated with minimum distance 0cm between the radiator&your body.
2. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
  - (1) This device may not cause harmful interference, and
  - (2) This device must accept any interference received, including interference that may cause undesired operation.
3. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
4. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
  - Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help.