


# Journey 2.0



OPERATION MANUAL  
H1-JNY2


# HELMETS SAVE LIVES!

Always wear a properly fitted helmet that complies with CPSC or CE safety standards when you ride your E-Scooter.



## **Correct Fit:**

Make sure your helmet covers your forehead.



## **Incorrect Fit:**

Forehead is exposed and vulnerable to serious injury.

## **WARNING**

As with all mechanical devices, the Hover-1 Journey 2.0 is subject to wear and tear. Different materials and components may react to wear or tear in different ways. If the design life of a component has been exceeded, it may suddenly fail, possibly causing injuries to the rider. Any form of crack, scratch, or change of coloring in highly stressed areas indicate that the life of the component has been reached and it should be replaced. Do not ride in an abusive manner.

## **CAUTION**

In this manual, the CAUTION sign indicates a hazardous situation which, if not avoided, can cause minor or moderate injury.

## **WARNING**

In this manual, the WARNING sign indicates a hazardous situation which, if not avoided, can cause serious injury or death.

## **WARNING**

Great care should be taken with the Hover-1 Journey 2.0 when folding and unfolding it. Moving and folding parts can cut skin or pinch if mishandled.

**DO NOT RIDE YOUR HOVER-1 JOURNEY 2.0 WITHOUT THE STEERING COLUMN, FOLDING HINGE, AND HANDLEBARS SECURELY LOCKED IN PLACE.**

# **WARNING**

## **PLEASE READ THE OPERATION MANUAL THOROUGHLY.**

**Failure to follow the basic instructions and safety precautions listed in the operation manual can lead to damage to your Journey 2.0, property damage, serious bodily injury, or death.**

Thank you for purchasing the Hover-1 Journey 2.0. Please read all instructions carefully before using it and retain this manual for future reference.

- To avoid collisions, falls, and loss of control, please learn how to ride the Journey 2.0 safely.
- You can learn how to ride the Journey 2.0 by reading the operation manual and watching videos.
- All users are responsible for any consequences caused by violating warning contents or proper operations. Hover-1 can not be held liable.

### **ATTENTION**

1. Use only the supplied charger from Hover-1 with this E-Scooter.
2. The operating temperature range of the charger is 32°F - 104°F (0°C - 40°C).
3. The operating temperature range of the Journey 2.0 is 32°F - 104°F (0°C - 40°C).
4. Do not ride on icy or slippery surfaces.
5. Read the operation manual and warning labels before riding.
6. Store the Journey 2.0 in a dry, ventilated environment.
7. When transporting the Journey 2.0, avoid violent crashes or impact.

## **LOW TEMPERATURE WARNING**

Low temperatures will affect the lubrication of moving parts inside the Journey 2.0, increasing internal resistance. Additionally, the discharge capacity and capacity of the battery will be significantly decreased.

Use caution when riding the Journey 2.0 in cold temperatures (below 40°F/4°C). Doing so may increase the risk of mechanical failures of the E-Scooter, which may lead to damage to your device, property damage, serious bodily injury, and even death.

## **SAFETY INSTRUCTIONS**

- Keep the E-Scooter away from heat sources, direct sunlight, humidity, water, and any other liquids.
- Do not operate the E-Scooter if it has been exposed to water, moisture, or any other liquids to prevent electric shock, explosion, and/or injury to yourself and damage to the E-Scooter.
- Do not use the E-Scooter if it has been dropped or damaged in any way.
- Repairs to electrical equipment should only be performed by the manufacturer. Improper repairs void the warranty and may place the user at serious risk.
- Do not puncture or harm the exterior surface of the E-Scooter in any way.
- Keep the device free from dust, lint, etc.
- Do not use this E-Scooter for anything other than its intended use or purpose. Doing so may damage the E-Scooter or lead to property damage, injury, or death.
- Do not expose the batteries to excessive heat such as direct sunlight or an open flame.
- Do not allow hands, feet, hair, body parts, clothing, or similar articles to come in contact with moving parts, wheels, or the drivetrain while the Journey 2.0 is running.

- Do not operate or allow others to operate the Journey 2.0 until the user understands all instructions, warnings, and safety features described in this manual.
- Check with your doctor if you have a medical condition that could affect your ability to use the Journey 2.0.
- Persons with head, back, neck ailments, or prior surgeries to those areas of the body are not recommended to use the Journey 2.0.
- Do not operate if you are pregnant or have a heart condition.
- Persons with any mental or physical conditions that may make them susceptible to injury or impair their physical or mental capabilities to recognize, understand, and perform all of the safety instructions and assume the hazards inherent in operation should not use the Journey 2.0.

## SERIAL NUMBER

Please keep your serial number on file for warranty claims as well as proof of purchase. Our serial number is stamped on the bottom of the E-Scooter platform. Record the serial number in the designated area of the "WARRANTY" section of this manual in the event that your Journey 2.0 is lost or stolen.

## WARNING

Prolonged exposure to UV rays, rain, and the elements may damage the enclosure materials. Store indoors when not in use.

Devices are not intended for use at elevations greater than 2,000 meters above sea level.

WARNING – Risk of Fire – No User Serviceable Parts.

# INTRODUCTION

Operating the Journey 2.0 without following the contents of this manual may lead to damage to your Journey 2.0 E-Scooter or bodily injury.

## PACKAGE CONTENTS

- Hover-1 Journey 2.0
- Operation Manual
- Charger
- Charging Cable
- Air Pump

## SAFETY PRECAUTIONS

- The first rule of safe riding is to use common sense.
- Different localities and countries have different laws about riding electric transportation devices on public roads. You should check with local officials to ensure you are complying with local traffic law requirements.
- Hover-1 is not liable for tickets or violations given to riders who do not follow local laws and regulations.
- For your safety, always wear a helmet that meets CPSC or CE safety standards. In the event of an accident, a helmet can protect you from serious injury and in some cases, death.

- Obey all local traffic laws. Obey red and green lights, one-way streets, stop signs, pedestrian crosswalks, etc.
- Ride with traffic, not against it.
- Ride defensively; expect the unexpected.
- Give pedestrians the right-of-way.
- Do not ride too close to pedestrians. Alert them if you intend to pass them from behind.
- Slow down at all street intersections and look to the left and right before crossing.
- If you are riding your E-Scooter in low-visibility conditions, ensure your LED headlight is turned on, and that you are wearing bright, reflective clothing.



## WARNING

When you ride in low-visibility conditions such as fog, dusk, or night, you might be difficult to see, which could lead to a collision. To increase your level of safety, be sure to wear bright, reflective clothing when riding in low-visibility conditions.

- Do not ride above your skill level. Ensure you have had enough practice with all functions and features of your Journey 2.0.
- Do not ride too fast – with increased speed comes increased risk. If you are moving at a higher speed, small bumps can create strong impacts, leading to a higher risk of injury.
- Do not ride with pets.
- Before stepping on your Journey 2.0, make sure it is placed flat on level ground.



- Do not try to open or modify your Journey 2.0 E-Scooter. Doing so voids the manufacturer warranty and may cause your Journey 2.0 to fail, resulting in injury or death.
- Do not use the Journey 2.0 in a manner that would put people or property in danger.
- If you are riding near other riders, be sure to maintain a safe distance between each other to prevent collisions.
- Be sure to keep your feet on the Journey 2.0 at all times. Moving your feet off your Journey 2.0 while driving is dangerous and may cause the Journey 2.0 to stop suddenly or veer sideways.
- Do not operate the Journey 2.0 while under the influence of drugs or alcohol.
- Do not operate the Journey 2.0 when you are restless or sleepy.
- Use your best judgment to keep yourself out of dangerous situations with your Journey 2.0.
- Do not ride your Journey 2.0 off of curbs, ramps, or attempt to operate in a skate park, empty pool, or in any way similar to a skateboard. Misuse of your Journey 2.0 voids the manufacturer warranty and may lead to injury or damage.
- Do not abuse your Journey 2.0. Doing so can damage your unit and cause failure to the operating system, which may lead to injury. Physical abuse, including dropping your Journey 2.0, voids the manufacturer warranty.
- Do not operate in or near puddles of water, mud, sand, stones, gravel, debris, or near rough and rugged terrain.
- The Journey 2.0 can be used on paved surfaces that are flat and even. If you encounter uneven pavement, lift your Journey 2.0 over and past the obstruction.
- Do not ride in inclement weather: snow, rain, hail, sleet, on icy roads, or in extreme heat or cold.
- Bend your knees when riding on bumpy pavement to absorb the shock and vibrations. This will help you keep your balance.
- If you are unsure if you can safely ride on a specific terrain, step off and carry your Journey 2.0. Always be on the side of caution.



## WARNING

Proper use of your brake is vital to ensure safe, efficient stopping. To avoid misuse and potential injury, do not apply sudden or excessive force to your brakes. Apply your brakes gradually and give yourself enough room to come to a complete stop safely.

- Do not attempt to ride over bumps or objects greater than ½ inch even when prepared and bending your knees.
- Pay attention. Look where you are riding and be conscious of the road conditions, people, property, and objects around you.
- Do not operate the Journey 2.0 in crowded areas.
- Operate your Journey 2.0 with extreme caution when indoors, especially around people, property, and narrow spaces.
- Do not operate the Journey 2.0 while talking, texting, or looking at your phone.
- Do not ride your Journey 2.0 where it is not permitted.
- Do not ride your Journey 2.0 near motor vehicles or on public roads.
- Do not travel up or down steep hills.
- The Journey 2.0 is intended for use by a single individual, DO NOT attempt to operate the Journey 2.0 with two or more people.
- Do not carry anything while riding the Journey 2.0.
- Individuals with lack of balance should not attempt to operate the Journey 2.0.
- Young children and the elderly should not operate the Journey 2.0.
- At higher speeds, always take longer stopping distances into consideration.
- Do not attempt to jump on or off your Journey 2.0.
- Do not attempt any stunts or tricks with your Journey 2.0.

- Do not ride the Journey 2.0 in dark or poorly lit areas.
- Do not ride the Journey 2.0 near or over potholes, cracks, or uneven pavement or surfaces.
- Do not operate your Journey 2.0 off-road.
- Do not turn sharply, especially at high speeds.
- Do not exceed the maximum weight limit of 264 lbs (120 kg).
- Avoid driving the Journey 2.0 in unsafe places, including areas with flammable gas, steam, liquid, dust, or fibers that could cause fire and explosion accidents.
- Do not operate near swimming pools or other bodies of water.
- Maintain a safe braking distance during wet conditions.

## **WARNING**

There may be additional risk of injury if you use your E-Scooter incorrectly. This includes, but is not limited to:

- Jumping your E-Scooter
- Riding over debris or obstacles
- Performing stunts
- Riding off-road
- Riding fast
- Racing other riders
- Riding in an unusual manner

The aforementioned examples add stress to each part of your E-Scooter and can lead to long term damage of the device. Damage to your E-Scooter can lead to an accident or increase your risk of injury. To decrease your risk of injury, use your E-Scooter correctly.

## **WARNING**

To reduce the risk of injury, adult supervision is required. Never use in roadways, near motor vehicles, on or near steep inclines or steps, swimming pools, or other bodies of water. Always wear shoes, and never allow more than one rider at a time.

## **CARE & MAINTENANCE**

- To avoid damage to the Journey 2.0's internal circuitry, do not expose it to liquid, moisture, or humidity.
- Do not use abrasive cleaning solvents to clean the Journey 2.0.
- Do not expose the Journey 2.0 to extremely high or low temperatures, as this will shorten the life of the device, destroy the battery, and/or distort certain plastic parts.
- Do not dispose of the Journey 2.0 in fire as it may explode or combust.
- Do not let the Journey 2.0 come into contact with sharp objects, as this will cause scratches and damage.
- Do not let the Journey 2.0 fall from high places, as doing so may damage the internal circuitry.
- Do not attempt to disassemble the Journey 2.0.
- Use only the charger provided by Hover-1.
- Use only the manufacturer's authorized replacement parts.

## **WARNING**

Avoid using water or other liquids for cleaning. If water or other liquids enter the Journey 2.0, it will cause permanent damage to the internal components.

## **WARNING**

Users who disassemble the Journey 2.0 without permission from Hover-1 will void the warranty.

# BATTERY CARE / MAINTENANCE

## BATTERY SPECIFICATIONS

Battery Type: Rechargeable lithium-ion battery

Charge Time: Up to 5 hours

Battery Voltage: 36Vdc

Battery Capacity: 6Ah

Working Temperature: 32°F - 104°F

Charging Temperature: 32°F - 104°F

Storage Time: 1 year

Storage Temperature: 32°F - 104°F

Storage Humidity: 5% - 95%

## BATTERY MAINTENANCE

- The lithium-ion battery is built into the device. Do not disassemble the device to remove the battery or attempt to separate it from the device.
- When charging the device, only use the enclosed charging cable.
- Do not connect or attach the device or the battery to a power supply plug or directly to a car's cigarette lighter.
- Do not place the device or batteries near a fire, or into direct sunlight. Heating the device and/or the battery can cause additional heating, breaking, or ignition of the battery inside the device.
- Do not continue charging the battery if it does not recharge within the specified charging time. Doing so may cause the battery to become hot, rupture, or ignite.
- To preserve natural resources, please recycle or dispose of batteries properly. This product contains lithium-ion batteries. Local, state, or federal laws may prohibit disposal of lithium-ion batteries in ordinary trash. Consult your local waste authority for information regarding available recycling and/or disposal options.

## WARNING

Failure to follow the safety precautions listed on the following page could lead to serious bodily injury or death.

- Do not attempt to modify, change, or replace your battery.
- Do not use your device if the battery begins to emit odor, overheats, or begins to leak.
- Do not touch any leaking materials or breathe fumes emitted.
- Do not allow children and animals to touch the battery.
- The battery contains dangerous substances, do not open the battery, or insert anything into the battery.
- Only use the charger provided by Hover-1.
- Do not attempt to charge the device if the battery has discharged or emits any substances. In that case, immediately distance yourself from the battery in case of fire or explosion.



## **WARNING**


SEEK IMMEDIATE MEDICAL ASSISTANCE IF  
YOU ARE EXPOSED TO ANY SUBSTANCE  
THAT IS EMITTED FROM THE BATTERY.

# SPECIFICATIONS

Model:	H1-JNY2
Net Weight:	33.73 lbs (15.3 kgs)
Max Supported Weight:	264 lbs (120 kg)
Max Speed:	Up to 16 mph (25 km/h)
Max Range:	Up to 16 miles (25 km)
Max Incline Angle:	15°
Battery Type:	Lithium-ion
Rated Motor Power:	300W brushless motor
Battery Voltage:	36Vdc
Battery Capacity:	6Ah
Power Requirement:	AC 100V-240V, 50 Hz/60 Hz
Folding Size:	(42.5in. x 18.1in. x 18.4in.) (108cm x 46cm x 46.9cm)
Open Size:	(42.5in. x 18.1in. x 44.4in.) (108cm x 46cm x 112.8cm)
Tire Type:	Air-filled tires
Tire Size:	8.5" front & rear
Brake Type:	Electronic brake & rear disc brake
Charger Manufacturer:	COMING DATA CO LTD
Charger Model:	CP4215

# PARTS LIST

- A.** Journey 2.0 E-Scooter
- B.** Handlebar Assembly
- C.** Charger + Charging Cable
- D.** Hex Keys & Bolts
- E.** Air Pump
- F.** 6 Spare Bolts
- G.** Front tire air pump connector




This diagram illustrates the exploded view of an electric scooter, showing the relationship between its various components. The parts are numbered as follows:

- 1: Left handlebar grip
- 2: Left handlebar clamp
- 3: Right handlebar grip
- 4: Right handlebar clamp
- 5: Left handlebar grip cap
- 6: Right handlebar grip cap
- 7: Throttle lever
- 8: Stem cap
- 9: Stem clamp
- 10: Deck plate
- 11: Deck plate screw
- 12: Kickstand
- 13: Rear fender
- 14: Rear fender screw
- 15: Rear wheel assembly


1. LED Display
2. Bell
3. Brake Handle
4. Handlebar (L)
5. Handlebar (R)
6. Throttle
7. Folding Clip
8. Steering Column
9. Folding Hinge
10. Charging Port
11. Foot Deck
12. Kickstand
13. Folding Hook
14. Brake Light
15. Rear Disc Brake



# HOVER-1 JOURNEY 2.0 DIAGRAM



## LED DISPLAY



### HEADLIGHT ICON

Indicates the headlight is activated. Press the power button once to turn the headlight on or off.

### HIGH SPEED MODE

Indicates high speed mode is activated.

### SPEEDOMETER

Displays your current speed in km/h or mph.

Displays the current speed mode when toggled. While powered on, press the power button twice to switch between high and low speed mode:

1 - Low speed mode (Max speed 9 mph)

2 - High speed mode (Max speed 16 mph)

**Press the power button 3 times to switch between mph and km/h**

### BATTERY INDICATOR

Displays your current battery level.

### CRUISE CONTROL ICON

To activate cruise control, long press the throttle down for 8 seconds while riding at a constant speed above 3 mph. You will hear a beep and the cruise control indicator will light up on the LED display indicating that it is activated. Press the throttle down once or squeeze the brake handle to cancel cruise control.

# CHARGING YOUR JOURNEY 2.0

- Ensure that the charging port is clean and dry.
- Make sure that there is no dust, debris or dirt inside the port.
- Plug the charger into a grounded wall outlet.
- Connect the cable with the power supply (100V-240V; 50 Hz/60 Hz).
- Align and connect the 1-pin charging cable into the charging port of the Journey 2.0 (DO NOT FORCE OR BEND THE CHARGING CABLE AS IT MAY CAUSE THE PRONGS TO BEND OR BREAK).
- The charging indicator light on the charger itself should change to red, indicating that your device is now being charged.
- When the red indicator light on your charger changes to green, then your device is fully charged.
- After fully charging your Journey 2.0, unplug the charger from your device and from the power outlet.

## CAUTION


Only use the included charging cable and charger to charge your Journey 2.0. Using any other charger may damage your Journey 2.0.

# ASSEMBLING YOUR JOURNEY 2.0

**PLEASE READ THE FOLLOWING INSTRUCTIONS CAREFULLY**

## ATTACHING THE HANDLEBAR ASSEMBLY

Attach the handlebar assembly by placing it into the steering column, aligning the front and back bolt holes, and tightening the 4 bolts into place with the hex key.



# PINCH POINTS

Some parts of your Journey 2.0 can injure you if mishandled. Moving and folding parts can cut skin. Clamps and pivoting parts such as brake levers can pinch. When folding and unfolding your Journey 2.0, please watch for pinch points where injury may be sustained. Do not leave your hand in these areas during the folding or unfolding process.



## FOLDING & UNFOLDING

To fold your Journey 2.0, push the folding hinge release button and pull the folding hinge down. Push the steering column down to the rear fender. Find the folding clip on the left handlebar and align the opening with the folding hook protruding from the rear fender to lock them together. Your Journey 2.0 should be locked in a folded position.

To unfold your Journey 2.0, pull on the bottom edge of the folding clip to unlock the steering column. Raise the steering column until it is pointing straight up. Pull the folding hinge up and press it against the steering column to ensure it is securely locked.



RELEASE FOLDING HINGE TO  
FOLD STEERING COLUMN

## HIGH SPEED MODE

To activate high speed mode, ensure the Journey 2.0 is powered on and not in motion. Press the power button twice. The high speed mode indicator should light up on your display to indicate it is activated.

## CRUISE CONTROL

To activate cruise control, long press the throttle down for 8 seconds while riding at a constant speed above 3 mph. You will hear a beep and the cruise control indicator will light up on the LED display indicating that it is activated. Press the throttle down once or squeeze the brake handle to cancel cruise control.

## KICK TO START

For safety reasons, the Journey 2.0 will not accelerate unless it is already moving at least 3 mph (1.8 km/h). You must push off the ground with your foot to get the Journey 2.0 moving, then press the throttle to ride it.

# BEFORE RIDING

Before each use, the E-Scooter operator shall perform the pre-operation checks as specified below:

- The area that the unit is to be operated in is safe and suitable for safe operation.
- The braking system is functioning properly.
- All safety labels are in place and understood by the operator.
- Any and all axle guards, chain guards, or other covers and guards supplied by the manufacturer are in place and in serviceable condition.
- The tires are in good condition, inflated properly, and have sufficient tread remaining.



## WARNING

Any Journey 2.0 E-Scooter that does not work properly can cause you to lose control and fall. Do not ride a Journey 2.0 with a part that is damaged. Replace the damaged part before riding.

It is important that you fully understand all the functions of your Journey 2.0 E-Scooter. If these functions are not used correctly, you will not have full control of your Journey 2.0.

Practice using the Journey 2.0 at slower speeds in a flat, open area before taking it out into public areas.

### PRE-RIDE CHECKLIST

Ensure that your Journey 2.0 is in proper working order each time you ride. If a part of the Journey 2.0 does not function correctly, please contact our Customer Support Center.

- Ensure the battery is fully charged before riding your E-Scooter.
- Please wear all appropriate safety and protective gear before operating your E-Scooter.
- Make sure to wear comfortable clothes and flat, closed-toe shoes when operating your E-Scooter.

# RIDING YOUR JOURNEY 2.0

**FAILURE TO FOLLOW ANY OF THE FOLLOWING SAFETY PRECAUTIONS MAY LEAD TO DAMAGE TO YOUR DEVICE, DAMAGE TO PROPERTY, VOID YOUR MANUFACTURER WARRANTY, AND MAY CAUSE SERIOUS BODILY INJURY OR DEATH.**

## OPERATING YOUR DEVICE

Make sure the device is fully charged before the first use. Before turning on your Journey 2.0 E-Scooter, ride it like a normal kick scooter to get comfortable with the device before using it with the motor.

When you are comfortable riding the E-Scooter, power it on. For the motor to activate, you must first push off the ground with your foot to get the E-Scooter moving, then press the throttle down with your thumb.

To slow down, disengage the throttle and squeeze the brake handle to engage the disc brake. The brake is pressure-sensitive, so a tighter squeeze will result in more stopping power. Do not attempt to stop suddenly as this may lead to injury or damage to your brake discs.

Use the handlebars to turn the Journey 2.0 in the desired direction.

The Journey 2.0 can be operated manually if you do not wish to use the motor.

As you get comfortable on the E-Scooter, you will notice it becomes easier to maneuver. Remember at higher speeds, it is necessary to shift your weight when making turns to maintain your stability.

Prepare to brace yourself if you encounter bumps or uneven surfaces. If necessary, dismount your Journey 2.0 and carry it to a safe operating surface.



## WARNING

Do not turn sharply or at high speeds. Do not turn or ride quickly along slopes, as it may cause injury.

## **SPEED AND WEIGHT LIMITATIONS**

Speed and weight limits are set for your own safety. Please abide by the limits listed here in the manual.

- Maximum Speed: 16 mph
- Maximum Supported Weight: 264 lbs



### **WARNING**

Riding the Journey 2.0 while exceeding the weight limit may increase the possibility of injury or product damage.

## **OPERATING RANGE**

The Journey 2.0 can travel up to 16 miles on a fully charged battery under ideal riding conditions. The following are some of the major factors that will affect the operating range of your device:

- Terrain: Operating range is highest when riding on a smooth, flat surface. Riding uphill and/or on rough terrain will reduce the operating range significantly.
- Weight: A lighter user will have a higher operating range than a heavier user.
- Ambient Temperature: Please ride and store the E-Scooter in recommended temperatures. This will preserve operating range, battery life, and the overall performance of your device.
- Speed and Riding Style: Maintaining a moderate and consistent speed while riding yields maximum range. Traveling at high speeds for extended periods of time, frequent starts and stops, and idling will decrease operating range.



### **WARNING**

Proper use of your brake is vital to ensure safe, efficient stopping. To avoid misuse and potential injury, do not apply sudden or excessive force to your brake. Apply the brake gradually and give yourself enough room to come to a complete stop safely.

# SAFETY ALERTS

If a system error occurs or an improper operation is performed while riding your Journey 2.0, the device will alert the user in a variety of ways.

The following are common occurrences that will produce safety alerts. These notices should not be ignored and appropriate action should be taken to correct any improper operation, failure, or errors.

- Prohibited riding surfaces (uneven, too steep, unsafe, etc.)
- Battery voltage is too low.
- The E-Scooter is still charging.
- The E-Scooter is overheating, or the motor temperature is too high.
- When the battery is about to run out of power, the battery icon will flash.
- If any or both tires are blocked, the device will stop after 10 seconds.
- When the battery level has depleted below protection mode, the motor will power off after 15 seconds.
- If a high discharge current is produced during use (such as riding up a steep slope for a long period of time), the motor will shut off after 15 seconds.



# FCC STATEMENT

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

# WARRANTY & ERROR CODES

For warranty information, please visit us at [www.hover-1.com](http://www.hover-1.com)

Error codes	Error E1 - Motor hall failure
	Error E2 - MOS tube failure
	Error E3 - Brake failure
	Error E4 - Throttle failure
	Error E5 - Under voltage protection
	Error E6 - Controller/instrument communication failure
	Error E7 - Overvoltage protection
	Error E9 - Blocking fault

Manufacturer: DGL Group, Ltd.  
2045 Lincoln Highway, Edison, NJ 08817

## UL2272 Compliant

Tested and certified to UL2272 Safety Standard by UL Solutions

The purchaser and rider of this product are responsible for knowing obeying all state and local regulations regarding the use of this product. It is highly encouraged that you read and follow the product instructions including all safety precautions and use protective gear.

NYC consumers, please review fire safety info available here:  
<https://www.nyc.gov/site/fdny/codes/reference/lithium-ion-battery-safety.page>

Affix Serial Number Label Here:



@Hover1Rideables



@RideHover1



@RideHover1



[www.Hover-1.com](http://www.Hover-1.com)