

Handheld Selfie Stick Head A6



User Manual

Operation interface



- ① Stabilizer power switch
- ② Stabilizer charging port
- ③ Light power/adjust button
- ④ Aluminum alloy tube
- ⑤ Wireless Remote
- ⑥ Tripod
- ⑦ Gimbal Unlock Key
- ⑧ Lamp
- ⑨ Lamp Charging Port
- ⑩ Manually tighten screws

Take out & Put in




Detachable remote control

How to replace the battery



Remove the screw
Slide the battery cover up,
You can replace the battery.

Open the Tripod



Open outwards at the
bottom of the handle
and become tripod mode.

How to connect

1. **Switch on and off:** press and hold the camera button for 2s to switch on and off.
2. **Wireless pairing:** Long press the photo button to enter the pairing state, the pairing state indicator 1S / time flashing, use the hand Machine search "Gimbal" to match, matching success, green light off. Once each button is triggered, the green light flashes immediately once.
3. **Camera button:** Long press: switch the machine;
Click: take pictures or videos (start/stop)
4. **No pairing:** After starting up, for 10 minutes without operation under unpaired connection, automatically shut down.
5. **Pairing:** After turning on, when the selfie device is connected to the phone, 10 minutes without operation will enter dormancy state.
6. **Power off:** In the power-on and sleep state, press and hold the camera button for 2s to shut down, and the indicator light will flash and turn off.
7. **Battery:** When the button battery is below 2.6V (Low electricity), flash 0.5S / flash.

Fill light function


- Operation function of fill light:**
Long press: on/off
Single click: set lighting mode and brightness/off flash mode
Double-click: activate flash mode
- White light:** soft light, medium light, strong light
Warm light: soft light, medium light, strong light
Mixed light: soft, medium, strong

Backlight charging method



Number of white lights: 12
White light color temperature: 11000K Lumen: 83LM Power: 0.6W
Warm light color temperature: 3000K Lumen: 90LM Power: 0.6W
Mixed light color temperature: 7000K Lumen: 87LM Power: 0.6W
Battery capacity: 400mAh
Operating voltage/output voltage: 3.7V
Operating current/output current: 0.16A
Charging voltage/input voltage: 5V
Charging current/input current: 450mA

Removable fill light



Take out the backlight from the selfie stick and rotate it 180° horizontal. Rotate 180° vertically and move it to the front of the selfie stick, Align with the hollow concave and convex groove on the selfie stick and install it (Picture 1) Then move down and fix it.



Picture 1

Remote Control

Note: The phone's camera must be on the same side as the power button in order not to interfere with the shooting.


- Long Press:** long press 2S to switch the machine
Click: Photo or video recording (start / shutdown)
Click: Photo or video recording (start / shutdown)
Click: 90, and the horizontal and vertical screen will switch & Portrait Mode
Three strikes: counterclockwise dream space
Double-click: Clockwise dream space
Click: POV half-following mode
Double-click: Cancel the POV mode

Note: Please refer to <Bluetooth Connection> for Bluetooth connection method.

DREAMSPACE MODE(UPSIDE-DOWN MODE)

Dreamspace Mode:
When the phone is landscape mode, levorotation 40° dextrorotation 230° levorotation 230°, dextrorotation 40° (back to the original position);
When the phone is portrait mode, dextrorotation 125°, levorotation 125° and 145°, dextrorotation 145° (back to its original position)

FUNCTION DISPLAY DIAGRAM




How to use the Gimbal



How to use the Gimbal Clamp the phone and keep the natural balance. Long press the power button for 3 seconds to turn on, and long press 3 seconds to turn it off.

Click: 90, and the horizontal and vertical screen will switch & Portrait Mode
Three strikes: counterclockwise dream space
Double-click: Clockwise Inception

How to charge the Gimbal



When the gimbal power is too low, the three white lights flash together in the low power state, at this time to use the Type-C port charging, charging process white lights gradually flashing to full 3 white lights always on

Specification

- Main Material: ABS+Aluminum Alloy
- Mount Holder: 108.7-150.4mm
- Folded Length: 180mm
- Extended Length: 790mm
- Product Size: 180x40.9x70.5mm
- Product Weight: 240g
- Remote Control Battery: CR1632(replaceable)
- Gimbal Battery: 400mAh
- Working voltage: 3.7V
- Charging voltage: DC5V
- Charging current: 500mA

(Batteries must not be exposed to sunlight, fire or similar overheating)

REMIND

- Selfie Stick compatible with Android 4.4 and above & iOS 5.1 and above (if you change the system's "volume button function" under your phone's camera option, be sure to change it to default, or "take a picture" to make the selfie stick work)
- The clip must be held tightly when the phone is clamped.

1. Gimbal Stabilizer Mode: the best use in the 3 rods
2. Selfie Stick Mode: 5 rods are recommended

Thank you for your support!

FC CE RoHS

FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.