User Manual

Thank you very much for choosing this Switch game Controller. Please read this Manual in detail before use in order to operate and use it correctly, and bring the superior performance of the product into full play. The descriptions in this Manual are based on the default settings of the device, all the pictures, statements and text information are for reference only, please refer to the actual product. The content is subject to update without further notice. The update will be included in the new version of the Manual, and the Company reserves the right of final interpretation. Available functions and additional services may vary by device, software or service provider. Please charge the Controller before use. If there are typographical errors or translation errors, we sincerely hope for all users understanding!


Product Photo





1. Mode and Connection operation instruction


Bluetooth Switch mode

(1) Turn the Switch console on, click the System Setting Menu button on the home screen, after enter to the next level of the Menu option and click the Airplane Mode option, then click the Controller Connection (Bluetooth) option to turn the Bluetooth function ON, and then turn the Airplane Mode option off.













(2) Enter the Switch console Bluetooth Pairing Controller mode, click the Controllers Menu button on the Console home screen, after entering the next level of Menu options, click the Change Grip/Orde option and the Console will automatically search for the matching Controller.





- (3) In the shutdown state, press the Y+HOME button of Controller or long press the Pairing button 3S to enter Bluetooth pairing mode, LED1-LED4 light flashing quickly, after the successful connection, the Switch Console will automatic distribution Controller channel and the corresponding channel indicator light will always be on; Synchronizing states or pairing with the Console: LED1-LED4 light flashing quickly.
- (4) In the shutdown state, directly insert the USB data cable into the USB port of the Switch console, if the console and the original charging base are integrated, insert the USB into charging base (Remark: need to open the wired controller connection option in the Console Setting), pair the console through the USB cable connection, and the Controller will automatically connect back to the console through Bluetooth wireless mode after unplug the USB cable.





Bluetooth standard Android Mode

In the shutdown state, press and hold the Controller A +HOME button to enter Bluetooth pairing mode, LED2+LED3 flashing quickly, then open the Android device Bluetooth for search, find and click the "Gamepad" device name in the list of available devices to pair, the LED2+LED3 are light on after pairing successful.

Remark: In Android mode, the Controller has not vibration, axis functions.

Bluetooth IOS protocol Android Mode

In the shutdown state, press the X+HOME button to enter pairing mode, LED1+LED4 flashing, then open Android device Bluetooth for search, find and click the "Xbox Wireless Controller" device name in the list of available devices to pair. After the pairing succeeds, the corresponding LED1+LED4 is steady on.

Bluetooth IOS Mode

In the shutdown state, press the X+HOME button to enter pairing mode, LED1+LED4 flashing, then open IOS device Bluetooth for search, find and click the "Xbox Wireless Controller" device name in the list of available devices to pair. After the pairing succeeds, the corresponding LED1+LED4 is steady on.

(Remark: The IOS device system need be 13.0 or above, the Controller has not vibration, axis functions in this mode).

Bluetooth PC (X-INPUT) Mode

In the shutdown state, press the X+HOME button to enter pairing mode, LED1+LED4 flashing, then open the PC Bluetooth for search, find and click the "Xbox Wireless Controller" device name in the list of available devices to pair. After the pairing succeeds, the corresponding LED1+LED4 is steady on, the Controller enter X-INPUT mode, can be used directly in Windows 10 system and above.

USB Mode

In the Controller power-off state, insert it into the PC USB port through the data cable, it is automatically recognized as X-INPUT mode (default mode) and LED1+LED4 is light on. In PC X-INPUT mode, long press the "-" +" button 3S to switch to D-INPUT Controller mode, and LED2+LED3 is light on.

TURBO speed adjustment

Hold down the TURBO key and press the corresponding key to set TURBO; to set the automatic TURBO mode, repeat the setting again, you can set the key: A,B,X,Y,L,ZL,R,ZR; To cancel the TURBO function, repeat the Settings; There are three gear TURBO speed adjustment (5-10-15HZ); TURBO + right 3D rocker push up: increase the speed of continuous shooting by 1 gear; TURBO+ right 3D rocker push down: reduce the speed of continuous shooting by 1 gear, default middle gear.

Motor vibration intensity adjustment

Press and hold the TURBO+ left 3D rocker push up: increase motor vibration strengthen; TURBO+ Left 3D rocker push down: decreases the motor vibration; 100% -75% - 50%- 0%, 4 gear intensity adjustable, Controller motor adjustment has a memory function.

RGB Light effect Set

- * Short press the LIGHT+R3 key together (right rocker push down) to switch the light effect mode, each press can switch the light effect mode (Dazzling light single color light single color breathing light single color breathing cycle light).
- * In Dazzling light mode, short press the LIGHT+L3 key together (left rocker push down) to pause and save the current Dazzling light effect mode.
- * In single color light mode, short press the LIGHT+L3 key (left rocker push down) to switch the light color.
- * In single color breathing light mode, short press the LIGHT+L3 key (left rocker push down) to Switch the light color.
- *In single color breathing cycle light mode, short press the LIGHT+L3 key (left rocker push down) to pause and save the current mode, press again to turn on the Breathing mode again.
- * In each mode, the brightness of the RGB light can be adjusted by pressing the LIGHT+(UP/DOWN arrow key) at the same time, by pressing the combination key once to adjust the one gear brightness; The LIGHT+UP combination key increases the brightness, and the LIGHT+DOWN combination key decreases the brightness.
- * Long press the LIGHT key 5S to close or open RGB light. Light effect Settings with memory function will automatically save the current setting of the light effect mode.

2. Wake up / Re-Connection Function

Press the HOME button for 1 second to wake up the Controller, reconnect and wake up the hibernating Switch console, the Controller will automatically sleeps if the connection fails in 15 seconds.

The controller has a mode memory function, which will keep the current mode after shutdown. Press the HOME button to wake up the Controller, and you can directly reconnect to the last saved mode.

3. Charging Indication

In controller shutdown state, the LED1-LED4 mode indicator blinks slowly while charging, and the LED is off after fully charged.

Battery low voltage alarm: The current mode indicator is blinking (quickly). The current mode indicator blinks (slowly) when charging, and the current mode indicator is steady on when fully charged.

4. Automatic sleep/Power-On/Off

The console screen closed, the Controller automatically sleeps; the Controller automatically sleeps


if without any key action (including sensor action) after 5 minutes. In Bluetooth mode, long press the HOME key for 5 seconds to close the Controller.

5. Lower voltage alarm

When the Controller battery is low, the current mode indicator blinks quickly indicating that the battery is low, if you continue to use the Controller until the voltage is lower than a certain value, the Controller will automatically enters the sleep state.

6. 3D joystick calibration

When there is a problem with the left and right 3D joystick, you can calibrate the 3D joystick through the console. Enter the calibration operation interface as shown in the following figure, and complete the corresponding actions according to the console instructions. When the console pops up the calibration completed, the calibration is complete.




7. Six-axis Calibration

If the axis sensor on the Controller has abnormal problems, the axis sensor of the Controller can be

restored to normal work through the axis calibration function; Axis calibration operations can be performed in any of the following ways.


(1) In the connection state, enter the sensor calibration interface through the console, keep the Controller flat on the plane and press the "+" or "-" key, when the console pops out the calibration completed, the calibration is complete.




(2) In shutdown state, press and hold the "A" + "-" + HOME keys 3S to turn on the Controller, Two groups front and rear lights flashing each other, press the "+" key again, LED lights extinguished then the calibration is complete.

8. Button Test

If the Controller buttons fail or do not work, you can use the console button test option to test whether each button function is normal.





Test Controller Buttons

Check if the controller buttons are working properly.

Test Touch Screen

Check if the touch screen works properly.



9. Reset Function

When the Controller function is abnormal or stops working, you can reset the Controller by pressing the Reset button at the bottom of the Controller.

10. Product Specification

Product Name: SWITCH wireless Controller Product Model: SZ-933A

Battery: 3.7V 800 mAh Li battery axis sensor: Six axis gyro sensor

Charge Voltage: DC 5V Working voltage & current: 3V & ≈25-100mA

Charge Current: ≈500mA Static working current: <5µA

Charge Time: ≈2.5小时 Working distance: 6m

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment

off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- •Reorient or relocate the receiving antenna.
- •Increase the separation between the equipment and receiver.
- •Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- •Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.