

Stratum™ -X5 Series

Quick Installation Guide

IMPORTANT!

For regulatory information and latest product updates, including firmware and the MIBs, please visit Proxim's support site at <http://support.proxim.com>.

The device must be installed by a trained professional who is familiar with radio frequency

Introduction

The Stratum™ X5 is a highly efficient radio endpoint that delivers gigabit-plus throughput in both point-to-point and multipoint wide area network configurations.

Able to operate in MIMO 4x4, with either integrated or external antenna (software switchable on some variant), the Stratum™ X5 is ideally suited to high-capacity backhaul, high-resolution video surveillance, or high-density multipoint deployments.








Powered by Proxim WORP® (Wireless Outdoor Router Protocol), managed via web GUI, CLI, Bluetooth-enabled Proxim BlueConnect™ and SNMP for ProximVision® Advanced, this high-speed platform offers advanced Quality of Service, granular service level management, and very secure networking.

Products Covered in This Guide

Model	
SX5-1040A	SX5-1042A

Package Contents

Each shipment includes the items listed in the following table. Please verify that you have received all the parts in the shipment, prior to the installation.

What's in the Kit	SX5-1040A	SX5-1042A
Stratum Device		
PoE Injector with country specific power cord US & TH - US power cord WD - US and EU power cord		
Connector Weather Proofing Kit		
Pole Mounting Kit		
Grounding Kit		
Quick Installation Guide		



Device Overview




Figure 1: SX5-1040A

Figure 2: SX5-1042A

The device contains the following features (not all features are available for every variant):

Item	Features	Description
1	Ethernet Port-1	<ul style="list-style-type: none">2.5 Gbps Ethernet802.3at/bt PoE In
2	Ethernet Port-2	<ul style="list-style-type: none">1 Gbps Ethernet802.3at PoE Out
3	SFP+ Port	<ul style="list-style-type: none">SFP+ Port with 10 Gbps Data transfer
4	Access Port	<ul style="list-style-type: none">12v External DC IN Supply
A1,A2, A3&A 4	5 GHz Antenna Ports (A1,A2,A3&A4)	<ul style="list-style-type: none">A provision to connect external antenna in MIMO 4x4 mode.Connect A1 to Antenna Vertical Polarity port and A2 to Antenna Horizontal Polarity port.Connect A3 and A4 to Antenna Slant Polarity ports.
5	GPS Connector	<ul style="list-style-type: none">A provision to connect passive GPS antenna for device positioning.
6	View LEDs & RSSI LEDs Display	<ul style="list-style-type: none">Displays boot up information (see View LEDs section).RSSI LEDs behavior Information (see RSSI LEDs Behavior Section).
7	Mounting Holes	<ul style="list-style-type: none">A provision to connect 10000-UMK mounting kit.
8	Hose Clamp Slits	<ul style="list-style-type: none">A provision to attach hose clamps (1/2 inch or 12 mm width) for pole mounting.
9	Grounding Points	<ul style="list-style-type: none">A provision to ground the device.

Important: Stratum X5-1042A device includes a Quad polarization 18 dBi panel antenna which is enabled by default. To use external antenna instead, switch to external antenna mode via BlueConnect application or via Web GUI. Refer to the antenna switching procedure in the Device Management Guide.

Weatherproofing RJ45 Connection

The following steps explain how to weatherproof the RJ45 connection:




Figure 3: Weatherproof the RJ45 connection

1. Use an outdoor rated CAT5e/CAT6 cable with a straight-through terminated on both ends.
2. Insert the CAT5e/CAT6 cable through the Sealing Nut (D) and install the Compression Washer (C) to the cable. Compression Washer (C) has a slit in the middle for quick installation onto the cable.
3. Install the parts (D) and (C) in the direction as shown in Figure 2.
4. Insert the Flat Washer (A) onto the Connector Body (B) and then insert the CAT5e/CAT6 cable through the Connector Body (B).
5. Connect the cable end of RJ45 connector into Ethernet port of the device.



6. Make sure that the locking latch of RJ45 Connector is properly inserted into the Ethernet port.
7. Fasten the Connector Body Assembly to the Device Ethernet port hole and fully tighten it.
8. Slide and Insert the Compression Washer (C) into the Connector Body Assembly.
9. Fasten the Sealing Nut (D) to the Connector Body Assembly and fully tighten it to weatherproof the cable.

Additional Weatherproofing Steps

To add an additional layer of protection to connectors against the environment, do the following:

1. Wrap vinyl tape in a half-lapped fashion, from the weatherproof connector end and continue wrapping down 3 inches onto the CAT5e/CAT6 cable.
2. Next, wrap a layer of the butyl mastic tape over the adhesive side of the tape, covering all of the tape and connector.
3. Wrap a final layer of vinyl tape over the butyl layer and cover the entire tape assembly.
4. Place a small zip tie over the last wrap of tape to prevent it from unwrapping over time.

For detailed explanation of RJ45 connectors and RP-SMA connections weatherproofing, refer to *Stratum™ X5 Series Hardware Installation Guide* at <http://support.proxim.com>.

Assemble the Mounting Hardware

1. Fix the Mounting Plate (A) onto the bottom of the device using the provided screws and washers such that the antennas will be vertically and horizontally polarized when mounted; also, it is recommended to partially fasten the screws with washers into all the mounting holes, prior to final tightening of each screw. Torque the screws to 75 Lbf-in (86 Kgf-cm)
2. Fix the Extension Arm (B) to the fixed Mounting Plate (A) with the provided bolt, nut, and washers. The Extension Arm (B) gives the device more possible tilt, letting you adjust for azimuth or elevation over a larger angle.




Figure 4: Assemble the Mounting Hardware

Mount the Device

1. To pole-mount the device, insert the provided bolts through Bracket (D), mate with Bracket (C) around the pole, and secure with supplied washers torquing to 100 Lbf-in (115 Kgf-cm). The supplied screws (Hex. Cap 5/16" x 4" long) are designed for pole diameters from 32 to 89 mm (1.25 to 3.5 inches).
2. Fix the fixed Extension Arm (B) to the Mounting Bracket (C) with the provided bolt, nut, and washers. Partially tighten the joints J1 and J2 to allow for alignment of the device.
3. Once satisfied with the alignment, tighten the assembled parts by applying torque 130 Lbf-in (150 Kgf-cm).
4. While installing the device, make sure that the device Ethernet Port-1 with cable installation (using cable gland) faces downward only as shown in Figure 5 below:




Figure 5: Pole Mounting

- To wall-mount the device, mount the bracket (C) to a wall by using 4 screws (not supplied), as shown figure below shown:





Figure 6: Wall Mounting

Plug in the Cables

Note: Unscrew the sealing cap port cover for installation of cables.

- Plug one end of the straight-through Cat5e/CAT6 cable into the Ethernet Port-1 of the device by following the Weatherproofing steps explained under section Weatherproofing RJ45 Connections. Connect the other end of the cable into the **OUT / PoE** port on the PoE Injector.
- Plugging in the second Cat5e/CAT6 cable to the Ethernet Port-2 is optional.



Note: 56V DC (30 W maximum) is available on the Ethernet Port-2; hence, ensure that connected device is rated to use the above voltage and maximum power.

- When PoE IN receives 56V DC, PoE OUT delivers the same voltage, i.e., 56V DC.
 - By default, the Ethernet Port- 2 is for Data only; however, it is possible to enable the PoE OUT and Data feature through Web configuration. Please make sure to disconnect the Ethernet Port-2 cable from the PC before enabling this feature.
- To connect the device through a hub or a switch to a Personal Computer, connect an Ethernet cable between the network interface card in the Personal Computer and the hub, and between the hub and the RJ45 **IN / LAN** port on the PoE Injector.
 - To connect the device directly to a Personal Computer, connect an Ethernet cable between the network interface card in the Personal Computer and the RJ45 **IN / LAN** port on the PoE Injector.
 - The PoE Power injector is a Gigabit Ethernet port and can supply up to 60 Watts.

Note: Optional 2.5/5 Gbps 802.3bt PoE injector is available (Part Number: 949-00147), place an order separately with your distributor.

Install Surge Protector

Stratum™ X5 Series comes with a built-in Ethernet surge protection; however, it is mandatory to install an approved lightning surge protector at the building ingress point. Moreover, if you are installing the device in a region subjected to violent thunderstorms or severe weather conditions, then installation of an additional approved lightning surge protector near the device is recommended.


Note: To buy an additional Surge Protector (Part Number: 235-00001), place an order separately with your distributor.

Perform the following steps to ensure proper surge protection:

- Mount a surge protector near the building ingress and use 10AWG or larger wire to connect the surge protector's ground lug to earth ground.
- The outdoor device and co-located surge protector should have a common grounding point using the shortest possible grounding cable.

Note: Use Outdoor-rated, UV protected, shielded CAT5e/CAT6 cable for the following.

- Connect an RJ45 terminated cable between the indoor equipment and to the port on the surge protector at the building ingress.



- Connect an RJ45 terminated cable between the surge protector and the outdoor device on Ethernet Port-1.


IMPORTANT: Ensure to loop the cable before entering the premise to prevent water ingress.



Ground the Device

To ensure proper grounding, attach a ground wire of at least 12 AWG stranded to the device at either of the ground points which are located at the bottom corners of the device and use the grounding screw provided. It is important to follow the grounding guidelines below to protect the device against lighting or ESD events:

- Connect one end of the grounding cable to the device and the other end to the closest earth ground point at the installation site.
- Remove any extra ground wire length when finished connecting it to the single point earth ground.
- Avoid sharp bends, loops or coiling the ground wire, always connect it straight to ground.
- A proper earth ground impedance is less than 1.0 ohm.
- Measure ground impedance at the point where the surge protector ground wire is connected and not at the grounding rod.
- Connect the surge protector ground wire and equipment ground (both power ground and telecomm ground) to a single common ground.
- Make sure all connections are fastened securely and tight.
- Never install a link during a storm and always follow your local safety codes.



Power on the Device

After connecting the PoE Injector and the device using straight-through CAT5e/CAT6 cable plug the power cord into a power outlet. There is no ON/OFF switch on the device. To power down the unit, unplug the RJ45 connector from the **OUT / POE** port on the PoE injector.

View LEDs

When the device is powered on, it performs startup diagnostics. When startup is complete, Ethernet LEDs show the device's Ethernet state.



Figure 7: Power & Link LEDs

LED State	Off	On
1G	Ethernet Port-2 not connected	Ethernet link is established
2.5G	Ethernet Port-1 not connected	Ethernet link is established
PWR	Power is Off	Power is ON

RSSI LED Behavior

During the first two minutes, after the device is turned on or rebooted, the unit LED indicators provide the following information:

LED State	Off	On
RSSI_LED-1 (Lower)	Power is OFF	Power is ON
RSSI_LED-2	Wireless 1 (5 GHz) is OFF	Wireless 1 (5 GHz) is ON
RSSI_LED-3	N/A	N/A

LED State	Off	On
RSSI_LED-4	Flash is corrupted (requires RMA)	Flash is Ok
RSSI_LED-5 (Higher)	Ethernet is DOWN	Ethernet is UP




Figure 8: RSSI LEDs Display

Initialize the Device

You can configure the IP address of the device by using HTTP, SNMP, CLI or Proxim's ScanTool.

For remote management of a device using Proxim BlueConnect application, refer the procedure given in the Device Management Guide at <http://support.proxim.com>.

Bluetooth Key: 123456

The following are the default access values of the device:

- Default IP address:** 169.254.128.132
- Subnet Mask:** 255.255.255.0
- Gateway:** 169.254.128.132
- Username:** admin
- Password:** public
- SNMP Read Write Community String:** public

Download Software and Documentation

To download the Software and Documentation, please visit the Proxim support site at <http://support.proxim.com>. Once you log on, select the product category **Stratum™X5 Series** from **Product Downloads Page** and links to the latest software, SNMP MIB file and documentation will be available for download from the **Stratum™X5 series download and documentation page**.

Note: You need Acrobat Reader to view the PDF documents.

Technical Support

- Proxim Customer Support Web site is available 7x24x365 at <http://support.proxim.com>
- Telephone Support:**
 - US and Canada:** +1-408-383-7700; +1-866-674-6626
 - International:** +1-408-383-7700
- Business Hours:** Tier 1 support: 24x7 live response.
Tier 3 support: 8 a.m. to 5 p.m. M-F PST (UTC/GMT -7 hrs).

Proxim Wireless Corporation
2114 Ringwood Ave,
San Jose/ CA 95131, USA.
Toll Free:+ 1 800-229-1630
Phone:+ 1 408-383-7600
Fax: +1 408-383-7680
<http://www.proxim.com>