
NYLAVES


USER MANUAL


Computer Speaker | SK600





Button Control			
Function	Operation	Voice Prompt	LED Indicator
Plug in	Insert the USB plug into any USB charging adapter or active computer USB port	1	Green light on for 1 second
Power on	Hold the Power Button for 2 seconds	Beep	LED flashing red and blue alternately (it defaults to Bluetooth mode when it's turned on for the first time)
Power off	Hold the Power Button for 5 seconds	Beep	Red light on for 1 second
Play/Pause	Press the Power Button once	1	I
Switch to Bluetooth/ Aux-in mode	Press the Mode Button once	Веер	1
Bluetooth pairing	I .	Веер	LED flashing red and blue alternate
Bluetooth connected	T.	Веер	1
Disconnect Bluetooth	Hold the Mode Button for 5 seconds	Beep	LED flashing red and blue alternatel
Toggle music effect	Press the EQ Button once	Bass, Balance	I .
Volume +	Turn the Volume Knob clockwise	1	1
Volume -	Turn the Volume Knob counter clockwise	7	1
Change lighting modes	Tap the LED Touch Point once	T	⊕ rhythm
Turn off/on the Light	Hold the LED Touch Point for 2 seconds	1	Light off/on
Reset	Hold the EQ Button for 10 seconds	7	1





3 Connect to your audio source device via the 3.5mm Audio Cable.

Troubleshooting of Sound If there is no sound comes out from the speaker, please try the following operations: > Rotate the volume knob clockwise to raise the volume of the speaker. > Press the volume knob to resume in case the speaker paused ➤ Re-insert the USB plug and restart. Troubleshooting of Bluetooth Connection > Make sure the Bluetooth of the speaker is not connected by other devices. ➤ Unplug the 3.5mm Audio Cable from your device. ➤ Delete "SK600" memorized on your device, then search for "SK600" and connect again.

Worry-free Service Guarantee

30 days free return and exchange.

Lifetime friendly customer service.

Please contact us for more details and further instructions via

support@nylavee.net

Extend 2-years warranty:

www.nylavee.net

FCC Compliance
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must withstand any interference received, including

F© (€ KHS 🗵 😘

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 5mm between the radiator and your body.