





TRI PRO MULTI-SPORT

WATERPROOF OPEN EAR HEADPHONES

SWIM 🚇 BIKE 🔥 RUN 🕉





TABLE OF CONTENTS:

BATTERY
TURN ON/OFF
BUTTON FUNCTIONS

M (MIDDLE / MODE BUTTON) +/- BUTTONS

DOWNLOAD VIA USB
MEMORY MODE - FOLDERS & SHUFFLE
BLUETOOTH CONNECTION & PAIRING
PLAYLIST
HOW TO WEAR
BIKING AND RUNNING WITH H2O TRI
SWIMMING WITH H2O TRI
SUPPORT & TROUBLESHOOT





HOW TO CHARGE

Connect the 4 pin USB cable to the H2O Tri (It will attach only 1 way with the magnets).

- BATTERY CHARGING: Red LED
- BATTERY FULL: Blue LED
- FULL BATTERY PLAY TIME: ~6 hrs

When you turn ON the H2O TRI you will hear the current battery level status.



POWER ON/OFF

TURN ON/OFF:

Press and hold the middle button for 3 seconds.

To RESET - hold for 10 sec





BUTTON FUNCTIONS



+/- BUTTONS

VOLUME UP/DOWN: 1-Click

SKIP SONG: Hold + or - to skip to next or

previous track.

SKIP FOLDER: 2-click to advance to next/previous folder (only in memory

play mode)

PLAYLIST+

2-click + button to start/stop Loading (Only in Bluetooth Mode)

M (MIDDLE/MODE BUTTON)

POWER ON/OFF: Hold (3 sec) to Power ON/OFF

PLAY/PAUSE: 1-Click to Play/Pause audio

MODE CHANGE (Memory <-> Bluetooth):

2-Click (Double Click)

RESET: Hold for 10 seconds to Reset. Make sure headphones are Off. After 10 seconds you will see the LED light blink 3 times.

SHUFFLE MODE:

3-click (triple click) to turn on/off (Only in memory mode)

SIRI/VOICE ASSISTANT

Long Press (Only in Bluetooth Mode)

ANSWER INCOMING CALL

1-click (Only in Bluetooth Mode)



DOWNLOADING MUSIC VIA USB

- Make sure the battery is changed. If battery is too low the USB connection may fail.
- Turn OFF the headphones.
- Then, connect the USB cable to the H2O TRI 4-pin connector and then to the computer USB port. DO NOT BUMP the headphones while it is connected.
- After connecting, wait for few moments to the computer to register the device.
- H2O TRI will appear as a memory drive or USB Memory device in the File Explorer (Windows) or Finder App (MAC).

IMPORTANT NOTE: Subscription based music like Spotify, Apple Music, Pandora, etc. are copyright protected and can NOT be copied to the memory via USB. See PLAYLIST+ feature.

- Find the music files on your computer. The H2O TRI can play .MP3, .WMA and .M4A (Apple iTunes) music.
- Select or Copy the music files and then copy/paste or 'drag & drop' the files to the H2O TRI.
- The file transfer will start. Do not disconnect until all files have been copied.
- To remove or delete files on the H2O TRI simply select the files in the H2O TRI memory and Delete them or drag to Trash.
- To disconnect it from the Computer, click Eject the H2O TRI or simply disconnect it.

TROUBLESHOOT USB CONNECTION

If you are having trouble with the USB connection, disconnect the H2O TRI from the computer, power off H2O TRI and restart the computer. After your computer has done a full restart – try to connect again. You can also try a different USB port. Make sure your H2O TRI battery is charged. You can also reset the H2O TRI headphones. Turn Off the headphones and the hold the Mode button for 10 sec. You will see a 3 blinking of the LED light.



MEMORY / BLUETOOTH PAIRING

MEMORY MODE (FOLDERS & SHUFFLE)

- The music can be organized into different folders.
- You will have 2 added folders. LOAD and FAVORITE. The LOAD folder will keep any audio you have loaded via PLAYLIST+.
- Skip to next or previous folder = 2-CLICK +/- button.

Turn on Shuffle Mode: 3-click M button to turn on / off shuffle mode.

BLUETOOTH CONNECTION & PAIRING

- Start with the H2O TRI headphones OFF.
- Power ON the headphones (press middle button for 2 sec). You will hear the start up prompts and battery level.
- Change the MODE to BLUETOOTH MODE by 2-click or double clicking the M button. You will hear Bluetooth Mode.
- Go to the Bluetooth Settings in your phone or smart watch. Look for the H2O TRI name and select it. This will complete the pairing and you will hear "Connected" prompt. A blue blinking LED light will also indicate that the Bluetooth is connected.

PLEASE NOTE

Bluetooth connection has a range of approx. 10m/30ft. in air and 10cm/2 inches under water. Bluetooth does not penetrate water (due to laws of physics)
PLEASE SEE PLAYLIST+ and SWIMMING WITH H2O TRI for more.



PLAYLIST+ is H2O Audio's Patent Pending Technology to load any Bluetooth audio into the headphones and listen without any phone even underwater. Use this with you favorite streaming apps, audio books, podcasts and more. Any audio you play over Bluetooth can be LOADED to the TRI PRO memory.

TO START ADDING AUDIO TO YOUR PLAYLIST+

- 1. Enter Bluetooth mode and pair the headphones with your smartphone.
- 2. Start your favorite music (you should hear it from the headphones.)
- 3. Start/Stop LOADING: 2-Click the + button. A BLUE LED will bling rapidly indicating the LOAD is active.


While loading, the TRI PRO will listen to the audio and store it. Make sure your play volume is set high enough. Any changes in volume will also be in the loaded audio.

You can also charge the TRI PRO battery while it is LOADING. Make sure it is connected to a wall charger (not a computer).

4. To Play the PLAYLIST+: Enter the Memory Mode and skip (2-click + button) to the LOAD Folder.



The **H2O TRI headphones** are **OPEN EAR** and use Bone Conduction. The Speakers are sitting **IN FRONT** of the ear vs in the ear, leaving your ear open for other surrounding sounds.



BIKING & RUNNING WITH H2O TRI

When biking or running, you can use either the Bluetooth or the Memory Mode.

- The memory mode will play music from the internal memory without the need of any other devices. i.e. you can leave your phone home.
- You can also listen to PLAYLIST+ audio without your phone.
- The Bluetooth mode will receive audio from a device you are carrying. Make sure you have paired the headphones with the device.

SAFETY TIP

It is important to adjust the audio level so that you are able to hear ambient sounds from around you – cars, traffic, etc. The H2O TRI has an open ear design that will allow you to hear what's around you easier.



SWIMMING WITH H2O TRI

WHICH MODE SHOULD I USE?

When swimming, we recommend using the Memory Mode – as this will provide you the uninterrupted sound without the need of additional devices.

Use PLAYLIST+ load music from Bluetooth and listen to it underwater!

If you have a music enabled smart watch like the Apple Watch – you can use this as the source for your audio while swimming. However, you need to place the smart watch with in 2-3 inches from the headphones. Put the watch under your swim cap or use the H2O Audio Apple Watch Clip (sold separately). NOTE: The Bluetooth range under water is only few inches (due to laws of physics)

HOW TO WEAR DURING SWIMMING:

Use your swim goggle strap or swim cap over the headphones to better keep the headphones in place.

TIP

For best audio experience, we recommend using earplugs to reduce the ambient sound of water splashing.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. in portable exposure condition without restriction.



SUPPORT & TROUBLESHOOT

TO RESET THE H2O TRI HEADPHONES:

Make sure the power is **OFF**, then press and **HOLD** the Power button for 12 seconds. This will reset the headphones.

ANY ISSUES?

Please do not hesitate to contact us at **SUPPORT@H2OAUDIO.COM**

Please note that your product has a 1 YEAR WARRANTY.

H2OAUDIO.COM

FOR MORE TIPS AND VIDEOS





H2OAUDIO,COM/PAGES/H2O-TRI-HEADPHONES