

Quick Start Guide

PowerXL™

products that excel

STEAMER AIR FRYER

See owner's manual for complete instructions and important safety information before using this product.

IMPORTANT: Unpack all parts from the box and remove any clear or blue protective film on the components. Wash with warm, soapy water before first use (only select accessories are dishwasher safe).

STEP 1



Remove Basket

For Air Frying: Pull the Handle straight out.

For Steaming: Remove the Water Tank, turn it over, and remove its cap. Fill the Water Tank with 4 ½ cups (1100 ml) of water. Close and tighten the Water Tank's cap and return the Water Tank to the appliance. Pull the Handle straight out.

STEP 2



Load Basket

Ensure the Fry Tray is in place in the Basket. If not, place the Fry Tray in the Basket and push down. Arrange the food you are cooking on top of the Fry Tray.

STEP 3



Return Basket to the Appliance

Push the Handle straight in until it clicks.

STEP 4



Power the Appliance On

Set the time and temperature. Follow instructions specific to your recipe.

STEP 5



Remove Basket

Set the Basket on a secure, heat-resistant surface. Use tongs to remove food.