

The ESP32-WROVER-E and ESP32-WROVER-E use the ESP32-D0WD-V3 "chip from the ESP32 series. The ESP32-D0WD-V3 chip has the characteristics of scalability and adaptability. Two CPU cores can be controlled separately. The adjustment range of CPU clock frequency is from 80 MHz to 240 MHz. Users can turn off the power of the CPU and use low-power coprocessors to monitor the status changes of peripherals or whether certain analog quantities exceed their values. ESP32 also integrates a variety of peripherals, including capacitive touch sensors, Hall sensors, SD card interfaces, Ethernet interfaces, high-speed SPI, UART, I2S, and PC.

152mm

155.5mm

156mm

155.5mm

The left buttons are Food, Account, WiFi, and About. On the far left of the right button are 'Insert' and 'Remove'.

Connect the receiver.

Connect the phone to the display screen and insert the screen with the rocket into the machine.

The external sensing emission device can be activated after being connected.

First, install the bracket onto the base, and then place the tablet on top of the bracket. Next, fix the box with handles to the right side of the base

Install the bracket structure onto the base.

First, install the bracket onto the base, and then place the tablet on top of the bracket. Then fix the box with handle to the right side of the base. Finally, use the provided wrench to firmly fix all parts and complete the assembly process

Insert the wire into the wire hole.

Insert the vertical descending component into the base and embed the circular component into that area

Open the WiFi connection on your phone and assemble the assembled parts.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.