

## **Quick Installation Guide**

Dual Band WiFi Repeater

A18/A15

(A18 is used for illustration in this guide)

### Package contents

• Ethernet cable × 1 • Quick installation guide × 1


For product or function details, please go to www.tendacn.com to download the

## Method 1:

## Extending your WiFi network using web UI

## **1)** Power on the repeater

Plug the repeater into a power outlet near the router in the Wait until the PWR LED indicator turns solid on.



## 2 Extend your WiFi network

- 1. Connect your WiFi device to the repeater's SSID Tenda EXT. Ensure that the **Mobile Data** (if any) function of your WiFi device
- 2. After connecting to the repeater's SSID, you will be directed to the quick setup page. If not, start a web browser, and access re.tenda.cn or 192.168.0.254 in the address bar.



3. Create a login password for security (recommend) and click  ${f Next.}$ 



4. Select the WiFi network (SSID) you want to extend.



### **LED Descriptions**

LED indicator	Status	Description
PWR	Solid on	The repeater is connected to a power source properly.
	Off	The repeater is not powered on.
Signal	Solid blue	The repeater has connected to your existing WiFi router, and its position is proper.
	Solid red	The repeater is too far away from the router. Relocate the repeater closer to the router.
	Off	The repeater does not connect to your WiFi router.
WPS	Solid on	A WPS connection has been established.
	Blinking	A WPS connection is being established.
	Off	The WPS function is disabled.

## **Buttons and ports**

Button/Port	Description		
WPS	Press the button of the router, and enable the WPS function of another device within 2 minutes to establish a WPS connection.		
RESET	When the PWR LED of the repeater is solid on, hold down this button using a needle, and release it when all the LED indicators blink once then turn off. When the PWR LED indicator turns solid on again, it is reset successfully.		
	LAN port.  - In repeater mode, it is used to connect to a computer or an IPTV STB In AP mode, it is used to connect to your wired router to provide wireless network for wireless devices.		

5. Enter the password for the selected WiFi network. Modify your repeater's SSID (optional), and click Extend.




Wait until the Extended successfully page appears

## **3** Relocate the repeater

For better performance, follow the on-screen tips or the steps below to relocate your repeater.

- 1. Plug the repeater into an outlet halfway between the router and the WiFi dead zone.
- The location you choose must be within the range of your existing WiFi network.
- 2. Wait until the Signal LED turns blue. If not, relocate the repeater closer to the router.



## 4 Connect to the Internet

Connect your WiFi devices to the repeater using the SSIDs set by yourself, or your router's SSID with the suffix **\_EXT** or **\_5GEXT** if they are not changed, and using the WiFi password which is the

### Method 2:

### **Extending your WiFi network using WPS**

You can use Method 2 if your router has a WPS button, which may be indicated by ( ), (ws), or otherwise, use Method 1.

## 1 Power on the repeater


Plug the repeater into a power outlet near the router in the same

Wait until the PWR LED turns solid on.



## 2 Extend your WiFi network


1. Press the WPS button on the router. Within 2 minutes, press the WPS button on the repeater.



2. Wait until the Signal LED on the repeater turns solid blue or red.

## (3) Relocate the repeater

- 1. For better performance, plug the repeater into an outlet halfway between the router and the WiFi dead zone.
- The location you choose must be within the range of your existing
- 2. Wait until the Signal LED turns solid blue. If not, relocate the repeater closer to the router.



### (4) Connect to the Internet

Connect your WiFi devices to the repeater. The repeater's SSIDs are your WiFi router's SSID with a suffix **\_EXT** or **\_5GEXT**. The WiFi password of the repeater is the same as your WiFi router.

### FAQ

## Q1: I cannot log in to the web UI of the repeater. What should I do?

- A1: Try the following solutions:
- If a WiFi device is used, ensure that your WiFi device has nected to the repeater's WiFi network **Tenda\_EXT**, and the Mobile Data (if any) function is disabled.
- If a computer is used, ensure that your computer has connected to the repeater's WiFi network **Tenda\_EXT**, and your computer has set to **Obtain an IP address** automatically and Obtain DNS server address
- Reset the repeater, and try again.

## Q2: How to reset the repeater?

A2: When the PWR LED of the repeater is solid on, press the RESET button on the repeater using a needle, and release it when all the LED indicators blink once then turn off. After the PWR LED turns solid on, the repeater is restored to the factory settings successfully.

### Q3: The repeater cannot find the WiFi network of my router. What should I do?

- A3: Try the following solutions:
- Ensure that the WiFi network of your router is enabled and can be detected by your WiFi
- Change the channel of your router, and try
- Change the encryption type of the router to WPA-PSK or WPA2-PSK, and try again.

# FC

### FCC Statement

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

— Reorient or relocate the receiving antenna.

— Increase the separation between the equipment and receiver.

— Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

— Consult the dealer or an experienced radio/TV technician for help.

This device is restricted to be used in the indoor.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.





**NOTE:** (1) The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. (2) To avoid unnecessary radiation interference, it is recommended to shielded RJ45 cable.

Declaration of Conformity

Hereby, SHENZHEN TENDA TECHNOLOGY CO. LTD. declares that the radio equipment type A18 is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address: http://www.tendacn.com/en/service/download-cata-101.html.

**Declaration of Conformity**Hereby, SHENZHEN TENDA TECHNOLOGY CO. LTD. declares that the radio equipment type A15 is in compliance with Directive 2014/53/EU.
The full text of the EU declaration of conformity is available at the following internet address:

Radiation Exposure Statement
This device complies with FCC radiation exposure limits set forth for an uncontrolled environment and it also complies with Part 15 of the FCC RF Rules.
This equipment should be installed and operated with minimum distance 20cm between the device and your body.

viction:

y changes or modifications not expressly approved by the party responsible for compliance could void the 
y's authority to operate this equipment.
s transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

**NOTE:** (1) The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. (2) To avoid unnecessary radiation interference, it is recommended to use a shielded RJ45 cable.

## IC RSS warning Industry Canada(RSS-Gen Issue 4)

The device for operation in the band 5150-5250 MHz is only for indoor use to reduce the potential for

les dispositifs fonctionnant dans la bande 5150-5250 MHz sont réservés uniquement pour une utilisation à l'intérieur afin de réduire les risques de brouillage préjudiciable aux systèmes de satellites mobiles utilisan

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following t

(1) This device may not cause interference; and (2) This device must accept any interference, including interference that may cause undesired operation of

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage; (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Operating Temperature: 0 °C - 40 °C Operating Humidity: (10% - 90%) RH, non-condensing



RECYCLING

This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycle or dismantled to minimize its impact on the environment.

. Jser has the choice to give his product to a competent recycling organization or to the retailer when he



nongshanyuan Road, Nanshan District, Shenzhen, China. 518052

USA hotline: 1-800-570-5892 Toll Free: Daily-9am to 6pm PS

Copyright
© 2020 Shenzhen Tenda Technology Co., Ltd. All rights reserved.

\*\*randa\* is a registered trademark legally held by Shenzhen Tenda Technology Co., Ltd. Other brand and product names mentioned herein are trademarks or registered trademarks of their respective holders.

Specifications are subject to change without notice.