


5b

OPTION 1 - Using Power Adapter Provided: The power should connect into the green input labeled GND /V+. This should be ran to the supplied adapter for the proper amount of power. Note that the keypad can only handle between 12v - 24v and nothing below or above. Warranty does not cover a damaged pad due to improper power installation. **DO NOT attempt to power the keypad using the power board from a gate motor. You must use the adapter provided.**



Owner/Manager Steps

Download Managers App! You will need login credentials, which will be provided to you by a Spiderdoor team member. Search App stores on your mobile device for the Spiderentry Managers App. Download the app and this will allow managers to access their gates from anywhere. Lastly, You can also login on your desktop at

www.management.spiderdoor.com


This will allow you to view activity log, photos of tenants, (on certain keypad models) and open or latch open your gate, all from the Spiderdoor dashboard. Email us at Support@Spiderdoor.com




Spiderdoor (205) 821-6000
INSTALL GUIDE

S33

1. Unpack the box and make sure you have all items shown below.



2. Unlock and open the front door to install and wire properly. Door will pull forward but needs to be lifted out of the slots during install. Do not open door too far or you can damage! You can also unplug punch pad cable if needed during install. Be careful when plugging punch pad cable back in.




WARNING


AUTOMATIC GATE CAN CAUSE SERIOUS INJURY OR DEATH!

ALWAYS CHECK THAT THE GATE PATH IS CLEAR PRIOR TO OPENING!
SAFETY REVERSING DEVICES SHOULD ALWAYS BE USED!


- 3 Mounting on a wall/stud:** Choose which side your stud is on and simply punch out the holes on the desired side. Then use a sheetrock screw or a comparable type screw to secure the keypad to the wall. Be sure to secure the pad somewhere at the top of the keypad as well as at the bottom. You can mount to pedestal as well.



- 4a Gate Install:** Bring one wire from normally open(NO) and one wire from common(COM) on the gate motor over to the input labeled gate on the board. Input labeled GATE, represents normally open and common inputs.



- 4b Mag Lock Install:** If using a Magnetic lock for a walk through door, you will want to use N/C (normally closed) and the COM (common wire) slot. In the illustration below, the green wire goes to the magnetic lock from the keypad. The blue wire also goes from the keypad out to the magnetic lock installed on the walk through door.



Keypad Sounds


ACTIVE CODE

A solid 4 second buzz means the gate code entered is a good code.

INACTIVE CODE

Three short beeps signifies that a code is INACTIVE or no good.

- 5a OPTION 2 - Using POE For Power:** Plug a CAT5/6 cable from your current modem (coming from current internet provider - Orange cable) into the slot labeled CAT 5/6 Then plug another CAT 5/6 cable into slot labeled "OUT," on the POE SWITCH and this line will go straight to your keypad (Using yellow Cable in diagram). This cable is what gives your keypad low voltage DC power that is needed to run the keypad. Plug into the CAT5/6 input inside keypad.



REQUIRED: Call us at (205) 821-6000,
24 hours in advance or email
Support@Spiderdoor.com

FCC Compliance Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION: The grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF exposure statement

This equipment complies with the FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 30cm between the radiator and any part of your body.

Canadian Compliance Statement

This device contains license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada license-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
(2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

L'appareil ne doit pas produire de brouillage;

L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

RF exposure statement

This equipment meets the exemption from the routine evaluation limits in section 6 of RSS-102. It should be installed and operated with a minimum distance of 30cm between the radiator and any part of your body.

Cet équipement est conforme à l'exemption des limites d'évaluation habituelle de la section 6 de la norme RSS-102. Il doit être installé et utilisé à une distance minimale de 30 cm entre le radiateur et toute partie de votre corps.

**Supplier's Declaration of Conformity
47 CFR § 2.1077 Compliance Information**

Product Name: Access Control Keypad

Product Model: S23, S33

Manufacturer:

Spiderdoor

2284 Brock Circle

Birmingham, Alabama 35242

support@spiderdoor.com

www.spiderdoor.com

Modular Components Used:

NAME: nRF91

MODEL: nrRF9160

FCC ID: 2ANPO00NRF9160

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.