












5-Bar Ratings

		The connector is clean and in perfect condition.
		The connector is clean and in good condition.
		The connector is in good condition. Try cleaning it to improve its condition.
		Consider replacing the connector after multiple cleaning attempts.
		Consider replacing the connector after multiple cleaning attempts.

Inspecting Single-Fiber Connectors








Compatible with







When paired with EXFO Exchange, the unit will automatically upload the results via Bluetooth.



Startup / Bluetooth Connection / Inspection

LEDs	Meaning
	The FIP-200 is starting up.
	New Bluetooth connection: Press the capture button to confirm the connection.
	The FIP-200 is ready to take a capture.
	The autofocus, capture or analysis process is in progress.
	The capture process is complete. You can now remove the inspection tip from the connector.

Inspection Errors

LEDs	Meaning
	Autofocus timeout: Clean the connector and ensure the connector/tip is inserted correctly.
	Positioning error: Hold the FIP-200 straight and retry.
	Focus quality error: Hold the FIP-200 steady and retry.
	Hardware error: Contact EXFO Technical Support for assistance.

EXFO Technical Support: 1 866 683-0155 (USA and Canada)
Tel.: 1 418 683-5498
support@exfo.com

Scan the QR code to access the support page for more information:
www.exfo.com

