

8855-000 – 8860-000

Quickstart Guide

Last Updated: January 15, 2024




Contents

In the box	01
What you'll need	02
Installation	03
Configuration	04
Testing	05
Regulatory	06
Support	07



01

In the box





IoT Sensor USB Reader

Cord is USB-A format
(USB-C available as special order)



Optional Accessories



9200-007-01 - 55 Degree Desktop Mount

Stand for use on desk
environment



9004-08-10 - Wall Mount Bracket

For mounting to wall
(includes screws for fixing)



02

What you'll need



- A WiFi connection is preferable however configuration is also possible using the Safetrust Wallet App
- A PC/printer/device to plug the USB into



03

Installation






To install, simply uncoil the cord and plug the IoT Sensor USB Reader/or Programmer into your laptop or desktop computer. Within 5 seconds, the IoT Sensor will complete its "power on cycle" and be operational and ready for configuration.



04


Configuration





Open the Safetrust Wallet App and select the Manage Sensor tab. Make sure your system administrator has set you up with this role.





With the Admin Installer tab open from the App, bring the phone in range of the IoT Sensor and once visible from the App, highlight and select “Configure.”






- Choose an Identity System*.
- Specify the Type of access from the dropdown (eg. Computer, Printer etc.)
- Assign a short Name and Description using alphanumeric characters.
- Choose a Media Output for the sensor (the default is set to USB Keyboard).

**Note: Identity System must be previously created in the Safetrust Credential Manager portal by a system administrator.*






Tap the Configure WiFi button to add a WiFi configuration; select from an available WiFi Profile or manually enter WiFi details.

Once complete, tap the 'Submit' button at the bottom of the configuration screen to save settings*.

**Note: The IoT USB will restart to apply the changes to the configuration.*





When the IoT Sensor information is saved successfully to Credential Manager and assigned to the Identity System, the new description will appear in the Manage Sensor tab with a unique serial number assigned.



Settings Key

Output media USB

- Human Interface Device (Keyboard)
- Terminal Mode (CDC Serial)
- OSDP Over USB (CDC Serial)
- (future) CCID APDU (Smartcard)
- (future) Emulated Network Driver

Credential System

- Defines the credential number mask such as facility and card length.
- Supported technologies such as DESFire, Prox, iCLASS, Apple Access, HCE, etc.

Human Interface Device Data Model

- Hexadecimal Wiegand, Card Number, Facility+Card number
- Custom format with static text, card, facility raw
- Carriage return and line feed

Networking

- Enterprise-grade WiFi options, including PPSK, 802.1x EAP/TLS



05

Testing



LED Ring

Access with cards

Status LED



Solid red

Indicates idle mode



Flashing red, blue, green


Power up mode



Flashing green

Card credential is read
and transmitted
through designated
wires





Access with Mobile – BLE

Status LED



Solid red

Indicates idle mode



Flashing red, blue, green

Power up mode



Solid Blue

Mobile credential
detected



Flashing green

Mobile BLE credential is
read and transmitted
through designated wires



LED Ring



Access with Mobile – NFC

Status LED



Solid red

Indicates idle mode



Flashing red, blue, green

Power up mode



Flashing green

Mobile BLE credential is
read and transmitted
through designated wires



06

Regulatory Information



FCC: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Canada Radio Certification: This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

CE Marking: Safetrust hereby declares that these proximity readers are in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.



07

Support

Thank you for purchasing the Safetrust IoT Sensor USB.

If for any reason you need assistance with your installation, please contact your local Sales representative .

Sincerely -
The Safetrust Team



www.safetrust.com/support