



## **Atlas 15.6" FHD Intel N100 USB-C Laptop**

**with Windows 11 Pro (128GB)**

KAL15E900PA



# Safety & Warnings

- Read all instructions and warnings in this user guide before use and retain this user guide for future reference.
- This laptop is suitable for use in non-tropical areas below 2,000 metres.
- The provided power adaptor requires 12V and 3A to charge the laptop. Do not use any third-party adaptors to charge the laptop.
- Do not drop the laptop.
- Do not have the laptop strongly impacted by heavy objects or surroundings.
- It is recommended that the maximum temperature of charging is no more than 25°C and the maximum temperature of discharging is no more than 45°C.
- Do not expose the laptop to direct sunlight.
- Avoid using the laptop in areas with strong magnetic or static fields.
- Do not allow water or any other liquid to touch the laptop. If any water or other liquid splashes onto the laptop, close it immediately and unplug the power adaptor. Do not use the laptop until it is completely dry.
- Do not attempt to modify or disassemble the laptop yourself.
- Regularly backup data stored in the laptop to avoid the risk of accidental data loss.
- Do not clean the laptop with any chemical detergents or other liquids to avoid causing damage.
- Replacing the laptop battery with the incorrect type may result in an explosion. Only use the original battery. To replace the battery, contact **help.Kogan.com** for support.

# Components



Laptop



Power Adaptor



User Guide


# Overview

## Front View



1	Camera	Used for photos, recording video and video calls.
2	Display	HD LCD display panel.
3	Microphones	Built-in twin microphones can be used to record audio and interact in video calls.
4	Indicators	These respective indicators will illuminate when power, caps lock, or the digital key lock is used.
5	Power button	Used to control the power status of the laptop.
6	Keyboard	QWERTY keyboard with Windows key and function options.
7	Track pad	Used as a mouse for on-screen navigation and gestures.
8	Left/right track pad buttons	Used as the left and right-click buttons of a traditional mouse.

## Left View




## Right View



9	Charging indicator	Illuminates red when the laptop is charging.
10	Charging port	Plug the power adaptor into the charging port to charge the laptop.
11	USB 3.0 port	Input for flash drives, additional keyboard/mouse and other compatible devices supporting USB 3.0 or older.
12	HDMI port	Suitable for connecting a TV or external monitor using an HDMI cable (not provided).
13	USB-C port (full function)	<ul style="list-style-type: none"><li>• This port can be used for charging the laptop with suitable adaptor.</li><li>• Suitable for connecting a device for data transfer.</li><li>• Suitable for connecting a monitor for video playing.</li></ul>
14	3.5mm audio port	Suitable for connecting audio devices (for example, headphones, external speakers, amplifiers) using an AUX cord (not supplied).
15	USB 2.0 port	Input for flash drives, additional keyboard/mouse and other compatible devices.
16	USB-C port (data transfer only)	Suitable for connecting a device for data transfer.

**Bottom View**



17	Speakers	Two built-in speakers allowing for stereo audio output.
----	----------	---

# Operation

## Getting Started

- Connect one end of the power adaptor to the charging port on the laptop and the other end to an electrical outlet. Switch on the power at the outlet. The 'Charging' indicator will illuminate red.
- Press the 'Power' button to turn on the laptop. During the first startup, you may be prompted to set up Windows 11. Follow the on-screen instructions to complete the setup.

### Note:

Charge the laptop for at least 3 hours before turning it on for the first time.

## Using Windows 11

### Desktop

Once the setup is complete, the laptop will boot to the desktop. Icons on the desktop serve as shortcuts to access applications. To open an application, double-click its icon.



### Note:

You may need to log in to your Microsoft account to ensure full compatibility with programs.



## Start Menu

- Click the Windows icon at the bottom of the screen to access the Start menu.
- Installed apps can be accessed from the Start menu. Recently used apps will appear under the 'Recent' section for quick access.
- Additional apps can be downloaded and installed via the Microsoft Store.

Microsoft Store



Windows icon

## Notification Menu

- Click the time/date in the lower-right corner of the screen to open the notification menu.
- This menu displays notifications such as updates, emails, and calendar reminders and provides quick access to settings like Wi-Fi, Bluetooth, and brightness adjustments.



## Multitasking

- Drag one window to the left or right side of the screen. Release it when an overlay appears, occupying half the screen.
- Select another open window to fill the remaining half of the screen.



## Sleep, Restart and Shut Down

- Click the Windows icon at the bottom of the screen, then select the 'Power' icon.
- Choose Sleep, Restart, or Shut Down to perform the desired action.
- To wake the laptop from sleep, press the 'Power' button.
- If the laptop becomes unresponsive, press and hold the 'Power' button to force a shutdown. Press the 'Power' button again to restart the laptop.



Power Icon

# Cleaning & Care

- Ensure the laptop is switched off before cleaning.
- Wipe the laptop surface with a dry, soft cloth or paper towel.

# Specifications

Display	
Screen size	15.6"
Screen resolution	1920 x 1080
Performance	
CPU	Intel 100
CPU speed	Up to 3.4GHz
GPU	Intel® UHD Graphics 750MHz
Operating system	Windows 11 Pro
System memory (RAM)	4GB
Power	
Battery capacity	5000mAh
Battery type	Lithium-ion polymer battery
Storage	
SSD slot	SATA M.2 2280 SSD
Storage capacity	128GB
Storage type	SSD
3.5mm audio port	Yes
HDMI	x1, 1.4a
USB 2.0	x1
USB 3.0	x2
Micro SD card slot	N/A
Connectivity	
Bluetooth	5.0
Wi-Fi	Yes
Wi-Fi protocols	802.11b/g/n/ac
Audio	
Speaker	x2, 1W
Other	
Dimensions	357 x 241 x 22.4mm
Weight	1.76kg
Built-in webcam	Yes

# Troubleshooting

## The Laptop is Not Turning On

- The battery may be fully depleted. Charge the laptop for at least an hour before attempting to turn it back on.
- Observe whether any indicators or internal components, such as fans, turn on during the process.

### Note:

If the laptop is stored for an extended period, it is recommended to charge it periodically to maintain battery health. Batteries naturally deteriorate over time and may lose capacity or fail entirely.

## The Laptop is Not Charging

Inspect the laptop, charging port and power adaptor for any physical damage. If damaged, cease use immediately and contact [help.Kogan.com](mailto:help.Kogan.com) for support.

## The Laptop is Not Connecting to Wi-Fi

- Restart your modem and router (or both if you have separate units).
- Reconnect any range extenders being used.
- Restart the laptop.
- Move the laptop closer to the modem/router.
- Ensure the Wi-Fi password is entered correctly.
- If the laptop connects to Wi-Fi but the connection is slow or weak, disconnect and reconnect to the network.

## The Laptop Screen Becomes Dark When the Power Adaptor is Unplugged

This will be occurring due to your power plan settings. Go to the Control Panel and change your power plan settings to allow the screen to remain on when the laptop is not charging/unplugged.

## Forgotten Password

If you forget your Microsoft account password, you can reset it using one of the following methods:

- Use a password reset disc via USB.
- Reset your Microsoft account password online using another device.
- Reset Windows 11 to factory default settings.

### **Note:**

Resetting to factory defaults will erase all personal data stored on the laptop. Ensure you back up any important files beforehand.

## Notes

[illegible]

### **Need more information?**

We hope that this user guide has given you the assistance needed for a simple set-up.

For the most up-to-date guide for your product, as well as any additional assistance you may require, head online to [help.Kogan.com](http://help.Kogan.com).

