

H03

All-in-One Sleep-Wake Solution
Sunrise Alarm Clock & Sleep Sounds Machine18-month Warranty
After-sales mailbox:


support@odokeeshop.com

Please read these instructions carefully before use
and retain for future reference.

Version 1.0

Odokee

FRONT VIEW




TOP VIEW



1. Press to turn on/pause Bluetooth
2. Hold 2 seconds to turn off Bluetooth when it's connected
3. For streaming music from phone
1. Repeatedly press to set the auto-off timer for sleep sound /nightlight/Bluetooth
2. Hold 2 seconds to turn off timer
1. Press to turn on/off sleep sound
2. Press to decrease sleep sound/Bluetooth volume
3. Press to increase sleep sound/Bluetooth volume
1. Press to start the 9 minutes snooze
2. Press to turn on and change the color of the nightlight
3. Hold 2 seconds to turn off the nightlight
1. Backward
2. Forward
1. Press to turn on/off alarm
2. Press to set the alarm time
1. Press to set the time/switch the regular time and military time

BACK VIEW



1. Scroll to adjust the nightlight brightness
1. Slide to set the alarm sound/alarm volume/sunrise brightness /sunrise duration
1. Slide to select the alarm mode
1. Scroll to adjust the display brightness
1. Power connector
1. Battery compartment

GETTING STARTED

1. Plug the adapter into a standard household outlet, you will see 12:00 AM on the display and the clock is ready to be set.



2. Insert 2 "AAA" batteries(Not Included) on the bottom of the clock to preserve the TIME/ALARM/SUNRISE/SLEEP SOUND/NIGHT LIGHT settings in case of power interruption. Follow the polarity(+/-) diagram in the battery compartment.



NOTICE:

1. If the display is "blank" after plugging in, please check whether the DISPLAY DIMMER on the left is at the HIGH Position.
2. Under the battery power, the display will go blank and preset alarm will not go off.

BLUETOOTH CONNECTION SETTING


1. Press "BT" button to turn on/off Bluetooth. When Bluetooth is ON, the "BT" icon will flash on the display.
2. Turn on Bluetooth on your phone and connect with the device "H03". The "BT" icon will stop flashing on the display upon connecting successfully. Press and hold the "BT" for 2 seconds to turn off Bluetooth when it is connected.
3. When music is playing, press "BT" or "BT" to change the music. Press "BT" to pause the music and press again to play.
4. Press "L" or "R" to adjust volume with range of 01-32 level.(The default volume is 16 level)

NOTICE:

1. The Bluetooth will automatically turn off if fails to connect to the phone within 5 minutes.
2. If a call comes in, the Bluetooth will stop playing the music.
3. Place your clock and phone no more than 10 meters(33ft) away from each other.

TIME SETTING

The time setting steps are as follows:



- Step 1: Press "H" first time to enter HOUR setting, the HOUR digits will flash on the display.
- Step 2: Press "L" or "R" to advance to the correct hour (hold for rapid setting).
- Step 3: Press "H" second time to confirm and enter MINUTE setting, the MINUTE digits will flash on the display.
- Step 4: Press "L" or "R" to advance to the correct minute (hold for rapid setting).
- Step 5: Press "H" third time to confirm and enter TIME FORMAT (12/24HR) setting. "12H" will flash, it means 12 hour mode(regular time), the default is 12 hour time format.
- Step 6: Press "L" or "R" to select time format. "24H" will flash, it means 24 hour mode(military time).
- Step 7: Press "H" fourth time to confirm and exit the time setting mode.

NOTICE:

1. The clock will exit automatically from the time setting mode if no action is taken within 8 seconds.
2. When using the 12-hour time format, the AM icon will be appeared for 12:00 midnight through 11:59am, and the PM icon will be appeared for 12:00 noon through 11:59pm.
3. In regular time, AM or PM will display. Otherwise clock is in Military Time.

BRIGHTNESS CONTROL

There are 0-100% brightness levels for LED Display. Slide the DISPLAY DIMMER knob on the left side of the clock to adjust the display brightness (HIGH: 100%, LOW: 0%).


TURNING ALARM ON/OFF

In non-setting mode, each push of "A" button can turn on or disable the alarm.



ALARM TIME SETTING

The alarm time setting steps are as follows:



- Step 1: Press "H" first time to enter ALARM HOUR setting, the HOUR digits will flash on the display.
- Step 2: Press "L" or "R" to advance to the correct hour (hold for rapid setting).
- Step 3: Press "H" second time to confirm and enter ALARM MINUTE setting, the MINUTE digits will flash on the display.
- Step 4: Press "L" or "R" to advance to the correct minute (hold for rapid setting).
- Step 5: Press "H" third time to confirm and exit the alarm setting mode.

ALARM SOUND & ALARM VOLUME SETTING

1. Slide "L" on the right side of the clock to ALARM SOUND position to enter alarm sound setting. The alarm sound options will flash and the alarm sound will ring. Press "L" or "R" to choose one of seven built-in alarm sounds (01-Birds Chirping; 02-Piano; 03-Flute; 04-Forest; 05-Wave; 06-Beep; 07-Buzzer)



2. Slide "L" to ALARM VOLUME position to enter alarm volume setting. The alarm volume options will flash. Press "L" or "R" to adjust alarm volume with 01-32 level. The default alarm volume is 16 level.



SUNRISE BRIGHTNESS & SUNRISE DURATION SETTING

1. Slide "L" to SUNRISE BRIGHTNESS position to enter sunrise brightness setting. The sunrise brightness options will flash. Press "L" or "R" to adjust sunrise brightness with 01-30 level. The default sunrise brightness is 15 level.



2. Slide "L" on the right side of the clock to SUNRISE DURATION position to enter sunrise duration setting. The sunrise duration options will flash. Press "L" or "R" to adjust sunrise duration with 05-60 minutes.




3. Slide "L" to LOCK position to confirm and exit setting mode, display will stop flashing.

NOTICE:

The sunrise light will light up gradually before the alarm time arrives (the default setting is 30 minutes). When the set alarm time arrives, the sunrise light will be on the preset brightness level.

EXAMPLE:



ALARM MODE SETTING

To select the alarm mode, slide "L" on the left side of the clock to your desired position:

1. Slide to "LIGHT" position means wake up light ONLY.
2. Slide to "SOUND" position means wake up sound ONLY.
3. Slide to "SOUND+LIGHT" position means both.

NOTICE:

The default alarm mode is "SOUND+LIGHT" wake up mode.

SNOOZE/TURN OFF ALARM DAILY

1. When the alarm goes off, press "SNOOZE" button to snooze for a while, the alarm will go off again 9 minutes later.
2. To cancel the snooze at any time or to TURN OFF this day alarm while it is sounding, press "A". The alarm will go off again at the same time the next day.
3. If not stop the alarm, it will last 30 mins before going silent.

NOTICE:

1. In the "LIGHT" alarm mode, when you start to snooze, the sunrise light will turn off and light up to your preset brightness level after 9 minutes.
2. In the "SOUND+LIGHT" alarm mode, when you start to snooze, the sunrise light does not turn off until you turn off the alarm for this day.

SLEEP SOUND SETTING

1. Press "S" to turn on/off sleep sound.
2. When the sleep sound is on, press "L" or "R" to choose the sleep sounds (01-25).
3. Press "L" or "R" to adjust the volume(01-32 levels adjustable).

Track List			
S01	Lullaby 1	S14	Yoga
S02	Birds Chirping	S15	Meditation
S03	Ocean Wave	S16	White Noise 1
S04	Shush	S17	White Noise 2
S05	Heartbeat	S18	Space White Noise
S06	Rain	S19	Pink Noise
S07	Thunderstorm	S20	Brown Noise
S08	Brook	S21	Blue Noise
S09	Cricket Chirping	S22	Fan 1
S10	Train	S23	Fan 2
S11	Forest	S24	Fan 3
S12	Wind	S25	Fan 4
S13	Lullaby 2		

NIGHT LIGHT SETTING

1. In normal time display mode, press "SNOOZE" to turn on the night light.
2. Press "SNOOZE" repeatedly to choose among 12 different night color options. 12 colors change as shown in the following sequence: sunrise, red, orange, yellow, green, indigo, blue, purple, sunset, loop color, RGB 1, RGB 2.
3. Slide the NIGHTLIGHT DIMMER on the right of the clock to adjust night light brightness. (HIGH: 100%, LOW: 10%)
4. Press and hold "SNOOZE" for 2 seconds (release it) to turn it off.

NOTICE:

The night light will default to the last color you choose when you reopen it.

SLEEP TIMER SETTING

Sleep timer lets you fall asleep with sleep sound/Bluetooth/nightlight for the set sleep duration then turns the sleep sound/Bluetooth/nightlight off.

1. When sleep sound/Bluetooth/nightlight is on, press "S" repeatedly to select range of 30, 60, 90, 120, 180, 240 minutes. The sleep timer will be seen on the display.
2. When the sleep timer is set, please wait for 5 seconds to exit from the setup. The sleep timer indicator will be seen on the display.
3. To turn off the sleep timer, press "S" repeatedly to select "OFF" and wait for 5 seconds to exit.
4. When sleep timer is on, press "S" to see the sleep timer remained.



NOTICE:

1. When sleep timer is on, press and hold "S" 2s to turn it off. The sleep timer will default to the last selected you choose when you reopen it.
2. When the nightlight and the sleep sound/Bluetooth are both on, the sleep timer can only be set for both.

SPECIFICATIONS

Power Input: DC 5V/2.0A Power: AC, 100-240V (50/60Hz)
Speaker Output: 5 Watt RMS

TROUBLESHOOTING

1. How Do I Fix Bluetooth Connection Issues?

- Confirm it's not paired with other devices.
- Forget all Bluetooth pairing records on your device.
- Unplug and remove the battery to reset, set again after power cycle.
- Disable and enable Bluetooth on your device.
- Try to connect the speaker to another device.
- Get customer support for help.

2. Alarm doesn't go off at the set time?

- Check if the alarm is set to AM or PM time;
- Check if the alarm is turn on (alarm icon display on the screen)
- Check if the alarm mode is set to SOUND or SOUND+LIGHT mode.
- Get customer support for help.

3. Display doesn't light up?

- Check if the power connection is loosed or not;
- Change another working outlet to try again;
- Slide the DISPLAY DIMMER knob to HIGH position in case the display is too dark to see.
- Get customer support for help.

4. Display doesn't stop flash?

- Check if the "L" on the right side of the clock is slide to the LOCK position.
- Get customer support for help.

5. How to turn off alarm daily?

- When the alarm goes off, pressing the "A" will turn the alarm off until the next scheduled time.
- Get customer support for help.

6. How to turn off the alarm completely?

- In the normal time display, you can turn the alarm off completely by single pressing the "A". The alarm icon will be disappear when the alarm is disabled.
- Get customer support for help.

WARRANTY & SUPPORT

- We offer a 45 day money-back guarantee and 18-month free replacement.
- Odokee customer support is committed to providing you with best-in-class service. For assistance, please keep the model number and order ID number of this product, then contact us by sending email, email address as below:
support@odokeeshop.com

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.