

TAP TO CONTROL, FRIENDLY USE AMID SLEEPING

WEIGHING 3.6G OF A SINGLE EARBUD, LIGHT FITTING

Product Manual

REMAX 睿量

V5.3

True Wireless *Music Earbuds*

SLEEPBUDS Z2





Dreamer Series True Wireless Music Earbuds

SKIN-FRIENDLY ANTIBACTERIAL SILICONE EARCAPS AND EARRHOOKS

Parameter

Product Model	SleepBuds Z2	Earbud Battery Capacity	30mAh
Wireless Version	V5.3	Charging Times of Charging Case	3 Time
Transmission Distance	≈ 10M	Input	5V==300mA
Driver Unit	Φ6mm	Play Time	≈ 5H
Frequency Response	20HZ~20KHZ	Standby Time	≈ 130H
Impedance	16Ω±15%	Charging Time	≈ 1.5H
Rated Power	3mW	Net Weight	39g
Charging Case Battery Capacity	230mAh	Charging Case Size	63*45.3*28.5mm



Operations

Turn on/off the earbud

(1) Power on

Method 1: Take out the two earbuds from the charging case, and the earbuds will be on automatically.

Method 2: When the earbuds are turned off, long press the touch key of L and R earbud for 2s to turn on the earbuds.

(Indicator: the white indicator on the earbud is on for 2s; Tone: "Power on")

Note: After turning on, the earbud will automatically turn off if no using or no devices connected within 5min.

(2) Power off

Method 1: Put the earbuds back into the charging case, the earbuds get charged, and the earbuds automatically turns off after fully charged.

Method 2: When the earbuds are on, press and hold the touch key of the L and R earbud for 5s, and the two earbuds will turn off. (Indicator: The white indicator on the earbud is on for 2s and then goes off; Tone: "Power off")

Wireless pairing

(1) First pairing

Step 1: After turning on, the L and R earbud will connect with each other automatically and then enter pairing mode to connect with a mobile phone.

(Indicator: one earbud flashes white light rapidly, and the other earbud flashes white light every 5s; Tone: "Pairing")

Step 2: Open the wireless list on the phone, search for "SleepBuds Z2" and connect.

(Tone for successful connection: "connected")

(2) Subsequent Connection

When using it again, take out the two earbuds from the charging case and the earbuds will automatically turn on and connect back to the previous connected phone.

Note: 1. If the connection fails, the earbud will enter pairing mode. At this time, clear the previous pairing record with the earbud on the mobile phone, and then re-select "SleepBuds Z2" in the wireless search list and pair. It will ensure successful connection.

2. When the distance between the earbud and the paired phone is too far, the earbud will disconnect from the phone. If entering effective range within 2min, the earbud will connect back to the phone.

3. When the earbud is disconnected from the phone due to far distance, it will turn off if no device connected within 5min.

(3) Switch to another new device

When the earbud is connected to Device 1, and you want to connect it with Device 2, just press and hold the touch key of the L/R earbud for 3s and release it until you hear the "beep-beep" sound. The earbud will automatically disconnect from Device 1 and enter pairing mode. At this time, select "SleepBuds Z2" in the wireless search list of Device 2 and pair with it.

Touch key operation

(1) Incoming call control

Answer/Hang up: Tap the touch key of the L/R earbud; Reject: Press and hold the touch key of L/R earbud for 1.5s;

(2) Music control

Play/Pause: Tap the touch key of the L/R earbud; Previous track: Tap the touch key of the L earbud twice;

Next track: Tap the touch key of the R earbud twice; Volume-: Tap the touch key of the L earbud 3 times;

Volume+: Tap the touch key of the R earbud 3 times;

(3) Voice assistant

When connected, during standby or music playing, press and hold the touch key of L/R earbud for 1.5s and release until you hear a "beep" sound;

(4) Game (low latency) mode

When the earbud is connected: On: Quickly tap the touch key of the L/R earbud 4 times. (Tone "Game mode on")

Off: Quickly tap the touch key of the L/R earbud 4 times. (Tone "Game mode off")

(5) Language Switch

When the earbud is pairing and not connected to a device:

Tap the touch key of the L/R earbud, you will hear the tone "Chinese mode", which means it has successfully switched to Chinese tone;
Tap the touch key of the L/R earbud once again, you will hear the tone "English mode", which means it has successfully switched to English tone.

Warnings

Please keep the product in a dry place away from fire and heat sources, and avoid contact with corrosive substances. Please charge the product once every 3 months.

Working Temperature: -10°C~45°C Storage Temperature: -20°C~55°C

Working Humidity: 5%-95% Storage Humidity: 5%-95%

Test Temperature: 25°C± 10°C Atmospheric Pressure: 70-106Mpa

1. Do not use any abrasive detergent to clean this product.
2. Do not heat this product or keep it close to a fire source, such as a cooking stove.
3. Do not expose this product to direct sunlight for a long time.
4. Do not dispose of this product in the fire to avoid explosion.
5. Do not try to disassemble this product to make any modifications, as it does not contain any maintenance components.
6. Do not use this product in the rain.
7. If the product is not for use for a long period of time, please store it in a dry environment, and charge it at least once a month to extend its life and avoid extreme temperatures and dust.

*Cautions

1. Do not use this product under high temperature or environment of high humidity, high cold, high dust, high electromagnetic radiation and lightning conditions;
2. Do not use non-original charging accessories to charge;
3. Charging time does not exceed 1.5 hours;
4. Recharge every 60 days when not in use for a long time;
5. Do not exceed 60 decibels when used for a long time to avoid hearing damage;
6. Do not disassemble at will, otherwise no warranty;
7. After the product has expired, it can be sent to a professional recycling agency. Do not drop it at will, so as not to pollute the environment.

Packing list



Charging case *1




Ear Caps * 1 pair



User manual *1



User manual *1



USB charging cable *1

General Safety Information

- ① Do not attempt to disassemble the earbud to avoid damaging your earbud or causing battery spontaneous combustion. Ask authorized maintenance service for help.
- ② If you use the earbud while driving, follow your local regulations.
- ③ Do not place this wireless earbud in high temperatures (above 50° C /122° F), for example, exposure to the sun,to avoid damaging its wireless performance or reducing its battery life.
- ④ Do not leave the earbud in moisture or soak it in liquids.
- ⑤ Using the earbud at high volume for a long time may damage your hearing.

Troubleshooting

Problems	Causes	Solutions
Cannot Power on	Dead battery	Charge the earbud
Cannot charge	The charger plug was not connected firmly or correctly	Replug the charger
Cannot Power off	Incorrect operation led to an error in the earbud program	Use the charger to charge and reset
Cannot be searched or paired	The earbud did not enter the pairing state	Let the earbud go into pairing mode
	Certain phone's wireless application program went wrong	Power off and pair one more time the earbud

Warranty

This product is covered under warranty for a period of one year from the date of sale limited to normal use and maintenance of the machine parts, materials and functions. Problems and failures verified upon further identification will be provided with free repair and replacement parts.

This warranty does not apply:

- (A) to a product that is out of warranty;
- (B) to damage caused by operating the product outside the permitted or intended uses described by Remax;
- (C) to a product that has been disassembled, repaired or modified with out the authorization of Remax;
- (D) if warranty card and proof of purchase cannot be presented;
- (E) to damage caused by earthquake, fire or other external causes, natural disasters, etc.

Note: The warranty does not include product transport costs and does not provide on-site maintenance services.



Remax reserves all rights to clarify this warranty interpretation.

Warranty Feedback Form(Tick Off)

- A. No sound
- B. Sound quality deteriorates
- C. Button mal-function
- D. Unable to pair other devices
- E. Can not be recharged
- F. Others

Buying time

Dealers of sale

Time of problems

User's contact info
