

DIGITAL ALARM CLOCK DOOMAY Model: 5293 doomay-vip@hotmail.com	CONTENTS English 1 ~ 9 Deutsch 10 ~ 19 Italiano 20 ~ 28 Français 29 ~ 37 Español 38 ~ 46	Digital Alarm Clock User Manual 1 2 3 4 5 1 2 3 4 5 6 7 8 1. Time 2. Low Battery icon 3. AM/PM 4. Weekend Mode 5. Alarm Time 6. Date 7. Week 8. Temperature 9 10 11 12 13 9 10 11 12 13 9. Time Set 12/24H Format 10. Alarm Set 11. Date Set 12. Down, Up, °C/°F	14 SNOOZE / LIGHT 14. Snooze/Light Before Use Thanks a lot for choosing our Digital Alarm Clock. Please take the time to read and understand this manual, so you can begin to enjoy the convenience and features from this product. Power On Open the battery cover at the rear of the clock, insert 2 pieces AAA batteries to start the product, a prompt tone "Di" indicate the clock start to work.	Time Setting 1 In the time mode, press the [●] button and hold until the Hour Number begins to flash, release the button and only press the [+] or [-] button to adjust the Hour. Press the [●] button again until the Minute Number begins to flash, release the button and only press the [+] or [-] button to adjust the Minute. Press the [●] button for quick adjustment. Press the [●] button to save the time setting. 2 During time display, press the [●] button to change the time format of 12/24 Hours. Note: If you select 12H format mode, the screen will display "AM". In the morning, display "PM" in the afternoon.	Date Setting 1 In the time mode, press the [■] button and hold until the Year Number begins to flash, release the button and only press the [+] or [-] button to adjust the Year. Press the [■] button again until the Month Number begins to flash, release the button and only press the [+] or [-] button to adjust the Month. Press the [■] button again until the Day Number begins to flash, release the button and only press the [+] or [-] button to adjust the Day. Press the [■] button to save the date setting. The Day of Week would change accordingly after the Year/Month/Day set. 2 During time display, press the [■] button to change the time format of 12/24 Hours. Note: If you select 12H format mode, the screen will display "AM". In the morning, display "PM" in the afternoon.	Alarm Setting 1 Alarm Setting In the time mode, press the [▲] button and hold until the Hour of Alarm begins to flash, release the button and only press the [+] or [-] button to adjust the Hour. Press the [▲] button again until the Minute of Alarm begins to flash, release the button and only press the [+] or [-] button to adjust the Minute. Press the [▲] button for quick adjustment. 2 Press the [▲] button to save the alarm time setting and enter alarm volume setting, press the [▲] or [-] button to select "L01" (High Volume) or "L02" (Low Volume), the corresponding volume icon flash with the corresponding prompt tone "DIDI".	Alarm Volume Level press 12:00 12:00 press 12:00 12:00 press 12:00 12:00
--	---	---	--	--	---	---	---

press

12:00

12:00

press

12:00

12:00