

# Tips Before use the bed

- When using the bed for the first time, please leave the bed for **2 hours** after inflation to let the material stretch out and then **top up** the air.
- After inflation, make sure the pump is off and the manual valve is fully closed.
- After long-term use, you may find that the material becomes more stretched and you may need to inflate the bed for additional time before using it.
- All inflatable beds have some natural leakage. Top up the air **once per week** to keep the same level of firmness.

## First inflation

