

I Loshall Card Operating Instructions on Apple Find My App

To use the Apple Find My app to locate this item, the latest version iOS, iPadOS, or macOS is recommended.


How to set up Loshall Card in the Apple Find My app:

First make sure WiFi and Bluetooth are turned on




Make the Loshall Card discovered following the steps :


Click the power button,after the ringtone rings and the Controlling light blinks in white, the Loshall card is ready.



Turn on the Apple Find My app




Click "Add Item" , then click "Add Other Supported Item" then follow the instructions shown.




If you have added other items, you need to click on the "+" sign at the top right and enter it by clicking on "Add Other Items".

How to remove items from the Apple Find My app:




Navigate to the item page on the Apple Find My app, Click "Items" , then Swipe left on the item you want to remove.

After removing it on the Apple Find My app, the Card will automatically shut down after 3 minutes. Subsequent relink can be done by following the steps above.



Unable to be linked

II Charge your card



Ensure that the charging position is aligned with the wireless charger



Always turn on orange light while charging
Always turn on green light when fully charged

Safe electrical disposal

The earth is our common home and LOSHALL attaches great importance to protecting the cleanliness of the environment and avoiding its pollution. When your device reaches the end of their useful life, please dispose of at your locale-waste center to be recycled and properly discarded,

How to restoring the factory setting.

Click the power button four times, and then press the power button for some seconds long; When the ringtone sounds, the light flashes in white quickly.That is completed.

III Warning

1. This product is not a toy or edible.
2. Obstacles or large metal objects can interfere with the Bluetooth signal.
3. This product has a built-in lithium battery. Please do not put this product directly on fire or any place near heat or fire, otherwise, the product may be damaged or malfunctioned, or even be dangerous.

IV Disclaimer

This is neither an anti-theft nor an anti-lost device.
This device provides the last detected location.

V Limited warranty

Loshall offers a one-year limited warranty against product defects, effective from the time of delivery.

Product defects do not include those resulting from accidents, product modification,or failure to follow instructions for use.


Manual

Type B

The Apple® Find My® network provides an easy, secure way to locate compatible personal items using the Find My app on your iPhone®, iPad®, Mac®, or the Find Items app on Apple Watch®.

To use the Apple Find My app to locate this item, the latest version of iOS®, iPadOS®, or macOS® is recommended. The Find Items app on Apple Watch requires the latest version of watchOS®.

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.



Remove your Item Locator

- Ensure “**Lost Mode**” is disabled, tap “**Remove Item**” tab, a summary will open, tap “**Remove**” to confirm.

Reset your Item Locator

- After successfully removing the Item Locator from the APP, press the Item Locator’s function button four times rapidly, and then hold it a fifth time until you hear a ringing chime, the Item Locator is now reset and ready to pair to a new device.

Getting Started

1. Check For Updates

To use the Apple Find My app to locate your Item Locator, the latest version of iOS, iPad OS, or macOS is recommended.

2.Power On

Press your locator’s function button once to turn on, it should beep once indicating it is powered on.




3.Add Your Item Locator

3.1 Start the APP

Open Find My APP on your supported iPhone or iPad.

3.2 Connect your Item Locator

Step1. Select the “**Items**” tab then Tap the “**Add Item**” tab. +symbol (Figure 1)



Step2. Tap “**Other Supported Items**”.




Step3. Make sure your Item Locator is close to your phone. Wait... until you see “**SualioTag**”, then tap “**Connect**”. Follow the pop-up to fill name and select an emoji; then tap “**Continue**”. There will be a request to add your Item Locator to your ID, then tap “**Continue**”. Tap “**Finish**” and your Item Locator will be set up.



5.Function Introduction


Locate your Item

- Find Item Locator
- Tap “**Play Sound**” to make your Item Locator beep when it is nearby.
- Find your Item Locator’s location
- Your Item Locator’s last known location will appear on the map as emoji you choose during set up, tap “**Directions**” to navigate to the last known location.



Find Item When Out of Range

- Enable the “**Notify When Left Behind**” toggle, you will receive a notification when you leave your Item Locator behind and it is no longer in range of your device.
- Enable the “**Notify when Found**” toggle, when your Item location is seen by another Find My enabled device, you will receive a notification of its updated location.
- **Note: “Notify When Found”** can only be activated when your Item Locator is out of range.



When Your Item is Lost

- When Your Item is Lost Under “**Lost Mode**”, tap the “**Enable**” tab, a screen detailing Lost Mode will pop up, tab “**Continue**”. You can enter your phone number or email address and tap “**Next**”. You may enter a message that will be shared with the person that finds your item. Tap “**Activate**” to enable “**Lost Mode**”
- **Note:** When “**Lost Mode**” is enabled, “**Notification When Found**” is automatically enabled.
- **Note:** When “**Lost Mode**” is enabled, your Item Locator is locked and cannot be paired to a new device.

How to replace the Battery:

- Use your fingernails at the small gap on the side of your Item Locator to carefully open the case.
- Replace the battery with a new CR2032 battery 3V. (Positive pole upward).
- Carefully close the Item Locator.




Unwanted Tracking Detection:

If your iPhone detects that an unknown Item Locator is traveling with you, it will send you a notification. A sound will start playing so you will be able to find it. These alerts are only activated when an Item Locator is not connected to its owner’s phone, so your partner’s Item Locator will not trigger a sound if they are with you.

Button function

1.Power on (Findmy function is on). Press the function button once to turn it on. it should a ringing chime indicating it is powered on.



If the product is not paired, it will be closed within 10 minutes. You need to trigger the findmy function again to continue pairing. Hold the function button for three seconds, then release it.. you will hear two beeps indicating it is powered off. Press the function button two times rapidly and you will hear a confirmation sound, This operation will be displayed on the findmy app to guide the person who gets the device to obtain the device information, such as the owner’s contact information (if the item is set to the lost mode on the app), and the serial number of the device. 4.Restore factory settings (reset the device locally and restore it to pairing status) Press the function button four times rapidly and then hold it a fifth time until you hear a ringing chime. A reset operation is required to enable the device to enter the pairing state again (synchronization of Findmy also requires simultaneous unbinding) and rebind the new Apple Id account.



Important tips:

- 1.When pairing a device with Find My app, the phone will link to the Apple server. Pairing may fail because of network problems. The following action is recommended: 1. Change the phone’s network, such as switching between WiFi and mobile. The first pairing may takes a long time, please wait patiently. 2. Reset your item. 3.Repair with Findmy APP.
- 2.When “Lost Mode” is enable, DO NOT REMOVE ITEM in the APP. Your Item Locator will be locked and cannot be paired to a new device.
- 3.The battery usage time varies depending on personal usage habits. Frequent use of the call function can accelerate battery consumption.

WARNING

1. Remove and Immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.
- 2.Even used batteries may cause severe injury or death.
- 3.Call a local poison control center for treatment information.
4. Non-rechargeable batteries are not to be recharged.
5. Do not force discharge, recharge, disassemble, heat above 50°C/122°F or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.
6. The compatible battery type is CR2032.

7. The nominal battery voltage: DC 3V
8. Ensure the batteries are installed correctly according to polarity(+ and -).
9. Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.
10. Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.
11. Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.



Battery type: CR2032. Battery voltage: 3V. Keep in original package until ready to use; Immediately dispose of used batteries and keep away from children. Do NOT dispose of batteries in household trash.



Remarks

- New function: Share items. The people you’ve shared it with will be able to locate it, and they won’t receive unidentified-tracking notifications. To use Share Items, make sure you and your friends have installed the iOS 17, iPadOS 17, or macOS 14 Sonoma public betas or newer.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
 - (2) this device must accept any interference received, including interference that may cause undesired operation.
- Any changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.
- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. The device has been evaluated to meet general RF exposure requirement.
- The device can be used in portable exposure condition without restriction.

