

di-GPS® Eco ProSumer **digital images GPS receiver**

Users Guide

Ver 1.0

Please visit our website www.di-gps.com for the latest version of the user guide



CONTENTS

CONTENTS	1
INTRODUCTION	2
WARNING / PRECAUTION FOR USE.....	3
WARNING / PRECAUTION FOR USE.....	4
PART NAMES OF ECO PRO-S GPS	5
CONNECTING ECO PRO-S GPS TO CAMERA	6
RECORDING GPS DATA (1)	7
RECORDING GPS DATA (2)	8
POWER MODE SWITCH (1)	9
POWER MODE SWITCH (2)	10
GPS STATUS LED INDICATOR FOR ECO PRO-S GPS FIX (1)	11
GPS STATUS LED INDICATOR FOR ECO PRO-S GPS FIX (2)	12
LAST POSITION RETENTION (“LPR”)	13
SPECIFICATIONS	14
WARRANTY	15

DI-GPS® IS A REGISTERED TRADEMARK OR A TRADEMARK OF DAWN TECHNOLOGY LIMITED.
NIKON D2HS, D2X, D2XS, D200, D3, D3S, D3X, D300, D300S, D600, D700, D800, D90, D3100, D3200, D5000,
D5100, D7000, D7100 AND P7700 ARE REGISTERED TRADEMARK OR A TRADEMARK OF NIKON
CORPORATION IN THE UNITED STATES AND/OR OTHER COUNTRIES.
FUJIFILM AND S5 PRO ARE REGISTERED TRADEMARK OR A TRADEMARK OF FUJIFILM U.S.A., INC. IN THE
UNITED STATES AND/OR OTHER COUNTRIES.

V1.0

INTRODUCTION

Thank you for purchasing **di-GPS®** Eco ProSumer series GPS receiver (digital images GPS).

di-GPS® Eco ProSumer series GPS receiver (thereafter “Eco Pro-S GPS”) is specially designed for a DSLR (Digital Single-lens Reflex) camera. It provides real time position (latitude, longitude, elevation) and the precise time (UTC time) information to your DSLR camera. It records the locations to each digital image file so that you will never forget the exact location where you took the pictures.

Eco Pro-S GPS has built with the latest third generation MTK MT3339 ultra low power consumption GPS engine. It supports up to 66 channels of satellite tracking with -165dBm sensitivity. Eco Pro-S GPS repeats the last fixed position⁽¹⁾ when no GPS signal is available or the unit is out of GPS coverage with real UTC date/time.

Eco Pro-S GPS allows you to save your present location data to your digital image file. Its State-Of-The-Art technology provides extremely fast TTFF (Time-To-First-Fix), unrivaled high sensitivity and superior performance in virtually any outdoor environment. Eco Pro-S GPS receiver can work in a place where GPS was not possible before: in the woods, under very heavy foliage, canyons, terrain obstructions, in cities with densely populated high-rise buildings and even inside a train or a car, with no external antenna required. It is designed to meet the rigorous demands of today's digital photographers.

Note (1) : Not applicable to Nikon Coolpix P7700

DI-GPS® IS A REGISTERED TRADEMARK OR A TRADEMARK OF DAWN TECHNOLOGY LIMITED.
NIKON D2HS, D2X, D2XS, D200, D3, D3S, D3X, D300, D300S, D600, D700, D800, D90, D3100, D3200, D5000, D5100, D7000, D7100 AND P7700 ARE REGISTERED TRADEMARK OR A TRADEMARK OF NIKON CORPORATION IN THE UNITED STATES AND/OR OTHER COUNTRIES.
FUJIFILM AND S5 PRO ARE REGISTERED TRADEMARK OR A TRADEMARK OF FUJIFILM U.S.A., INC. IN THE UNITED STATES AND/OR OTHER COUNTRIES.

V1.0

WARNING / PRECAUTION FOR USE (I)

- Keep out of reach of children. This device contains small parts that may pose a choking hazard. Consult a physician immediately if a child swallows any part of this device.
- Under no circumstances should you attempt to disassemble the product and repair it yourself. Doing so may result in electric shock or product malfunction. Should the product break open as the result of a fall or other accident, send the unit to Dawn Technology Limited for inspection. For more information, please visit our web site at www.di-gps.com.
- Do not handle with wet hands or immerse in or expose to water or rain. Failure to observe this precaution could result in fire or electric shock.
- Do not use in the presence of flammable gas. Failure to observe this precaution could result in explosion or fire.
- Do not expose to flame or excessive heat.
- Do not expose to high temperatures.
- Do not leave the device in a closed vehicle under the sun or in other areas subject to extremely high temperatures. Failure to observe this precaution could result in fire or in damage to the casing or internal parts.
- Turn off immediately in the event of malfunction. Should you notice smoke or an unusual smell coming from this device, remove the 10 pins connector immediately and send the unit to Dawn Technology Limited for inspection. For more information, please visit our web site at www.di-gps.com.

DI-GPS® IS A REGISTERED TRADEMARK OR A TRADEMARK OF DAWN TECHNOLOGY LIMITED.
NIKON D2HS, D2X, D2XS, D200, D3, D3S, D3X, D300, D300S, D600, D700, D800, D90, D3100, D3200, D5000, D5100, D7000, D7100 AND P7700 ARE REGISTERED TRADEMARK OR A TRADEMARK OF NIKON CORPORATION IN THE UNITED STATES AND/OR OTHER COUNTRIES.
FUJIFILM AND S5 PRO ARE REGISTERED TRADEMARK OR A TRADEMARK OF FUJIFILM U.S.A., INC. IN THE UNITED STATES AND/OR OTHER COUNTRIES.

V1.0

WARNING / PRECAUTION FOR USE (II)

Important WARNING

Do not put the camera to the bag with the GPS at the bottom (as shown in the picture below). Failure to do so may cause permanent damage to the GPS unit and/or the camera's terminal.



DI-GPS® IS A REGISTERED TRADEMARK OR A TRADEMARK OF DAWN TECHNOLOGY LIMITED.
NIKON D2HS, D2X, D2XS, D200, D3, D3S, D3X, D300, D300S, D600, D700, D800, D90, D3100, D3200, D5000, D5100, D7000, D7100 AND P7700 ARE REGISTERED TRADEMARK OR A TRADEMARK OF NIKON CORPORATION IN THE UNITED STATES AND/OR OTHER COUNTRIES.
FUJIFILM AND S5 PRO ARE REGISTERED TRADEMARK OR A TRADEMARK OF FUJIFILM U.S.A., INC. IN THE UNITED STATES AND/OR OTHER COUNTRIES.

V1.0

PART NAMES OF ECO PRO-S GPS



A – Power Mode Switch

B – Status LED

C – Connector to DSLR camera

D – Shutter release socket (2.5mm)

DI-GPS® IS A REGISTERED TRADEMARK OR A TRADEMARK OF DAWN TECHNOLOGY LIMITED.
NIKON D2HS, D2X, D2XS, D200, D3, D3S, D3X, D300, D300S, D600, D700, D800, D90, D3100, D3200, D5000,
D5100, D7000, D7100 AND P7700 ARE REGISTERED TRADEMARK OR A TRADEMARK OF NIKON
CORPORATION IN THE UNITED STATES AND/OR OTHER COUNTRIES.
FUJIFILM AND S5 PRO ARE REGISTERED TRADEMARK OR A TRADEMARK OF FUJIFILM U.S.A., INC. IN THE
UNITED STATES AND/OR OTHER COUNTRIES.

V1.0

CONNECTING ECO PRO-S GPS TO CAMERA



Direct connect Eco Pro-S GPS to the accessory terminal of the DSLR camera body.



How the strip should be attached

A supplied remote control accessory can be connected to the 2.5mm remote terminal of Eco Pro-S GPS for remote shutter release.



NOTE

- Eco Pro-S GPS cannot be turned on when the camera is not connected.
- Please refer to user guide of your DSLR for more information on taking photographs with a GPS receiver.
- Be sure to turn off your camera before disconnecting Eco Pro-S GPS. Do not connect or disconnect Eco Pro-S GPS while the camera is on. Failure to observe this precaution could cause a malfunction of the camera.
- Do not carry the camera by Eco Pro-S GPS or subject the camera or the unit to physical shocks while the unit is connected. Failure to observe this precaution could result in physical damage of the unit or the camera's GPS terminals.
- Re-place the caps on the camera when the terminals are not in use.

DI-GPS® IS A REGISTERED TRADEMARK OR A TRADEMARK OF DAWN TECHNOLOGY LIMITED.

NIKON D2HS, D2X, D2XS, D200, D3, D3S, D3X, D300, D300S, D600, D700, D800, D90, D3100, D3200, D5000, D5100, D7000, D7100 AND P7700 ARE REGISTERED TRADEMARK OR A TRADEMARK OF NIKON CORPORATION IN THE UNITED STATES AND/OR OTHER COUNTRIES.

FUJIFILM AND S5 PRO ARE REGISTERED TRADEMARK OR A TRADEMARK OF FUJIFILM U.S.A., INC. IN THE UNITED STATES AND/OR OTHER COUNTRIES.

V1.0

RECORDING GPS DATA (I)

Connect the DSLR camera and Eco Pro-S GPS as described below.

1. Turn off the camera.
2. Remove the cap from the accessory terminal on the camera body.
3. Attach the Eco Pro-S GPS directly to the accessory terminal on camera. Do not use any extension cord.
4. Switch the power mode to "On" or "Auto".
5. Turn the camera on.
6. If Eco Pro-S GPS is properly connected, the camera will display a blinking icon on the top control panel. It means Eco Pro-S GPS is searching for a signal. The icon will stop blinking once signal has been established and Eco Pro-S GPS is ready for supplying the current position.
7. Eco Pro-S GPS will automatically detect the connection of the camera. It cannot be turned on when the camera is not connected whatever the power mode switch is set to "On" or "Auto". Both "On" and "Auto" mode only function when the camera is properly connected.

DI-GPS® IS A REGISTERED TRADEMARK OR A TRADEMARK OF DAWN TECHNOLOGY LIMITED.
NIKON D2HS, D2X, D2XS, D200, D3, D3S, D3X, D300, D300S, D600, D700, D800, D90, D3100, D3200, D5000, D5100, D7000, D7100 AND P7700 ARE REGISTERED TRADEMARK OR A TRADEMARK OF NIKON CORPORATION IN THE UNITED STATES AND/OR OTHER COUNTRIES.
FUJIFILM AND S5 PRO ARE REGISTERED TRADEMARK OR A TRADEMARK OF FUJIFILM U.S.A., INC. IN THE UNITED STATES AND/OR OTHER COUNTRIES.

V1.0

RECORDING GPS DATA (II)

Each satellite broadcasts a digital message that contains two types of information. One type is ephemeris data, which includes the assigned serial number of the satellite, the status of the satellite (healthy or faulty), current date and time. The second type is almanac data which includes precise orbital position of every satellite in the system.

At the initial stage, ECO Pro-S GPS needs all these data for the position fixed. It usually takes a minute to few minutes to receive all data. An open sky outdoor environment will enable faster acquisition process. It will take a longer time at a weak signal environment. Once Eco Pro-S GPS locks to the satellites, it will take a few seconds for reacquisition even at weak signal environment.

The **EASY™** function is Embedded Assist System for quick positioning. Eco Pro-S GPS will calculate and predict automatically the single ephemeris (Max. up to 3 days) when power on, and save the predict information into the memory, Eco Pro-S GPS will use these information for positioning if no enough information from satellites, this function will be helpful for positioning weak signal environment.




Before the **EASY™** function works properly, Eco Pro-S GPS needs to collect enough information from satellites. The GPS usually needs 1-2 minutes to collect all information from satellites after the first fix. Please let the GPS turn on for 1-2 minutes after the first fix for the first time of use.

Eco Pro-S GPS has a memory backup capacitor inside. The capacitor can provide about two minutes power to the internal memory after disconnect from the camera of changing battery. To avoid the lost of ephemeris data in the internal memory, Eco Pro-S GPS should be connected to the camera all the time. The internal memory only consumes a very small amount of energy, it will not affect the battery life of the camera. As the ephemeris data only be good for 3 days maximum, Eco Pro-S GPS should be disconnected from the camera if the camera will not be used for a long period of time.

DI-GPS® IS A REGISTERED TRADEMARK OR A TRADEMARK OF DAWN TECHNOLOGY LIMITED.
NIKON D2HS, D2X, D2XS, D200, D3, D3S, D3X, D300, D300S, D600, D700, D800, D90, D3100, D3200, D5000, D5100, D7000, D7100 AND P7700 ARE REGISTERED TRADEMARK OR A TRADEMARK OF NIKON CORPORATION IN THE UNITED STATES AND/OR OTHER COUNTRIES.
FUJIFILM AND S5 PRO ARE REGISTERED TRADEMARK OR A TRADEMARK OF FUJIFILM U.S.A., INC. IN THE UNITED STATES AND/OR OTHER COUNTRIES.

POWER MODE SWITCH (I)

When Eco Pro-S GPS connects to **Nikon D600, D90, D3100, D3200, D5000, D5100, D5200, D7000 and D7100**:-




POWER MODE	DESCRIPTION
 ON	<ul style="list-style-type: none"> Eco Pro-S GPS is "on", no matter the camera is on or off. It sends current GPS location to the camera when locked to satellites. Last Position Retention ("LPR") function enabled.
 AUTO	<p>When metering system active:</p> <ul style="list-style-type: none"> Eco Pro-S GPS turns on automatically. It sends current GPS location to the camera when locked to satellites. <p>When metering system inactive:</p> <ul style="list-style-type: none"> Eco Pro-S GPS turns off automatically.
 OFF	<ul style="list-style-type: none"> Eco Pro-S GPS in off state.

DI-GPS® IS A REGISTERED TRADEMARK OR A TRADEMARK OF DAWN TECHNOLOGY LIMITED.
 NIKON D2HS, D2X, D2XS, D200, D3, D3S, D3X, D300, D300S, D600, D700, D800, D90, D3100, D3200, D5000, D5100, D7000, D7100 AND P7700 ARE REGISTERED TRADEMARK OR A TRADEMARK OF NIKON CORPORATION IN THE UNITED STATES AND/OR OTHER COUNTRIES.
 FUJIFILM AND S5 PRO ARE REGISTERED TRADEMARK OR A TRADEMARK OF FUJIFILM U.S.A., INC. IN THE UNITED STATES AND/OR OTHER COUNTRIES.

V1.0

POWER MODE SWITCH (II)

When Eco Pro-S GPS connects to **Nikon Coolpix P7700** :-







POWER MODE	DESCRIPTION
 ON	<p>When P7700 is ON:</p> <ul style="list-style-type: none"> Eco Pro-S GPS turns on automatically. It sends current GPS location to the camera when locked to satellites.
 AUTO	<p>When P7700 is OFF:</p> <ul style="list-style-type: none"> Eco Pro-S GPS turns off automatically.
 OFF	<ul style="list-style-type: none"> Eco Pro-S GPS in off state.

DI-GPS® IS A REGISTERED TRADEMARK OR A TRADEMARK OF DAWN TECHNOLOGY LIMITED.
 NIKON D2HS, D2X, D2XS, D200, D3, D3S, D3X, D300, D300S, D600, D700, D800, D90, D3100, D3200, D5000, D5100, D7000, D7100 AND P7700 ARE REGISTERED TRADEMARK OR A TRADEMARK OF NIKON CORPORATION IN THE UNITED STATES AND/OR OTHER COUNTRIES.
 FUJIFILM AND S5 PRO ARE REGISTERED TRADEMARK OR A TRADEMARK OF FUJIFILM U.S.A., INC. IN THE UNITED STATES AND/OR OTHER COUNTRIES.

V1.0

GPS STATUS LED INDICATOR FOR ECO PRO-S GPS FIX (I)

When Eco Pro-S GPS connects to **Nikon D600, D90, D3100, D3200, D5000, D5100, D5200, D7000 and D7100** :-

STATUS LED (on Eco Pro-S)	GPS ICON (on camera)	DESCRIPTION
 Flashing	 Flashing Icon	<ul style="list-style-type: none"> No fix, Signal searching No GPS data will be recorded in the photos.
 Flashing	 Icon Steady	<ul style="list-style-type: none"> No fix, Signal searching Eco Pro-S GPS continuously sends the last known position with current UTC date / time to the camera until new fix available. (only available in "ON" mode)
 Steady On	 Icon Steady	<ul style="list-style-type: none"> Fix available Eco Pro-S GPS continuously sends the current GPS position to the camera.

NOTE






- LED on Eco Pro-S GPS only represents the status of Eco Pro-S GPS, but not the reception of GPS data to the DSLR camera.
- GPS data are only recorded when **GPS** icon displayed on the top of LCD panel of DSLR camera. Please make sure that **GPS** icon is displayed before shooting.

DI-GPS® IS A REGISTERED TRADEMARK OR A TRADEMARK OF DAWN TECHNOLOGY LIMITED.
 NIKON D2HS, D2X, D2XS, D200, D3, D3S, D3X, D300, D300S, D600, D700, D800, D90, D3100, D3200, D5000, D5100, D7000, D7100 AND P7700 ARE REGISTERED TRADEMARK OR A TRADEMARK OF NIKON CORPORATION IN THE UNITED STATES AND/OR OTHER COUNTRIES.
 FUJIFILM AND S5 PRO ARE REGISTERED TRADEMARK OR A TRADEMARK OF FUJIFILM U.S.A., INC. IN THE UNITED STATES AND/OR OTHER COUNTRIES.







V1.0

GPS STATUS LED INDICATOR FOR ECO PRO-S GPS FIX (II)

When Eco Pro-S GPS connects to **Nikon Coolpix P7700** :-

STATUS LED (on Eco Pro-S)	GPS ICON (on camera)	DESCRIPTION
 Flashing	 Icon in Red colour	<ul style="list-style-type: none"> • No fix, Signal searching • No GPS data will be recorded in the photos.
 Steady On	 or  Icon in white colour	<ul style="list-style-type: none"> • Fix available • Eco Pro-S GPS continuously sends the current GPS position to the camera.

NOTE

- LED on Eco Pro-S GPS only represents the status of Eco Pro-S GPS, but not the reception of GPS data to the camera.
- GPS data are only recorded when ,  or  icon displayed on shooting screen of camera. Please make sure that ,  or  icon is displayed before shooting.

DI-GPS® IS A REGISTERED TRADEMARK OR A TRADEMARK OF DAWN TECHNOLOGY LIMITED.
 NIKON D2HS, D2X, D2XS, D200, D3, D3S, D3X, D300, D300S, D600, D700, D800, D90, D3100, D3200, D5000, D5100, D7000, D7100 AND P7700 ARE REGISTERED TRADEMARK OR A TRADEMARK OF NIKON CORPORATION IN THE UNITED STATES AND/OR OTHER COUNTRIES.
 FUJIFILM AND S5 PRO ARE REGISTERED TRADEMARK OR A TRADEMARK OF FUJIFILM U.S.A., INC. IN THE UNITED STATES AND/OR OTHER COUNTRIES.

V1.0

LAST POSITION RETENTION (“LPR”)

Eco Pro-S GPS is able to provide the **last known GPS position with current UTC date / time**⁽¹⁾ to the DSLR camera even if there is the GPS signal is lost or the unit is out of the GPS coverage.

- **No fix** will be reported when no GPS position. The camera’s GPS icon will flash and no GPS data will be recorded.
- **A first fix** is needed during initialization before the LPR works properly.
- Current GPS position will immediately be reported to the camera once the new fix available.
- Last known GPS position with current UTC date / time will be continuously report when the GPS signal is lost, the unit is out of GPS coverage, until there is a good position fix.
- The LPR function works only in “ON” power mode, the last known position will be cleared once the power turns off.

Note (1) : Not applicable to Nikon Coolpix P7700

DI-GPS® IS A REGISTERED TRADEMARK OR A TRADEMARK OF DAWN TECHNOLOGY LIMITED.
NIKON D2HS, D2X, D2XS, D200, D3, D3S, D3X, D300, D300S, D600, D700, D800, D90, D3100, D3200, D5000, D5100, D7000, D7100 AND P7700 ARE REGISTERED TRADEMARK OR A TRADEMARK OF NIKON CORPORATION IN THE UNITED STATES AND/OR OTHER COUNTRIES.
FUJIFILM AND S5 PRO ARE REGISTERED TRADEMARK OR A TRADEMARK OF FUJIFILM U.S.A., INC. IN THE UNITED STATES AND/OR OTHER COUNTRIES.

V1.0

SPECIFICATIONS

General	Chipset MTK MT3339 Frequency L1, 1575.42 MHz C/A code 1.023 MHz chip rate Channels 66 channels all-in-view tracking
Sensitivity	Acquisition -148dBm (Cold Start), -165 dBm tracking
Accuracy (Open Sky)	Position 10 meters, 2D RMS 5 meters, 2D RMS, WAAS enabled Velocity 0.1 m/s Time 1us synchronized to GPS time
Datum	WGS-84
Acquisition Time (Open sky, stationary requirements)	Reacquisition Less than 1 sec., average Hot start 1 sec., average Warm start 33 sec., average Cold start 35 sec., average (No. of SVs>4, C/N>40dB, PDop<1.5)
Dynamic Conditions	Altitude: Maximum 18,000m Velocity: Maximum 515m/s Acceleration: Maximum 4G
Power Source	Powered from DSLR camera via 10 pin connector Current consumption: 21mA acquisition, 19mA tracking
Protocol	Baud rate 4,800 bps Output message NMEA 0183
Interface	Nikon rectangle 10 pin connector direct connect to Nikon DSLR cameras
Physical Characteristics	Dimension 53mm*23mm*14mm Weight: 18g Operating Temperature -10°C to +45°C Operating Humidity: 5% to 90%, No Condensing

DI-GPS® IS A REGISTERED TRADEMARK OR A TRADEMARK OF DAWN TECHNOLOGY LIMITED.
 NIKON D2HS, D2X, D2XS, D200, D3, D3S, D3X, D300, D300S, D600, D700, D800, D90, D3100, D3200, D5000, D5100, D7000, D7100 AND P7700 ARE REGISTERED TRADEMARK OR A TRADEMARK OF NIKON CORPORATION IN THE UNITED STATES AND/OR OTHER COUNTRIES.
 FUJIFILM AND S5 PRO ARE REGISTERED TRADEMARK OR A TRADEMARK OF FUJIFILM U.S.A., INC. IN THE UNITED STATES AND/OR OTHER COUNTRIES.

V1.0

WARRANTY

- Dawn Technology Limited guarantees its product, which is determined to be defective or faulty materials and workmanship, for a period of one year after the date of purchase. During the one-year warranty, Dawn Technology will repair or replace the product free of charges. Please keep your original invoice as proof of purchase.
- Customers who have products covered under the warranty are required to contact Dawn Technology Limited by e-mail for troubleshooting issues before returning product.
- Customer should responsible for shipping and insurance charges for returning the product to Dawn Technology Limited.
- Charges will be imposed for repair product, which is out of warranty coverage or invalid warranty.
- The guarantee is not valid if defect is due to damage caused by incorrect use, poor maintenance or if alterations or repairs have been carried out by persons not authorized by Dawn Technology Limited.
- For the device to be used correctly, the user should strictly adhere to all instructions included in the user guide and should abstain from any actions or uses that are described as undesired or which are warned against in the user guide.

Information in this document is subject to change without notice. Dawn Technology Limited reserves the right to change or improve their products and to make changes in the content without obligation to notify any person or organization of such changes or improvements.

DI-GPS® IS A REGISTERED TRADEMARK OR A TRADEMARK OF DAWN TECHNOLOGY LIMITED.
NIKON D2HS, D2X, D2XS, D200, D3, D3S, D3X, D300, D300S, D600, D700, D800, D90, D3100, D3200, D5000, D5100, D7000, D7100 AND P7700 ARE REGISTERED TRADEMARK OR A TRADEMARK OF NIKON CORPORATION IN THE UNITED STATES AND/OR OTHER COUNTRIES.
FUJIFILM AND S5 PRO ARE REGISTERED TRADEMARK OR A TRADEMARK OF FUJIFILM U.S.A., INC. IN THE UNITED STATES AND/OR OTHER COUNTRIES.