

Catering Urn (Water Boiler)



MODEL: E1910 - E1920

thank you

Thank you for the purchase of this quality **LLOYTRON** product. Used carefully and in accordance with the instructions enclosed, it should give you trouble free service over a long period of time. Please keep these instructions for future reference.

FEATURES

- 1500w or 2500w Power Consumption
- 10Ltr or 20Ltr
- Water level window with gauge
- Power Indicator Light
- Keep Warm Function
- Lockable Lid and Carrying Handles
- Built in safety cut-out against boil dry
- Includes non-fixed drip tray

LOCATION OF CONTROLS

1. Carrying Handle / Twist Lid
2. Water Level Gauge
3. Non-Drip Tap
4. Power / Heating Light
5. Keep Warm Light
6. On / Off Switch
7. Drip tray



TECHNICAL SPECIFICATIONS

Rated Input (E1910):	220-240V ~ 50Hz 1500W
Rated Input (E1920)	220-240V ~ 50Hz 2500W
Capacity (E1910):	10Ltr Max, 1Ltr Min
Capacity (E1920):	20Ltr Max, 1.5Ltr Min
Max Temperature:	95°C +/- 5°C
Re-Boil Temperature:	70°C +/- 5°C
Cable Length:	1.2m approximately
Dimensions (E1910):	28 x 28 x 51.5cm (approx.)
Dimensions (E1920):	34 x 34 x 53cm (approx.)
Operating Temperature:	+5°C to +25°C

IMPORTANT SAFEGUARDS AND PRECAUTIONS

SAVE THESE INSTRUCTIONS

- Read all instructions carefully
- This appliance is intended to be used in household and similar applications such as:
 - Staff kitchen areas in shops, offices and other working environments;
 - Farm houses;
 - By clients in hotels, motels and other residential type environments;
 - Bed and breakfast type environments.
- This appliance is not suitable in an area where water jet is used.
- The appliance must be placed on a horizontal surface.
- Only for use indoors.
- Do not use outside or in damp conditions.
- Before plugging into mains socket, check whether supply line voltage and current rating are in compliance with the rated electrical parameters shown on the rating label.
- Keep away from hot surfaces, such as gas or electric hobs and ovens etc
- Do not use for any purposes other than the appliances intended use.
- This appliance is not intended to be operated by means of an external timer or separate remote control system.
- To prevent damage to the mains cord, do not let it pass over sharp corners, edges or hot surfaces.
- If the supply cord is damaged, do not use. Check before each use!
- The supply cord cannot be replaced. If the cord is damaged the appliance should be scrapped.
- Do not use if any part of this appliance is damaged in any way.
- Always unplug when not in use.

- This appliance can be used by children aged from 8 years and above if they have been given supervision or instruction concerning use of the appliance in a safe way and if they understand the hazards involved. Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised. Keep the appliance and its cord out of reach of children aged less than 8 years.
- Appliances can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance.

- Do not use with extension leads
- To prevent against the risk of electric shock, do not submerge any part of this appliance in water, unless advised in this manual.



CAUTION: Hot Surface

- This appliance should only be used on a flat level surface.
- Always unplug the appliance before refilling.
- Do not operate the appliance without water.
- Do not use with any other liquid.
- Do not carry when filled with water.
- Burns can occur from touching hot surfaces, hot water or steam.
- Do not overfill the appliance, since this may eject hot water.
- Do not use this appliance to warm feeding-bottles.
- Do not allow the water to freeze inside this appliance.

WARNING

Do Not remove the lid while the water is boiling.

CAUTION

Ensure that the appliance is switched off before removing it from its stand.

CAUTION

In order to avoid a hazard due to inadvertent resetting of the thermal cut-out, this appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by the utility.

WARNING

Never carry or move when filled with water.

OPERATION

CAUTION

Before first use, boil the appliance twice and discard the water to remove any dirt left over from production.

1. Place the appliance on a stable flat surface. (DO NOT position near hot surfaces or near open flames).
2. Insert the plug of the mains cord into a wall socket, taking care that the mains cord cannot be accidentally caught by passers-by.
3. Twist the Lid and fill with water upto the 'maximum' level shown on the Water Level Indicator . It should be neither higher than the 'Max' line nor lower than the 'Min' line.
4. Replace the lid, ensuring it falls securely into place.

WARNING

DO NOT OVERFILL – This will cause boiling water to be ejected from the lid.

5. Make sure the environmental temperature indoors is about 10-38 degrees and environmental humidity is less than 90%
6. The heating lamp indicator should now light up and the unit will begin to boil the water.
7. After about 35 minutes the water temperature will have reached 97 degrees and the water-thermostat switches the heating element which automatically keeps the water at the correct temperature.
8. When water level reaches minimum mark, turn the unit off and unplug it from the electric outlet, before refilling with cold water.

■ SAFETY CUT-OFF

This appliance is equipped with a safety cut-off device, to protect the appliance from inappropriate use. Should the appliance be accidentally operated without water, or if all the water has evaporated, the safety cut-off device will automatically switch off the heating element. If this occurs, unplug the appliance and leave unplugged for a minimum of 2 minutes. This resets the safety cut-off and you can now check the unit for any faults before re-using the product.

■ DRIP TRAY

This product includes a free drip tray. Please note that this does not attach to the main unit. Place the drip tray underneath the tap during use to avoid any spillages. After use, clean the drip tray with a cloth and warm soapy water.

TROUBLE SHOOTING

Problem	Cause	Remedy
The light is off, the water is not heated.	The unit is not connected to the power cord.	Check the switch, outlet, fuse, cord and connect it correctly.
The light is off, the water is not heated.	The unit automatically shut down when it detects that there is no water inside the boiler.	Unplug and allow to cool for 2 minutes and the unit should automatically reset.
The light is off, the water is not heated.	1. The lights or resistance are loose. 2. The lights or resistance broke down.	Take it to an authorized services center for repair.
The light is off, the water is not heated.	1. The wire is loose. 2. Heater tube broke down.	Take it to an authorized services center for repair.
The switch doesn't turn into keep warm position.	The warm thermostat is malfunctioning.	Take it to an authorized services center for repair.

CLEANING AND CARE

■ MAINTENANCE

This appliance has been designed to operate over a long period of time with a minimum of maintenance. Continuous satisfactory operation depends upon proper care and regular cleaning.

WARNING

Before performing any maintenance or cleaning of this appliance, disconnect the appliance from the electrical supply.

■ CLEANING

The exterior surface of the appliance and the warming base should be cleaned with a clean damp cloth only. To clean the tap:

1. Move a brush up and down through the tap.
2. Insert the brush through opening inside the appliance to clean the tap connection.
3. Wash the tap handle in hot soapy water and rinse.
4. Replace the tap.

DO NOT

Do Not use abrasive cleaners on any part of this appliance.

DO NOT

Do Not use water jet for cleaning.

■ HARD WATER AREAS

In Hard Water areas, a build up of calcium deposits may become visible around the element. This sometimes causes a distaste in the water. To help keep the appliance in pristine condition, it is recommended to clean the inside of the appliance with a solution of 10% White Vinegar and Water. Boil several times, before rinsing twice with fresh water to remove the calcium build up and the vinegar.


WEEE/ENVIRONMENTAL PROTECTION



■ DISPOSAL OF ELECTRICAL AND ELECTRONIC EQUIPMENT

Do not dispose of this product with household waste. For the proper treatment, recovery and recycling please take this product to the appropriate waste collection point. If you are unsure where this may be, please contact your local authority. Improper disposal may be harmful to the environment.

FITTING A NEW UK PLUG




Your appliance operates on 220-240V~50Hz AC Mains and comes fitted with a 3-pin BSI Approved plug, so that it is ready for use for the UK or Eire market. If for any reason you need to fit a new plug, the flexible mains lead must be connected as shown below: -

■ IMPORTANT:

The wires in the mains lead are coloured in accordance with the following code:

BLUE:	NEUTRAL (N)
BROWN:	LIVE (L)
GREEN AND YELLOW:	EARTH (E)

As the colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

The BLUE wire must be connected to the terminal which is marked with the letter "N" or coloured BLACK.
The BROWN wire must be connected to the terminal which is marked with the letter "L" or coloured RED.
The GREEN AND YELLOW wire must be connected to the terminal which is marked with the letter "E", the symbol  or coloured GREEN.

■ DO NOT CONNECT EITHER WIRE 'L' OR 'N' TO THE EARTH TERMINAL OF A 3-PIN PLUG

Always ensure that the Mains Cord is located into the Plug through the Cord Guard or Cable Clamp, and that the Cord Guard screws are tightened to clamp the Cord (outer sheath and inner coloured wires) in position in the Plug. Make sure the Plug top is also fitted securely.

The supply cord cannot be replaced. If the supply cord is damaged, the appliance should be scrapped.

This appliance must be protected by a 13 Amp fuse in a 13 Amp type (BS1363) plug. Should you need to replace the fuse, use only an ASTA approved BS1362 fuse.

LLOYTRON® CUSTOMER SERVICES

If you have any queries about this product then please contact Lloytron Customer Services online at:



www.lloytronhelpdesk.com

To find out more about Lloytron products, visit www.lloytron.com



Distributed in UK by Lloytron Ltd, Laltex House, Leigh, England. WN7 3XH
Distributed in Europe by Laltex Ireland Ltd, Dublin 2, Eire. D02 AY86