


Instruction


A. Features

- ★ 6 Digits LCD Display, Display Hour ,Minute ,Second ,Month ,Day and Week
- ★ Chime hourly and Daily Alarm
- ★ 12 / 24H format selectable, Auto Calendar
- ★ 1/100 second Chronograph with split functions EL backlight



B. Operational Manual

- ★ Press B key to convert mode:



At any state ,press A key EL backlight for 3s .

At Time mode ,press C key for Date;press D key for alarm time .

Chronograph function

Max time keeping range : 23:59:59.99

The chronograph start from 0.01s, 30 minutes later will be recorded by every seconds.

In normal display mode: press B key once, enter into Chronograph mode

- ★ Press C key to Start running ,press C key again will suspend running, press D key to 0:00:00
- ★ Press C key to start, press D key to split function, the watch will stop display the time keeping function, you can read first group records,but the chronograph will keep running on the background.Press D key again to read second group records,just circulation like that, you can read many group. In split function state, press C key to suspend and exit the split function, press D key to display the sum data of split,press D key again to 0:00:00.

Alarm Setting

- ★ in normal display Mode, press B key twice enter into Alarm Mode.
- ★ At the same time Hour flashing,press C key to adjust Alarm Hour
- ★ Press D key the Minutes will flash. Press C key to adjust Alarm minutes. Press B key to exit.

Alarm & Chime ON/OFF

- ★ In normal mode press, hold C and D key together to ON/OFF the Alarm function, if the alarm symbol display means Alarm ON, otherwise means OFF.
- ★ In normal mode press, hold D then press B key to ON/OFF the Chime function, if the alarm symbol display means Chime ON, otherwise means OFF.
- ★ Press B key to exit.

Time & date Setting

In normal Mode, press B key three times to enter setting mode and the seconds will flashing. Press C key to zero.

- ★ Press C key the Minute will flash. Press D key to adjust the correct Minutes.
- ★ Press D key the Hours will flash. Press D key to adjust correct Hours("A" and "P" display means 12H, "H" display means 24H)
- ★ Press C key the Date will flash. Press D key to adjust correct date
- ★ Press C key the Month will flash. Press D key to adjust correct Month
- ★ Press C key the week will flash. Press D key to adjust the correct week.
- ★ Press B key to exit.