
# XTOOL

**Quick Start Guide** 

# XTOOL



# **THANK YOU!**

#### Dear xTooler:

Thank you for purchasing xTool D1. We are so grateful for your recognition, and sincerely hope you will enjoy this product!

xTool D1 is a high-accuracy and high-power laser engraver and laser cutter. From novice to expert, from home use to business, xTool D1 is ready to give you the best laser engraving & cutting experience.

Our mission is to make it easier for everyone to create with our machine. We attach great importance to product experience and user suggestions. Please let us know if you have any questions at anytime, we are always here to help. You can join our facebook group which gathers 25000+ innovators like you, to share creative ideas and get inspired by others.

By visiting our online store, you can also find our latest accessories and various materials to maximize the magic of xTool D1.

Thanks again for your support, and we will consistently provide quality products and services in the future.

Sincerely,

Official Website: www.xtool.com

Jersen Wef

Facebook Group: xTool D1 Official Group / Makeblock xTool Official Group


**Support Center:** support.xtool.com **Technical Support:** support@xtool.com

Unbox and check	1
Assemble xTool D1	<b>4</b>
Meet your xTool D1	23
Set up xTool D1	24
Download and install software	<b>2</b> 6
Connect Rotary Attachment	<b>2</b> 7

#### **Unbox and check**

Laser module

Safety goggles




Riser Rotary Attachment components (included only in some packs)

1 2

User manual









You can visit support.xtool.com or scan the QR code to find the tutorial video.







The secret to getting ahead is getting started.


Are you ready to embark on a creative journey?


Let's go!










































If you can't put the optical shaft through the timing belt, the possible cause is that the timing belt is set too tight. You can adjust its tension by turning the screw.













Slide the two sliders down against the front plate.


















Pay attention to the front and back sides of the connector. Insert it properly.



Fully tighten the two screws.




















Pay attention to the front and back sides of the connectors. Insert them properly.

No scissors are included in the pack.














The screw is used to set the tension of the timing belt. Do not fully tighten it. Otherwise, the timing belt may be damaged.


































Reserve a sufficient length of the cable to allow the laser module to slide between the left and right plates.









Congratulations!
You have completed the installation!

# **Meet your xTool D1**

# Set up xTool D1

#### Adjust the tension of the timing belts








Try to set the timing belts on the right and left plates to the same tension, so that xTool D1 can cut and engrave materials properly.

#### Set the position of the laser module





Put the focal length setting bar down



Loosen the thumb screw on the other side and slide the laser module upward or downward




After determining the position, tighten the thumb screw and put the focal length setting bar back

#### **Download and install software**

You can operate xTool D1 by using our official software or the third-party software LightBurn.

Note: You need to purchase LightBurn before using it.



### **Connect Rotary Attachment**




You can connect xTool D1 to Rotary Attachment to engrave cylindrical object.


Rotary Attachment needs to work with a device and software. For details about how to use it, visit support.xtool.com.
















Place Rotary Attachment parallel to the working area of xTool D1. Before you connect it to xTool D1, you may need to set its level based on the diameter of the material to be processed.

## Level reference



**Level 1:** 3mm≤d≤50mm



**Level 2:** 45mm≤d≤60mm



**Level 3:** d>60mm

## Set the level

Use the changing of the level from 3 to 2 as an example.

