# **SYNCO G2 Wireless Lavalier Microphone FAQ**

# Q1: What should I do if I lost the accessories of my product? How can I get after-sales support?

- If you have lost any accessories or need after-sales assistance, please
  contact Synco Audio's official customer support via email
  at <a href="mailto:support@syncoaudio.com">support@syncoaudio.com</a>. They will provide further guidance and support
  to resolve your issue.
- For faster service, include your product details and a description of the problem in your email.

# Q2: The receiver stops working/signal drops . What should I do?

#### 1. Check Battery Level

- The receiver (RX) may have low battery, causing unexpected shutdowns or signal drops.
- Connect the RX to a power source using the included Type-C charging cable.
- Charge for 5-10 minutes, then try powering it on again.
- If the device turns on, continue charging until fully charged (~2 hours).



#### 2. Check Pairing Status:

- Ensure the transmitter (TX) and receiver (RX) are successfully paired (screen displays "Connected").
- If not connected, try manual pairing: Press and hold the power buttons on both TX and RX for 8 seconds to enter pairing mode.

#### 3. Restart Devices:

 Turn off devices by holding the power button for 3 seconds, then power them back on.

### 4. Contact Support:

• If the issue persists, email <a href="mailto:support@syncoaudio.com">support@syncoaudio.com</a> with your purchase receipt and a description of the issue.

# Q3: There's significant background noise during recording/noise cancellation isn't working. How to fix this?

#### 1. Enable Noise Cancellation:

Press the Noise Cancellation button on the TX to cycle through modes:
 Off → Low-Level → High-Level (recommended for noisy environments).

#### 2. Adjust Gain Settings:

- Step 1: Connect headphones to the 3.5mm Monitoring Port on the RX.
- Step 2: Press the gain adjustment button on the TX to set levels between 0-15dB while listening to the audio in real time.
- Step 3: Gradually increase the gain until the desired volume is achieved, avoiding high levels (e.g., 12-15dB) to prevent distortion.

#### 3. Check Microphone Connection:

 Ensure external mics are fully inserted into the TRS input jack (compatible with included lavalier mic).

#### 4. Attach Wind Muff:

• Use the included wind muff to reduce wind noise.

#### Why This Helps

- **Real-Time Feedback**: Monitoring through the 3.5mm port allows you to hear exactly how gain adjustments affect audio clarity and noise levels.
- Avoid Overloading: High gain can amplify background noise. By adjusting while listening, you can find the optimal balance between volume and clarity.
- Troubleshooting Tip: If noise persists, try switching to High-Level Noise
   Cancellation and reposition the microphone closer to the sound source
   (10-15cm from the mouth).

# Q4: The product won't connect to iPhone/Android, showing "No Audio Input." How to resolve this?

#### 1. For iPhone users:

 Ensure you're using an MFi-certified Lightning adapter. Non-certified adapters may not support external audio input.

#### 2. For Android users:

 Some stock camera apps don't support external microphones. Try switching to a third-party camera app (e.g., Open Camera, Filmic Pro) for compatibility.

Q5: Audio clipping when connected to DSLR cameras. How to optimize?

#### 1. Lower Camera Input Level:

 Set the camera's recording level to 1/3–1/2 of maximum (see Page 2 for Sony/Canon/Panasonic examples).

#### 2. Adjust RX Gain:

Press the A/B gain buttons on the RX to reduce levels (start at 3dB).

Q5: The receiver/transmitter can be charged via a data cable, but it won't charge in the charging case. What should I do?

## 1. Check the insulating sticker:

• Ensure the protective insulating sticker on the back contact points of the receiver/transmitter has been removed.

### 2. Ensure proper contact:

 Gently press the receiver/transmitter into the charging case to align its contact points with the case's charging pins.

## 3. Charge the case first:

 The charging case's battery level detection might lag. If the case itself is low on power, charge it fully before attempting to charge the devices again.

## 4. Contact SYNCO support:

 If the issue persists, email <u>support@syncoaudio.com</u> with details to request a replacement or further assistance.