


ZUMIMALL[®]

Get Smarter about Your Home Security

QUICK START GUIDE

FCC ID: 2AVKP-BF-BK04



BF-BK06

SECURITY BABY CAMERA
WIRED | WIFI | 24/7 RECORDING

Warranty Service

Thanks for your shopping and trust.

We have been optimizing our products and improving our lifetime customer service to offer you a better shopping experience.

If you have any problems, please feel free to send us an E-mail.

We will address your problems **within 24 hours**. In addition, Your advice and suggestions are always appreciated.

How to Activate the Free 1-year Warranty Extension?

Send us the order number and SN number via email.

Please email us within 30 days of receiving the camera.

Email: Support@zumimall.com

Product Service

Email: Support@zumimall.com

Distributor: Distributor@zumimall.com

More About Us

Web: www.zumimall.com

Facebook: www.facebook.com/zumimalloffice

Brand Story








ZUMIMALL, founded in 2008, focuses on the design and research of intelligent security technology. We insist on taking consumers as the core and strive to create smart home products that lead the global home fashion trend for consumers. Believe in craftsmanship to create top-quality goods, technology changes life. With high-quality products and first-class services, it won the love and trust of millions of customers as soon as it went public.

Over the years, ZUMIMALL has served 45 countries, covering 80% of the population. We are the provider of smart lifestyles and a guardian of the wonderful moments of your life.

1. What's in the Box -----	P 1
2. Product Diagram -----	P2
3. Download and Install App -----	P3
4. Account Registration -----	P4
5. Add Camera to App -----	P4
5.1 Preparations for connection -----	P4
Method 1: Bluetooth Setup(RECOMMENDED) -----	P5
Method 2: QR Code Setup -----	P7
6. How to Reset the Camera -----	P9
7. Camera Installation -----	P10
8. Important Notes -----	P10
9. Monitoring Area -----	P11
10. Device Menu -----	P12
11. Two-Way Audio -----	P13

12. PIR Motion Detection -----	P13
12.1 Motion Detection Alarm Setting -----	P13
12.2 Alarm Notification -----	P14
12.3 Record/Playback/Delete -----	P14
13. Multi-Device Management -----	P15
13.1 Multi-Camera Management -----	P15
13.2 Multi-User Sharing -----	P15
14. FAQ -----	P17

1. What's in the Box



Camera * 1

Power Adapter * 1

Quick User Guide * 1

Screws Set * 1


Charging Cable * 1

Bracket * 1

Warning Sticker * 1

Location Sticker * 1

2. Product Diagram



Reset Button	Keep pressing for 5 seconds to reset
Solid Red Light on	The camera is turning on or malfunctional
Red Light Slowly Blinking	Awaiting WiFi connection
Red Light Quickly Blinking	Connecting the WiFi
Blue Light Blinking	It is in connecting
Solid Blue Light on	The camera runs correctly

3. Download and Install App

Download ZUMIMALL App from Google Play™ or App Store™.

Or scan the QR codes below, with your smartphone.



NOTE: Google Play™ is a trademark of Google Inc.

App Store™ is a service mark of Apple Inc.




NOTE: Please turn on both of the following permissions.

- ① Allow ZUMIMALL App to access mobile cellular data and wireless LAN, otherwise it will fail to connect the camera.
- ② Allow ZUMIMALL App to receive pushed messages, otherwise the phone will not receive alarms when motion is detected.



4. Account Registration

New user needs to sign up ZUMIMALL App with an email address. Click 'Sign up' to create a New Account and follow the steps to complete registration.




5. Add Camera to App

5.1 Preparations for connection

- ① Insert a Micro SD Card into the camera to save video clips or you can start the 7-day free cloud service. Without Micro SD Card or cloud service, no video will be saved.
- ② Please select 2.4G/5GWiFi to ensure good signal.
- ③ For successful pairing, ensure that both the phone and camera are connected to the same network.
- ④ When connecting to the network, please take the camera close to the router(Recommended within 10-15ft).

Method 1: Bluetooth Setup(RECOMMENDED)



- ① On the Homepage, tap 'Add' or '+' in the upper right corner, tap 'Add Device'.
- ② If the Bluetooth of the cellphone doesn't turn on, the app will show a pop-up, please allow it to turn on Bluetooth.
- ③ After Bluetooth turns on, the app will automatically search for devices that are on and not bound. Select the device you want to connect to in the search list.

- ④ To connect the camera, select either the 2.4GHz or 5GHz Wi-Fi and enter the password. The app will automatically display the Wi-Fi you may be using when Bluetooth is turned on. Usually, the name and password for both Wi-Fi networks are the same or similar. If you cannot find the Wi-Fi network, please contact your router provider to check your router's Wi-Fi settings.
- ⑤ The app will automatically go to the page where the wifi connection is in progress. A sound will be heard. Wait until the connection is successful and camera indicator light changes to steady blue. Click ' Next ' to edit the camera name and choose a family. Click ' Done ' to finish the setup.
- ⑥ If failed to connect, check the reason and resolution shown on the app. Long press the reset button until hearing a ' Boogu ' sound to reset the camera and start again, or try the other methods below.


Method 2: QR Code Setup




Tap 'Add Device'



Select Camera



Turn on the Camera



Input Wi-Fi Password




Prepare the Scanning



Scan QR Code



Installation Complete at 100%




Name the Camera



View Installation Tips





Perform Network Diagnosis



Using the Camera



6. How to Reset the Camera

- ① Go to the device homepage, select the camera that needs to be reset, and keep pressing it to remove it from the app.
- ② Press the camera's reset button for 5s until hearing the 'Boogu' sound.
- ③ Reconnect as a new camera.



7. Camera Installation

- ① Secure the camera bracket to the desired position using the screws provided, then rotate the camera against the bracket to snap it into the slot.
- ② Or place the product directly on a clean and flat countertop.





8. Important Notes

 To reduce false alarms, please note that:

- ① Do not install the camera in a position facing strong lights/mirror/window/swimming pool.
- ② Do not install the camera in areas with heavy traffic. Recommended distance between the camera and motion objects is within 32ft.
- ③ Keep camera away from the outlets, including air conditioner vents, humidifier outlets, the heat transfer vents of the projectors, etc.
- ④ Keep the camera at least 1 meter away from any wireless devices to avoid interference, such as microwave stove, Wi-Fi routers, etc.

9. Monitoring Area


- ① It is not suggested to install the camera vertically towards the moving objects, otherwise it may not detect the motion events or cause delay.
- ② It is suggested to make the angle between PIR Sensor and detected objects more than 10 degrees.
- ③ The camera motion sensor is much more sensitive to side-to-side movement across its field of view than to movement directly toward or away from the camera.



Suggestion: The best downward tilt angle of the lens is 15° to obtain the best alarm detection range.

Recommended installation height: 8-10 feet above the ground, at this height, the sensor will provide a detection distance up to 40 feet.

10. Device Menu



1	Add Device and Scan Code	17	Record to Phone
2	More Functions	18	Motion Detection On/Off
3	Basic Equipment Information	19	PTZ
4	Connection Status	20	Light
5	Device Homepage	21	Lens Switch
6	Messages	22	Temperatura & Humidity
7	Explore	23	Music
8	Personal Homepage	24	Album
9	Quit Live Viewing	25	Time Bar
10	Setting Manual	26	Adjusting the Timeline
11	View Live	27	Date of History Record
12	SD Card History	28	Alarm Time Point
13	Cloud Storage	29	Screenshot
14	Screenshot to Phone	30	Record
15	Two-Way Talk	31	Download Video
16	Original Sound	32	Delete Video Recording

11. Two-Way Audio

- ① Open the microphone permission of ZUMIMALL APP.
- ② Long press the intercom button to start speaking, and the sound will be emitted from the camera at this time.
- ③ Release the intercom button to listen to the speech, and the sound will be emitted from the mobile phone.

12. PIR Motion Detection

12.1 Motion Detection Alarm Setting

Motion detection sensitivity can be adjusted from Low to High. Please refer to the image below.



Tap on 'Motion Detection'



Set it up

Sensitivity	Detecting Distance
LOW	3-16ft (1-5meters)
MID	16-32ft (5-10meters)
HIGH	32-49ft (10-15meters)


12.2 Alarm Notification

This camera supports 24/7 recording, and also supports event recording. Here are the system's reactions:

- ① Alarm notifications with sounds from App.
- ② Pictures/videos automatically stored in Micro SD Card or Cloud.

12.3 Record/Playback/Delete

- ① On 'MESSAGES' page, click 'Alarm Messages', you can view all the records listed.
- ② Click the following buttons to playback or delete.
- ③ All screenshots or manually recorded videos on live/history/cloud page will be saved in Pictures & Videos. Files here can be saved in your phone Album or shared with others directly.



13. Multi-Device Management

13.1 Multi-Camera Management




13.2 Multi-User Sharing


NOTE: One App account (A) cannot log in on multiple devices simultaneously. One camera can't be connected to multiple App accounts either. But camera can be shared from A to B.

Share steps:

- ① B downloads ZUMIMALL App to his/her phone and creates a new account in the App.
- ② Click 'Add' in App on A's phone.
- ③ A scan B's QR Code or input B's account ID.
- ④ B accept share and refresh the device page.



On the camera's settings page, tap Share




You have two ways to share: QR code and enter your account number




The person being shared clicks on the QR code on the My page




Scan this QR code




Or enter the account number of the person being shared



Customise the permissions of the person being shared



View Shared Records



Accepting sharing requests

14. FAQ

1. Unable to connect network

- ① Check WiFi name and password (password cannot contain special symbols).
- ② Please select 2.4G/5GWiFi to ensure good signal.
- ③ Please make sure the camera and mobile phone are in the same WiFi environment when connecting, and add the camera near the router.

2. Connect to a new network

- ① Remove camera from ZUMIMALL APP.
- ② Long press the reset button to restore factory settings.
- ③ Reconnect.

3. Reset the camera

- ① Long press the reset button until you hear the sound of ' Boogu '.
- ② Wait for the camera status indicator to flash red slowly.

4. Frequently received alarm information

- ① Reduce the sensitivity of motion detection alarm.
- ② Check whether there is any object within the detection range of the camera to interfere with triggering the sensor.

5. Some people pass by without triggering the alarm

- ① Ensure that the network is in good condition, and the WiFi signal strength should be at least 70%.
- ② Ensure that motion detection is turned on and increase the sensitivity of the camera.
- ③ Make sure the motion occurs within the detection range.

6. No alarm video recording

- ① Make sure the camera is triggered.
- ② Ensure that the Micro SD card is inserted correctly and recognized successfully, or subscribe to cloud services.

7. No alarm push

- ① Open the phone settings, click the notification, find the ' ZUMIMALL ' APP, and open the permission notification.
- ② Open the ' ZUMIMALL ' APP, in the ' Settings ' interface, enable the alarm push.
- ③ In the 'My' interface, enter the settings and turn on the push sound.
- ④ Ensure that the motion detection function of the device is successfully turned on.
- ⑤ Restart the phone, try to clear the cache on the Android phone.
- ⑥ Check whether the network is good.

8. Unable to play local history playback

- ① Check the status of the Micro SD card in ' Settings ' to ensure that the Micro SD card has been successfully recognized.
- ② Reinsert the Micro SD card.
- ③ Format the Micro SD card in the APP.
- ④ Use a new Micro SD card.

9. Unable to play cloud playback

- ① Make sure the cloud service function is enabled.
- ② Open cloud storage button in cloud service interface.

10. Device offline

- ① Check whether the device has sufficient battery power, and observe whether the camera status indicator lights up normally.
- ② Check whether the WiFi network is good, restart the router.
- ③ If the camera is installed far away from the router and cannot obtain a good WiFi signal, it is recommended to move the router to a closer place or install a WiFi signal extender to increase the WiFi strength.
- ④ Delete the camera from the ZUMIMALL account, reset the device and add it again.
- ⑤ Check if the device version and ZUMIMALL APP are the latest version.

11. ZUMIMALL APP crashes

- ① Re-download the latest version of ZUMIMALL APP.
- ② The mobile phone's operating system version may be too old or too new.
- ③ Clear the phone cache.

12. Unable to register an account

- ① Ensure that ZUMIMALL APP has access to mobile cellular data and wireless LAN.
- ② Use an unregistered email to create a new account and ensure that the email format is correct.

13. Unable to share device

- ① The accounts you and your friends have registered must be in the same country.
- ② For example, UK users cannot share with US users.

14. No sound is heard when the device is talking

- ① Open the speaker button on the APP.
- ② Adjust the intercom volume in the settings.
- ③ Turn on the phone media volume.
- ④ Release the intercom button and listen to the other party.

15. Noise during two-way intercom

- ① If the distance between the camera and the mobile phone is too close (1~2 meters), there will be howling, which is a normal phenomenon.
- ② It is recommended to keep a certain distance between the camera and the mobile phone during the intercom.

16. Live video is blurry

- ① Check the lens for dust and wipe it clean.
- ② Try switching between different resolutions.
- ③ Re-add camera after reset.


17. The live broadcast at night has white spots

- ① When the light source is directly on the lens, there will be white spots on the screen.
- ② Avoid pointing the lens directly at strong light sources.


If you have other questions, please send us the SN number of your camera and describe the problem you have encountered, we will solve it as soon as possible.

Email: Support@zumimall.com


How to find SN number?



Click Settings



Click Device Information



View SN ID