# Mesquul

# Upgraded Simple Loud Alarm Clock BEST DECORATION FOR BEDROOMS

# Contact our experts:


support-us@mesqool.com support-ca@mesqool.com

https://www.mesgool.com

- CR 1028 EM



Version 1.0



- 02 -


24. Vibrator Insert Port25. Night Light

# **Package Lists**

1x Alarm Clock 1x Cable(Length:1.5M/5ft)

1x Adapter( DC 5V/2A) 1x User Manual


1x Bed Shaker(Length:1.8M/6ft)



#### **Installation Notes**

- Connect the power cord to the DC jack, and plug into a 100~240V AC wall power outlet.
- 2. Install 2pcs 1.5V "AAA" batteries to the proper terminals in the battery compartment to memorize the time setting and the alarm will ring in case of power outage.

Note: Batteries are not included and don't support time display or any other functions.




- 03 -

# **Time Setting**

 Press the "TIME" button to enter the time setting mode. The week digits will start flashing. Use the " + " and " - " buttons to select the day of a week.

12. PM Indicator

- 2.Press the "TIME" button again to enter the hour setting mode. The hour digits will start flashing. Use the " + " and " - " buttons to adjust the hour display.
- 3.Press the "TIME" button again to enter the minute setting mode.
  The minute digits will start flashing.
  Use the " + " and " " buttons to adjust the minute display.
- 4.Press the "TIME" button to confirm the time, or wait for another 10 seconds to confirm automatically.




### **Alarm Setting**

(1)

#### Set the Alarm

- 1. Slide the Period Range switch for Alarm 1 on the back to choose the period range.
- 2. Press"AL1" button the alarm 1 indicator will light up.
- 3. Press "AL1" button again, the hour digits will start flashing. Use the " + " and " - " buttons to set the hour
- 4. Press the "AL1" button once more, the minute digits will start flashing. Use the " + " and " \_ " buttons to set the minute.
- 5. Press the "AL1" button again to save the alarm settings, the icon starts flashing.
- 6. Repeat-press " " or " + " button to choose the 3 wake-up modes "Single Buzzer" or "Single vibrator" or "Buzzer + vibrator", and press the "AL1" button again to confirm your choice.





MON-SUN

MON-FRI

S A T-SUN

0:0=0

- 05 -

#### Set the Wake up Mode

- 1. Wake up by buzzer sound only: only buzzer indicator lights up.
- 2. Wake up by bed shaker only: only vibrator indicator lights up.
- 3. Wake up by both buzzer and bed shaker: both buzzer indicator and vibrator indicator light up.



#### Set the Vibration Intensity

Plug in the vibrator and slide the Vibration Intensity switch on the back to adjust the 3-level strength of the bed shaker.



#### Set the Volume

Repeat-press the "VoL" button to adjust alarm volume.



### Turn off Alarm & Snooze Mode

- 1. When the alarm goes off, press the "SNOOZE/OK/LIGHT" button, the alarm icon will be flashing and alarm will stop temporarily and ring again after 9 minutes. (SNOOZE mode can be recycled 9 times)
- 2. During the alarm ringing, press the "AL1" or "AL2" button to turn off the alarm for the current day. The alarm will ring again the next day.
- 3. If there is no operation after the alarm goes off, the alarm will automatically stop after 60 minutes and ring again the next day.

- 06 -

#### **Cancel Alarm**


Hold press the "AL1" button for 3 seconds until the alarm 1 indicator disappears from the display, it will never ring.

Note: The setting method for Alarm 2 is the same as Alarm 1.




# 12/24H Time & DST Setting

1. Short press the "12/24H DST" button to switch the 12H/24H time format. In the 12-hour format, an AM/PM icon will be displayed.



2. Hold press the "12/24H DST" button to turn on or off the DST function.



### Night Light

When there is no alarm clock ringing, press the "SNOOZE/OK/LIGHT" button to turn on the night light. Repeat-press it to adjust the brightness: High-Medium-Low-OFF.


## **Brightness Setting**

- 1. Display screen brightness (default L04). Repeat-press the "DIM" button to adjust the brightness of the digits display. It cycles through levels L01 to L05.
- 2. When in L01 level, bow icon appears, the icon will disappear after 20s of display if no operation. Press "DIM" button once more, the LOW icon will display again.



# **Charging Other Devices**

This alarm clock has a USB port, you can charge your mobile device at the same time (charging cable not included), the maximum charging current is 1 Ampere.



#### **Warranty Service**

#### 45-Day Full Refund

If you are unsatisfied with the product or encounter any issues, please contact us promptly for a full refund or technical support.

**18-Month Warranty**Within 18 months, if the product has any quality issues, please contact us for a replacement or partial refund.

#### Lifetime Free Customer Support

We provide lifelong free customer support. If you have any questions or concerns, please don't hesitate to reach out to us.