

Wireless Doorbell User Manual

FCC WARNING

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency

energy and, if not installed and used in accordance with

the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm distance between the radiator and your body: Use only the supplied antenna.

Product description:


1.Product features: wireless doorbell, drive wireless signal by pressing, no wiring, simple installation, green and environmental protection The appearance adopts minimalist design,simple and elegant,round and beautiful in appearance.It is not only used for doorbells, but also for switches pagers, etc. various fields.



Transmitter B



Pairing
Volume
Music



Receiver

- (1) Wireless transmission, no wiring required
- (2) Outdoor open space is between 100-300 meters
Note: This is the test distance, the actual distance varies depending on the environment, the more obstacles the shorter the distance
- (3) 3-level volume adjustable
- (4) 38 songs to choose from
- (5) Learning code function

Technical parameter

(Please correspond to the specific model)

Receiver Parameters

Receiver parameters

Working voltage: AC 5V(USB powered)

Power consumption: $\leq 0.5W$

Volume: 25-105dB

Music: 38 Music

USB Receiver size: 43x41x32mm

Transmitter B parameters

Working voltage: DC 12V

Transmit power: $< 10mW$

Battery model: 23A 12V

Instructions

The packaged products are paired before leaving the factory and do not need to be paired again.

To replace transmitters or ask transmitters, do the following:

Pairing method

The receiver is plugged into the USB interface, in the power on state, if you need different transmitters to connect to different ring tones, first press the music button to select music and then long press the receiver pairing button for about 3 seconds until the indicator light flashes, enter the pairing mode, at this time, press the transmitter, the receiver rings, and the pairing is successful.

Clear code

Press and hold the receiver pairing button for about 10-13 seconds until the indicator light flashes rapidly and then stops flashing, that is, all pairing codes are cleared.



Installation method

The transmitter can be placed or moved at will, and can also be fixed to your preferred location. Before fixing, please put it in the required fixing position to try it out, it will not affect the normal use and then fix it. Fixed as follows:

Note: Please remove the battery insulation sheet before performing the following steps

(1) Tear off the double-sided tape and stick it on the back of the transmitter, press firmly

(2) Tear off the double-sided tape on the other side, choose the installation location on the transmitter and wipe it clean (be not to get close to iron and metal objects, metal objects will affect the wireless signal), press it on the wall for more than 30 seconds and fix it firmly

(3) Plug the receiver into the USB interface and power on

(4) Press the music button of the receiver to select the appropriate music

Fig. 10-1-1-1



Fig. 10-1-1-2

Distance between transmitter and receiver, 10-15cm, the distance between transmitter and receiver should be 10-15cm.

Troubleshooting and troubleshooting:

1. The doorbell does not ring: Check whether the receiver is plugged in and the socket is powered.

2. Short transmission distance: metal objects such as iron gates, iron gates and iron frames will affect the effective transmission distance. Avoid placing the transmitter and receiver near metal objects, walls and ceilings also affect the transmission distance. Be far away from other wireless devices, etc.

3. Power switch of a battery head in time to replace the battery when the red color light of the transmitter type A is dark, so as not to affect the launch distance.

