

Go to www.vtechphones.com to register your product for enhanced warranty support and the latest VTech product news.

DM226 DM226-2

Safe & Sound® Digital Audio Monitor



vtech®

User's manual


Congratulations

on purchasing your new VTech product. Before using this product, please read **Important safety instructions**.

This manual has all the feature operations and troubleshooting necessary to install and operate your new VTech product. Please review this manual thoroughly to ensure proper installation and operation of this innovative and feature rich VTech product.

For support, shopping, and everything new at VTech, visit our website at www.vtechphones.com.

What's in the box



1 set for DM226;
2 sets for DM226-2



Install the battery

The parent unit runs on rechargeable battery or AC power. To continuously monitor your baby, make sure you use both battery and AC power at the same time. With the battery alone, the parent unit can cordlessly run for a short time only.

NOTES



- Use only the battery supplied with this product.
- If the parent unit will not be used for a long time, disconnect and remove the battery to prevent possible leakage.

Install the battery as shown below



NOTE

- Make sure the **THIS SIDE UP** is facing up while inserting the battery.



Replace the battery




To replace the battery, pull out the battery compartment cover, and then lift up the battery. Follow the previous steps to install the battery.

Connect and charge the battery

NOTES

- Use only the power adapters supplied with this product.
- Make sure the electrical outlets are not controlled by wall switches.
- The power adapters are intended to be correctly oriented in a vertical or floor mount position. The prongs are not designed to hold the plug in place if it is plugged into a ceiling, under-the-table or cabinet outlet.
- Make sure the parent unit, the baby unit and the power adapter cords are out of reach of children.

Connect the baby monitor



Charge the parent unit battery

When you have connected the parent unit and installed its battery for the first time, it powers on automatically. The battery icon indicates the battery status (see the following table).

NOTES

- The parent unit battery is fully charged after 11 hours of continuous charging.
- It takes longer to charge the battery when the parent unit is turned on. To shorten the charging time, turn the parent unit off while charging.
- The standby time varies depending on the voice-activated (VOX) sensitivity level you set, your actual use and the age of the battery.

Battery indicators	Battery status	Action
The battery icon is off.	No battery is installed but operates using AC power. -OR- Abnormal battery is detected.	Install the parent unit battery. Charge without interruption (at least 30 minutes).
The screen displays LOW BATTERY and . The light flashes.	The battery has very little charge and may be used for only a short time.	Charge without interruption (about 30 minutes).
The battery icon becomes solid .	The battery is fully charged.	To keep the battery charged, connect it to AC power when not in use.

Before use

NOTE


- This baby monitor is intended as an aid. It is not a substitute for proper adult supervision, and should not be used as such.

Test your baby monitor

You may test the baby monitor before initial use, and at regular times thereafter.

CAUTION

- For hearing protection, make sure the parent unit is more than 6.5 feet (2 meters) away from the baby unit. If you hear any high-pitched noise, move the parent unit further until the noise stops. You can also press **VOL** on the parent unit to lower or mute the noise.



- Make sure your baby unit and parent unit are on.
- Speak towards the microphone of the baby unit. You will hear the sound at the parent unit, and see the visual sound indicators light up.

NOTE

- When the parent unit displays **NOT LINKED** and flashes, move the parent unit closer to the baby unit (observe the minimum distance of 6.5 feet/ 2 meters). You can also check if the baby monitor is connected to a live power socket and switched on.

TIP


- Increase the speaker volume of the parent unit if you cannot hear the sounds transmitted from the baby unit.

Positioning the baby monitor


CAUTION

- Keep the baby unit out of the reach of the baby. Never place or mount the baby unit inside the baby's crib or playpen.

- Place the baby unit more than 3 feet (1 meter) away from your baby.



- Place the parent unit more than 2 meters (6.5 feet) away from the baby unit.



CAUTION


- The default volume of your parent unit is level 3. If you experience high-pitched screeching noise from your baby monitor while positioning:
 - Make sure your baby unit and parent unit are more than 6.5 feet (2 meters) apart, OR
 - Turn down the volume of your parent unit.

Operating range

The operating range of the baby monitor is up to 1,000 feet (300 meters) outdoors or 160 feet (50 meters) indoors. The actual operating range may vary depending on the environmental conditions, and other interferences such as walls, doors, and other obstructions.


Overview

Baby unit overview



1	Night light Press to turn the night light on or off.
2	Night light - On when night light is turned on manually. - Off when night light is turned off manually.
3	On/off - Press to power on, the power light turns on. - Press and hold to power off, the power light turns off.
4	PAGE Press to start or stop paging parent unit.
5	Microphone
6	VOL + Press to increase the speaker volume.
7	VOL - Press to decrease the speaker volume.
8	Speaker
9	Power jack

Parent unit overview



1	Microphone
2	On/off - Press and hold to power on, the screen turns on. - Press and hold to power off, the screen turns off. - While in a menu, press to return to idle screen.
3	MENU/ - Press to enter the menu while idle. - While in a menu, press to return to the previous screen. - Press to return to idle screen.
4	Visual sound indicator The visual sound indicator has two functions. One is to show the sound level detected by the baby unit. The other one is to show the volume level during speaker volume setting. Sound level detected by the baby unit - One to three green lights indicate a moderate sound level detected by the baby unit. - Additional red lights indicate a higher sound level detected by the baby unit (e.g. baby crying loudly). Speaker volume level - One to three green lights indicate Level 1 to Level 3 of the speaker volume setting. - Additional red lights indicate Level 4 to Level 5 of the speaker volume setting.

5	LCD panel
6	Battery level indicator - Light on when the battery is being charged. - Light flashes when the battery is low and needs charging. - Light off when no battery is installed, or abnormal battery is detected.
7	TALK - Press and hold to talk to the baby unit; release to stop talking. - While in a menu, press to return to idle screen.
8	SELECT While in a menu, press to choose an item, or save a setting.
9	+ VOL - Press to increase the speaker volume. - While in a menu, press to scroll up.
10	- VOL - Press to decrease the speaker volume. - While in a menu, press to scroll down.
11	Power jack
12	Speaker
13	Belt clip
14	Battery compartment cover

Parent unit display icons

	Connection status - displays when strong signal strength is detected between the baby unit and the parent unit. - displays when moderate signal strength is detected between the baby unit and the parent unit. - displays when the weak signal strength is detected between the baby unit and the parent unit. - flashes when the link between the baby unit and the parent unit is lost.
	Night light On when the night light is turned on.
	Sound alert - Displays when the sound alert of the parent unit is turned on. - Flashes when there are loud sounds detected from the baby unit.
	Vibration alert - Displays when the vibration alert of the parent unit is turned on. - Flashes when there are loud sounds detected from the baby unit.
	Mute Displays when the volume is turned off.
	Battery status - animates when the battery is charging. - displays solid when the battery is fully charged. - flashes when the battery is charged with AC adaptor, or charging is failed. - flashes when the battery is in low level and needs charging. - No battery icon displays when there is no battery installed, or abnormal battery is detected.


Parent unit display screen messages

LINKED	The link between the parent unit and the baby unit is established.
LOW BATTERY	The parent unit uses only the rechargeable battery pack and it needs to be recharged.
NOT LINKED	The link between the parent unit and the baby unit is lost continuously for over 10 seconds.
PAGING	All idle parent units are being paged by the baby unit.
SAVED	Your selection has been saved.
SEARCHING	The parent unit is out of range of the baby unit, or the baby unit is out of power.
TALK	The parent unit is talking to the baby unit.
TALKBACK	The other parent unit is talking to the baby unit.

Using the baby monitor


Power the baby unit on or off

- Press to power on the baby unit. The power light turns on.
- Press and hold to power off the baby unit. The power light turns off.



Power the parent unit on or off

- Press and hold to power on the parent unit. The screen turns on.
- Press and hold to power off the parent unit. The screen turns off.



NOTE

- The parent unit powers on automatically once it is connected to AC power or battery installed. The baby unit also powers on automatically once connected to AC power.

Adjust the speaker volume for baby unit

- Press **VOL +** or **VOL -** on the baby unit at any time.

Adjust the speaker volume for parent unit

You can adjust the speaker volume from **VOLUME 1** to **VOLUME 5**, or turn it off. The speaker volume is preset to **VOLUME 3**.

- Press **+ VOL** or **- VOL** when the parent unit is not in use.

When the speaker volume is set to off, the screen displays .

Adjust the Voice-activated (VOX) sensitivity level of the baby unit

You can choose to hear sounds from the baby unit all the time, or to hear sounds that exceed a certain level. You can use the parent unit to adjust the microphone sensitivity of your baby unit. The higher the VOX sensitivity level, the more sensitive the baby unit is in detecting sounds for transmitting to the parent unit. The VOX sensitivity level is preset to **HIGHEST**.

VOX sensitivity level table for reference

Display	Sensitivity	Description
HIGHEST	High sensitivity	Highest VOX sensitivity level The parent unit speaker is constantly on, and you will hear all sounds (including background noises) from your baby's room.
HIGH		High VOX sensitivity level The parent unit speaker turns on for soft babbling and louder sounds from your baby. It remains quiet when your baby sleeps soundly.
MEDIUM		Medium VOX sensitivity level The parent unit speaker turns on for loud babbling and louder sounds from your baby. It remains quiet when your baby makes soft sounds.
LOW		Low VOX sensitivity level The parent unit speaker turns on for crying and louder sounds from your baby. It remains quiet when your baby makes soft sounds.
LOWEST	Low sensitivity	Lowest VOX sensitivity level The parent unit speaker turns on for loud crying or screeching sounds from your baby. It remains quiet when your baby makes soft sounds.

- Press **MENU** when the parent unit is not in use.
- Press **SELECT** to select **VOX LEVEL**.

- Press **+ VOL** or **- VOL** to choose the VOX sensitivity level.
- Press **SELECT** to confirm your selection. The screen displays **SAVED** and you hear a confirmation tone.

NOTE

- To enter the **VOX Level** menu of the parent unit, the baby unit must be turned on.

Sound alert

If you turn on the sound alert, the parent unit beeps when the baby unit detects sounds which had triggered the red light of visual sound indicator on the parent unit.

When the sound alert of the parent unit is turned on, displays. The sound alert is preset to **OFF**.

- Press **MENU** when the parent unit is not in use.
- Press **+ VOL** or **- VOL** to choose **SOUND ALERT**, then press **SELECT**.
- Press **+ VOL** or **- VOL** to choose **ON** or **OFF**.
- Press **SELECT** to confirm your selection. The screen displays **SAVED** and you hear a confirmation tone.

NOTE

- The sound alert setting on each parent unit is independent.

Vibration alert

You can turn on the vibration alert so that the parent unit vibrates when the baby unit detects sounds which had triggered the red light of visual sound indicator on the parent unit.

When the vibration alert of the parent unit is turned on, displays. The vibration alert is preset to **OFF**.

- Press **MENU** when the parent unit is not in use.
- Press **+ VOL** or **- VOL** to choose **VIBE ALERT**, then press **SELECT**.
- Press **+ VOL** or **- VOL** to choose **ON** or **OFF**.
- Press **SELECT** to confirm your selection. The screen displays **SAVED** and you hear a confirmation tone.

NOTES

- Each time you set the vibration alert to **ON**, the parent unit vibrates briefly after you press **SELECT**.
- The vibration alert setting on each parent unit is independent.

