


HOTATA

ENGLISH




HOTATA L
Smart
Lock

TTLOCK DEADBOLT LOCK

APP Guide
Model: SL102

HOW TO REGISTER

Download the TTLOCK app from
Google Play or App Store.
Search“ TTLOCK ”



STEP 1
Tap on register
to get started !



STEP 2
Fill out this and then tap
“Get Code”. You will be
sent a verification code to
verify your account! Once
you receive it, tap on
“Register”

Note: The ttlock app is need to use this lock.If this lock was professionally installed (or installed by someone other than the homeowner),make sure this step is performed by the homeowner.

PAIRING YOUR LOCK



STEP 1
Tap on the three
horizontal lines.



STEP 2
Tap on
"+ Add Lock"




STEP 3
Tap on "Next"



STEP 4
Tap on the blue plus sign.

Note: You may need to tap
on lock keypad.

LOCK PAGE OVERVIEW



Unlock/Lock

Unlock/Lock using phone's bluetooth



Generate Passcode Page

Generate 6 different types of passcodes



eKey Page

View and modify current eKeys



Remote Unlock (Need Gateway)

Unlock remotely if Sifely Gateway is connected nearby



Records Page

View entry times, attempts and methods



Settings Page

View and modify settings



Cards/Fobs Page

Set up your fobs here



Fingerprints Page

Set up fingerprints




Authorized Admin Page

Create and edit admins

Note: Some of these icons may not appear if the Gateway is not connected to the lock.

APP UNLOCK/LOCK



To unlock the lock, tap this icon once.

To lock the lock, press and hold on this icon.

Note: This will only work while you are within bluetooth range of the lock. Refer to Gateway Guide page for remote unlock/lock information.

PASSCODES



Passcodes

STEP 1

To access the passcode menu tap on "Generate Passcode". This will take you to the passcode page.



STEP 2

Enter a name for this Passcode.

Here is a breakdown of the 6 different code types for different durations

Permanent	Lasts permanently	Erase	Erases all codes on lock
Timed	Lasts between selected hours	Custom	Choose your own digits such as 4321 (permanent or timed)
One-time	Lasts for one use	Recurring	Lasts during scheduled hours weekly

PASSCODES



Best Practice:

When inputting the passcode use # + Code + #.

Pay attention to this text when generating a code. You may experience issues if these instructions are not followed.

Note: To generate custom codes, you will need to be within bluetooth range of the lock unless a Gateway is connected.



Within this page, you can

- Edit a passcode's number, validity, and name.
- Delete code and view records.



Note: The above can only be done within bluetooth range unless a Gateway is connected.

IC CARD/FOBS




STEP 3

To add a fob to your lock. Follow these steps.

STEP 4-6

4. Choose the validity period of the lock.
5. Once the lock says "Please swipe your card" place the fob against on the keypad.
6. If you hear "input successful", the fob can be used to unlock your lock.




STEP 1

Tap on "Cards"


STEP 2

Tap on "Add Card"


FINGERPRINTS TO ADD A FINGERPRINT FOLLOW THESE INSTRUCTION




Step1
Tap on Fingerprints.




Step2
Tap on "Add Fingerprints"




Step4
Follow instructions on app. You will be asked to place your finger on the sensor 4 times






Step3
Select Fingerprint type depending on when you would like it to be valid.



Experiencing issues with fingerprint recognition?


- Ensure the sensor surface is clean.
- Try a different finger.
- Ensure your finger is moist enough.
- Take out batteries for a minute and place back in.


eKEYS




STEP 1
eKeys work by sharing app access of your lock with another Smart Lock account. eKey recipients will be able to use their phone to unlock/lock the lock.

Best Practices:
It is strongly recommended that the recipient first register for an account using the Smart Lock app.





STEP 2
Enter recipient's username. It will be the phone number or email address used during registration. eKeys do not require wifi or bluetooth to be sent or revoked.



AUTHORIZED ADMIN



Authorized Admin

STEP 1

Authorized Admins are similar to eKeys; however, an authorized admin can do the following:

1. Unlock/lock via the app.
2. Generate, Edit, Delete passcodes, IC cards, & fingerprints.
3. Adjust settings like passage mode, auto-lock timer, & turn on/off the lock sound.



STEP 2

Enter recipient's username. It will be the phone number or email address used during registration.

PASSAGE MODE & AUTO-LOCK



Settings


STEP 1

Auto-lock will automatically lock the lock when it has been opened after 5 seconds by default. This can be adjusted with Passage Mode and Auto-lock timer. Outlined below is how to adjust these settings related to auto-lock.



STEP 2

Select Passage Mode



STEP 3

Passage Mode disables auto-lock during a set schedule.



LOCK SETTINGS



Here are some settings you should familiarize yourself with.

Under Basics, you can view and change information such as Lock Name.

Gateway shows signal strength if Gateway is connected.

With Remote Unlock on and a Gateway connected, you can remotely unlock/lock your lock.

Lock Sound adjusts the locks sound level.

Import from another lock allows for the transfer of passcodes and fobs from one lock to another.

Delete will remove the lock from your account and clear any settings one the lock.

You must be near the lock to do this.

EDIT ADMIN PASSCODE



Note: Edit admin postcode only work while you are within Bluetooth range of lock if no tlock gateway connect.

GATEWAY(Sold Separately)

The Gateway bridges any nearby locks to your local wifi allowing for remote control.



With the Gateway connected.

- Receive unlock notifications wherever you are.
- Remote unlock/lock.
- Check access logs whenever you need them.
- Generate, edit, or delete custom codes for your guests.
- Access the features of the webportal version of our app for free!
- Check battery level remotely

FAQ

Q: I entered a code or fingerprint incorrectly too many times and my lock will not accept any new inputs.

A: Unlock the lock once via the app or wait 5minutes.

Q: How can I manually lock the lock?

A: Press and hold # to lock the lock.

Q: The batteries died before I could replace them. What can I do?

A: Use the provided physical keys to open or plug in a powerbank in emergency power supply slot at the bottom of lock to be able to enter and change the batteries

Q: How do I share access of the lock on 2 different phones?

A: Refer to eKeys or Authorized Admin section on how to do that is.

Not working like it should? Contact us with the following information for quicker resolution.

- Which product you do have?
- Where are you in the setup process?
 - Installing the product.
 - Setting up the app and pairing the product.
 - Already set up app with the product.
- How long have you had our products for?

Here is how you can contact us:

Email: aftersale@hotata.com

Live chat: the seller website.