


SETUP GUIDE

Demologo Battery Cam 1



demologo


In the box




Battery Cam 1 x 1



Anchor plate x 1






USB-C charging cable x 1



Screws / Drywall anchors

At a glance





- | | |
|-----------------|-----------------------|
| 1 Camera lens | 7 Magnetic bracket |
| 2 LED indicator | 8 Power button |
| 3 Microphone | 9 Charging port |
| 4 Spotlight | 10 Restart slot |
| 5 Motion sensor | 11 Micro SD card slot |
| 6 Speaker | |

Download Demo app


Search "Demologo" in your phone's app store or scan the QR code.

To reduce the risk of scams or malware, use your phone's built-in camera app to scan the QR codes instead of third-party apps.




Add devices to your Demo app

Press and hold the Power button for 3 seconds to turn on the camera. Then, sign in to the app and click the "+ Add device" button. Follow the in-app instructions to complete the setup.



Charge the camera


Fully charge the battery before its initial use by connecting it to a USB-C cable and charge via a USB-C charger (DC 5V/1A-2A), sold separately. Charging the battery will take approximately 4-6 hours. The power indicator will turn green once the battery is fully charged.




Mount the camera

Wall

We recommend hanging the camera 7-10 ft (2-3m) above the ground for optimal monitoring coverage.



Note: Ensure to mount the camera according to the correct orientation steps shown below (1-4).




Install using the magnetic bracket

The magnetic bracket is designed to securely attach to any ferrous material.

Important Note:


The strength of the camera's magnetic adhesion depends directly on the thickness of the metal it is attached to. It is advised to avoid attaching it to extremely thin metal materials, as this may compromise the effectiveness of the magnetic connection.



Install using the anchor plate


1. If magnetic attachment is not an option in your home, you can use the anchor plate for installation.

- Use a 15/64-inch (6mm) drill bit to drill holes where the anchor plate will be placed.
- If your wall is made of concrete, wood, brick, or stucco, insert the provided drywall anchors into the holes.
- Attach the anchor plate to the wall, ensuring the "Up" label on the plate is placed in the upward direction.




2. Mount the camera

- Fasten the camera to the anchor plate, and make sure it is attached securely.




- Adjust to the appropriate angle for monitoring.



Ceiling


1. Mount the anchor plate

- Use a 15/64-inch (6mm) drill bit to drill holes where the anchor plate will be placed.
- If your ceiling is made of concrete, wood, brick, or stucco, insert the provided drywall anchors into the holes.
- Attach the anchor plate to the ceiling.




2. Mount the camera

- Fasten the camera to the anchor plate, and make sure it is attached securely.




- Adjust to the appropriate angle for monitoring.



Flat surface

- Place the camera on a table and adjust the angle for optimal monitoring.



Safety

- Do not use the device in extreme temperatures, and never expose the device to strong direct sunlight or a humid, wet environment.
- The suitable temperature for Battery Cam 1 and its accessories is -10°C / 14°F to 45°C / 113°F .
- The best environment is a temperature range between 5°C / 41°F and 25°C / 77°F .
- The suitable temperature for charging is $0^{\circ}\text{C}/32^{\circ}\text{F}$ to 45°C / 113°F . When charging, place the device(s) at room temperature in a place with good ventilation.
- Only use the adapter and battery supplied by the manufacturer. Using unauthorized adapters and batteries may cause damage to the device and will void the device's warranty.

Warning

- Replacing the battery with an incorrect version can destroy the safety mechanisms within the device.
- Inappropriate battery disposal, for example, into a fire or a hot oven, or mechanically crushing or cutting the battery, can result in an explosion.
- Leaving the camera in a very high-temperature environment can result in an explosion or the leakage of flammable liquid or gas.
- A battery subjected to extremely low air pressure may result in an explosion or the leakage of flammable liquid or gas.

Attention

- Le remplacement de la batterie par un type incorrect peut détruire les mécanismes de sécurité à l'intérieur de l'appareil.
- L'élimination inappropriée de la batterie —par exemple, dans un feu ou dans un four, ou par écrasement ou coupure—peut provoquer une explosion.
- Le maintien de la batterie dans un environnement à très haute température peut provoquer une explosion ou la fuite de liquide ou de gaz inflammables.
- Une batterie soumise à une pression d'air extrêmement faible peut provoquer une explosion ou la fuite de liquide ou de gaz inflammables.

⚠ CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT MODEL. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

⚠ ATTENTION: RISQUE D'EXPLOSION SI LA BATTERIE EST REMPLACÉE PAR UN TYPE INCORRECT. ÉLIMINER LES BATTERIES USÉES SELON LES INSTRUCTIONS.

Notice

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- this device may not cause harmful interference;
- this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

FCC Radio Frequency Exposure Statement

This device has been evaluated to meet general RF exposure requirements. The device can be used in fixed/mobile exposure conditions. The minimum separation distance is 20 cm.

Notice: Shielded cables

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment on and off, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

All connections to other computing devices must be made using shielded cables to maintain compliance with FCC regulations.

IC Statement

This device complies with Industry Canada Licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- this device may not cause interference, and
- this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exemptés de licence.

L'exploitation est soumise aux deux conditions suivantes:

- l'appareil ne doit pas produire de brouillage, et
- l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

IC RF Statement

When using the product, maintain a distance of 20 cm from the body to ensure compliance with RF exposure requirements.

Lors de l'utilisation du produit, maintenez une distance de 20 cm du corps afin de vous conformer aux exigences en matière d'exposition RF.

EU Statement



This product complies with the radio interference requirements of the European Community. Hereby, demo declares that this device is in

compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. For the declaration of conformity, visit the Website: <https://www.Demo.com>

This product can be used across EU member states.

RF exposure information

The Maximum Permissible Exposure (MPE) level has been calculated based on a distance of 20 cm between the device and the human body. To maintain compliance with RF exposure requirement, use product while maintaining a 20 cm distance between the device and human body.

Battery Cam 1 Wi-Fi Operating Frequency Range:2412~2472 MHz(2.4G),Wi-Fi Max Output Power:20 dBm(EIRP);

Battery Cam 1 Operating Frequency Range:2402~2480 MHz; Bluetooth Max Output Power:8 dBm(EIRP) ;

This product is designed and manufactured with high quality



materials and components, which can be recycled and reused.



This symbol means the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment. For more information on disposal and recycling of this product, contact your local municipality, disposal service, or the shop where you purchased this product.

UK Statement



This product complies with the radio interference requirements of the United Kingdom Declaration of Conformity.

Hereby, Demo Inc. declares that this product is in compliance with Radio Equipment Regulations 2017(S.I. 2017/1206). The full text of the UK declaration of conformity is available at the following internet address: <https://www.Demo.com>

Demologo

Demo Inc. All rights reserved. Demo and the Demo logo are registered trademarks of Demo Inc. in the United States and other countries. Certain trademarks including, App Store, Alexa and Google Play are the property of their perspective owners.

MODEL: Battery Cam 1



B C 1 1 1 0 A M 1