

## INSTRUCTIONS

1.



2.



3.



1. Remove debris from tyre tread or sidewall using the pair of pliers provided in the kit. Take care, as residual air will escape under pressure.

2. Apply lubricant to the spiral shaft of the reamer tool. This will help to probe the hole and temporarily separate the steel belts.

3. Insert the reamer into the puncture hole and push in to clean out the hole. Reinflate tyre to help with insertion of cord.

4. Thread the repair cord through the eye of the insertion tool until equal parts are either side of the tool. Lubricant may be added to the tip to make insertion easier.

5. Firmly push the insertion tool and cord into the tyre. A small amount of the cord should be visible. (50-10mm only)

6. Remove the tool, by slowly pulling up on the handle. The cord should remain stationary in this process. Note: do not twist the handle. Trim the excess protruding cord with the blade provided.

7. Reinflate the tyre using a Bushranger compressor to the recommended tyre pressure and check for leaks.

8. Check the repair regularly and have the tyre professionally checked and repaired as soon as possible. Seals are only intended to be used as temporary repair.

4.



5.



6.



# WARRANTY

**BUSHRANGER**  
4x4 GEAR

Kingsley Enterprises Pty Ltd ('Kingsley') warrants to the original purchaser that the product sold or distributed by Kingsley identified below (the Product) will be free from defects in materials and workmanship for the warranty period identified below commencing on the date of purchase from Kingsley ('the Warranty').

Kingsley, will rectify any defect in materials or workmanship appearing within the Warranty period by repairing or replacing the Product (at its option).

Kingsley reserves the right to determine whether the Product contains any defects in materials or workmanship covered by the Warranty.

The benefits offered by this Warranty are in addition to your rights and remedies under the Australian Consumer Law. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

## How to make a warranty claim

A claim under the Warranty must be made within the Warranty period identified below, which commences on the date of purchase from Kingsley. To make a Warranty claim, the Product must be returned to the place of purchase together with proof of purchase unless otherwise agreed by Kingsley.

Any costs incurred in making a Warranty claim or returning a Product to the place of purchase are to be borne by the person making the Warranty claim unless otherwise agreed by Kingsley.

## Exclusions

This Warranty does not cover any defect or injury caused by, or associated with improper installation or maintenance; unauthorised service, repair, modification or alteration; unsuitable physical or operating environment; electrical supply; acts of God; misuse, abuse or neglect; accidental damage, or other alterations or modifications which affect the reliability or performance of the product not attributable to a defect in materials or workmanship.

**Kingsley Enterprises Pty Ltd.**

6A Brooks Road, Ingleburn 2565 New South Wales, Australia | P: 1800 654 767 | Int: +612 8700 0400 | E: [sales@kingsleyenterprises.com.au](mailto:sales@kingsleyenterprises.com.au)