



What's in the box?

Charging Case x1 Earbuds x2 Ear Tips Set x3 (Size M has been preinstalled on earbuds)

Type-C Charging Cable x1 User Manual x1

01

Overview

LED Indicator of Earbud Multi-functional Button (MFB)

Microphone Earbud L&R Charging Status

Power of Charging Case Type-C Charging Port

Charging Pins Power Status

02

First-use

1. Before the first use, please tear off the isolating film on the earbuds. Put the earbuds into the case, then charge both earbuds and charging case via supplied Type-C charging cable for at least 10mins (or after not use for a long time), do not take out the earbuds during this period.

2. The earbuds are installed with a pair of size M ear tips by default. You can select other suitable sizes for a secure fit.

03

Wearing

1. Choose the Ear Tips that fit your ears best.

2. Insert the earbuds into the inner canal of your ears and turn gently until you find the most comfortable and secure position.

Bluetooth Pairing

1. Open the charging case, and pick up the earbuds from the charging case for 3 seconds to enter Bluetooth pairing mode.

04

• The LED indicators on the buds will flash white-red in sequence continuously, the other bud will blink white slowly.

• If the earbuds are not connected to any devices over 5 minutes, they will power off automatically. Turn on the earbuds manually by pressing the MFB button for 2 seconds to hear the prompt "power on".

2. Select "T60" on your device's Bluetooth list to connect.

• When successfully connected, you will hear the prompt "connected" and the LED indicators will turn off.

05

Switch from one device to another

Each time you power on your earbuds, they will automatically connect to your last successfully connected device if available within the Bluetooth range. If you wanna switch between devices, please first turn off the Bluetooth of the last device.

First Device

1. Go to the Bluetooth settings on the other device. For example, on your phone, go to Settings → Bluetooth.

2. Tap or click your earphones on the list of discovered devices.

Second Device

* If you don't see your buds in the list, you might need to reset the buds.

06

Mono mode

• When Bluetooth connected, you can use either one of the earbuds only by placing the other one into the charging case.

• When powered on and connected, if either one of the earbuds is out of battery and powered off, you can keep using the other one.

• When you are on a call, place either one of the earbuds into the charging case, and the microphone in the other earbud will be activated.

07

Reset

You might need to reset the earbuds if you experience any connectivity problems or function issues.

❶ Take the earbuds out for 5mins to consume some battery of both buds.(Can't be reset if the earbuds are fully charged)

❷ Place the earbuds in the charging case and earbuds blink red.

❸ Press and hold the button on the buds for 8 seconds until the LED indicators flash red-white 3 times. This confirms that the reset was successful and your earbuds can be connected normally.

When resetting the earbuds, make sure the earbuds are properly connected with charging points in the case, or it may cause resetting failure.

hold for 8s

08

Specifications

Specifications are subject to change without notice.

Model NO:	T60
Input	5V ⚡ 0.5A
Rated output power	5mW(@1% THD)
Battery capacity	50 mAh*2 (earbuds) 600 mAh (charging case)
Driver size	13mm*2
Frequency response	20Hz - 20kHz
Impedance	32Ω
Bluetooth range	10m/33ft

Maintenance

Clean your earbuds

Your earbuds are sweat and water-resistant, but not sweatproof or waterproof. The charging case is not waterproof, so be careful not to get moisture in any openings.

09

❶ Remove the earbuds from the charging case.

❷ Disconnect the charging cable from both the case and your computer or power adapter.

❸ To clean the charging contacts on buds, use a cotton swab slightly dampened with warm water. To clean the charging pins on the case, use a lint-free cloth slightly dampened with warm water. If necessary, you can slightly dampen the cotton swab or cloth with 70 percent isopropyl alcohol.

❹ Use a soft, dry, lint-free cloth to clean all other areas of the buds and case. Here's how to clean your earbuds.

Care for your earbuds

Clean and dry your earbuds and your skin after workouts or heavy sweating. Keep your earbuds and charging case clean and dry.

10

Button Operation tips

🎵 Music Mode	
Play/Pause	Press once (R/L)
Next Track	Press twice (R)
Previous Track	Press twice (L)
Volume+	Long Press (R)
Volume -	Long Press (L)

🗣️ Voice Assistance	
Activate Siri or other voice assistant software	Press thrice (R/L)

☎️ For Call	
Answer/End a call	Press once (R/L)
Reject a call	Press and hold for 2 seconds (R/L)

🔌 Power On/Off	
Power on	*Press and hold for 2s (R/L) in power-off state *Pick up buds from the charging case
Power off	*Non-music playing, press and hold for 5s(R/L) *Put back into the charging case. *Not connected to any devices over 5mins

11

Charging

Type-C USB charging

• Fully dry off the earbuds and the USB port before charging.

• Use a certified USB-C charging cable and charger to prevent any damage.

• Fully charge both the earbuds and the charging case before the first use.

1. Place the earbuds in the charging case and close it.

2. Connect the charging case to the power supply by using a USB-C charging cable.

► During charging, the digital display flashes and shows the real-time power until 100.

► The right display panel indicates the charging status per bud. There are separated power consumption indicators by 4 grids in total, which will be flashing when charging.

► The LED indicator on the charging case indicates the charging status.

12

Wireless charging

Easily charge the case without cables, just put your charging case on the wireless charging pad. If the charging case is not being charged, please try to reposition it.

Wireless Charging Pad (Not Included)

FAQ

Q: What should I do if the earbuds disconnect or the sound is choppy?

A: Please note that this doesn't necessarily mean there is an issue with the earbuds, but may have something to do with the connected device and environment. Bluetooth signals may be influenced by obstructions, such as walls, pillars, home appliances, Wi-Fi, and more. To ensure a stable connection, we recommend avoiding such obstructions. To fix this issue, please try the following:

1. Fully charge and reset your earbuds as stated above and re-pair them.

2. Check the earbuds by listening to a downloaded song/video.

3. Check the earbuds with another Bluetooth device in a different environment to see if it works well.

13

Q: What should I do if any of the following problems occur?

1. Cannot pair or reconnect with my device.

2. One side does not pair with the other side of my device.

3. No music plays after connecting with my device.

4. Only one earbud has sound.

A:

1. Remove the protective film covering the connectors on the earbuds.

2. Reboot the Bluetooth device you're using (such as a phone or computer). Forget all the pairing records of your earbuds on your device and turn off Bluetooth.

3. Reset the earbuds as per the steps above(make sure your earbuds have enough battery).

4. Turn on the Bluetooth of your device and search for "T60" and pair. If there is a pop-up window to confirm pairing for "T60," please select "Pair." If you accidentally select "Cancel," you need to refresh (turn off and turn on) the Bluetooth of your device and pair the earbuds again.

Q: What should I do if any of the following problems occur?

1) The earbuds don't recharge in the charging case.

2) The earbuds stay connected to the device even after being placed in the charging case with the lid closed.

3) The earbuds don't turn on when taken out of the charging case.

14

A:

1. Confirm the charging case has power left (open the charging case to check if there is white light flashing).

2. Clean the charging pins with a dry cloth and an alcohol-based disinfectant. This is to ensure all charging contact pins on the earbuds and charging case is completely clean and dry from sweat and water. Then put the earbuds correctly into the case. The light and display flash when the earbuds are placed in the case.

3. Please use the certified charging cable and wall charger.

4. Please check whether the ear tips are installed properly.

Kindly scan the QR code to activate the **lifetime warranty** of your earbuds within **15 days**.

www.pocbuds.store

15