

# Galaxy 5G Mobile Wi-Fi

## Quick Start Guide

For detailed descriptions of various functions, refer to "取扱説明書 詳細版 (Full Instruction Manual)" (Japanese) available on the au homepage.  
<https://www.au.com/support/service/mobile/guide/manual/> (Japanese)

### ■Note■

Please read the phrases in this manual as those shown on the table below according to your carrier.

Phrase	Read as
Customer Center Repair and Delivery Support Center	your WiMAX carrier*
au homepage	your WiMAX carrier* homepage
Sales: KDDI CORPORATION · OKINAWA CELLULAR TELEPHONE COMPANY	Sales: KDDI CORPORATION · OKINAWA CELLULAR TELEPHONE COMPANY · UQ Communications Inc.
au IC Card	SIM card

\*We will let you know about the contact for WiMAX carrier when you purchase the product.



Cell phone and PHS operators collect and recycle unused telephones, batteries and battery chargers at stores bearing the ♻️ logo regardless of brand and manufacturer to protect the environment and reuse valuable resources.


Sales: KDDI CORPORATION · OKINAWA CELLULAR TELEPHONE COMPANY

Imported by: SAMSUNG ELECTRONICS JAPAN Co., Ltd.

Manufactured by: Samsung Electronics Co., Ltd.


April 2021, 1st Edition

## Names of Parts



### ■ Using the back stand

Open the back stand to stand the main unit horizontally as in the illustration below.



### ■ If the back stand has come off

Do not remove the back stand. If it has come off, confirm the orientation, make the back stand vertical with the main unit as in the illustration below, and then insert the back stand straight into the groove of the main unit.



- When you stand the main unit with the back stand, be sure to stand the main unit horizontally; otherwise, the main unit may be unstable.
- Be careful not to apply a strong force or impact to the main unit while it is standing with the back stand, as the back stand may come off.
- Do not open/close the back stand or try to remove it forcibly; otherwise, it may be deformed or damaged.

## List of Packaged Items


- Main unit
- SIM card removal tool (sample)
- はじめてガイド (Quick Start Guide) (Japanese)
- ご利用にあたっての注意事項 (保証書) (Notes on Usage (Warranty card)) (Japanese)



### memo

- ◎ Be sure to use the specified charging equipment (sold separately).
- ◎ The battery is built into the product.
- ◎ Illustrations of the product in this manual are sample images. They may look different from the actual ones.

## Attaching the au IC Card



## Turning the Power On

- 1 Press and hold the side key for at least 2 seconds
- 2 Unlock the screen



• Swipe the area other than the calendar display.



### memo

- ◎ If you cannot turn the power off with the normal procedure or the display freezes, press and hold the side key for at least 7 seconds to restart the product.

## Making Initial Settings

When you turn the power on for the first time, the initial setup wizard appears. You can make basic settings of the product.

- 1 Tap "日本語" → Select "English" → "OK" → "Start"
- 2 Confirm the contents of the "Welcome!" screen → "Continue"
- 3 Make the settings below following the on-screen instructions

Step 1 Select the "communication mode"

Step 2 Select the "performance mode"

Step 3 Transfer settings from your previous device

Make this setting if you hand over the Wi-Fi® settings from your previous device. If you do not, select "Skip".

Step 4 Enter the Wi-Fi® network name and password

Change the SSID (network name) and password from the default value as necessary.

Step 5 Select the screen locking method

Step 6 Select the setting of "Turn off Wi-Fi automatically"\*1

Step 7 Select the setting of "Use battery protection?"\*2

\*1 Turns off Wi-Fi® to reduce battery consumption if no communication is done for 10 minutes.

\*2 Sets the upper limit of battery charge to 85 % of battery capacity to prolong the battery life.

- 4 On the "You're all set up!" screen, tap "Start"

The Home screen appears.

## Connecting with Wireless LAN (Wi-Fi®)

The product conforms to IEEE802.11a/b/g/n/ac wireless LAN (Wi-Fi®) standards and can be connected to wireless LAN (Wi-Fi®) devices (PC, smartphone, tablet, etc.) with wireless LAN (Wi-Fi®) for data communication.

Also, the product is compatible with the WPS function and can be connected to your wireless LAN (Wi-Fi®) devices with wireless LAN (Wi-Fi®) by simple operations if your device is compatible with the WPS function.

In addition, the product is compatible with a QR code and can be easily connected to wireless LAN (Wi-Fi®) devices compatible with QR code scanning and connection with a QR code.

This manual describes the connection method with the WPS function.

- For the connection methods other than those with the WPS function or details on connection with the WPS function, refer to "無線LAN (Wi-Fi®) で接続する (Connecting with Wireless LAN (Wi-Fi®))" in "取扱説明書 詳細版 (Full Instruction Manual)" (Japanese).

## Connecting with the WPS Function

- 1 From the Home screen of the product, "≡" → "Wi-Fi" → "WPS" → "Start" → "Continue"  
The WPS function turns on.
- 2 Perform connecting operations with your wireless LAN (Wi-Fi®) device within 2 minutes
  - Operations vary depending on your wireless LAN (Wi-Fi®) device.

## Checking Your Phone Number

- 1 From the Home screen of the product, "≡" → "About" → "Status"

\* You cannot make/receive a voice call with this product.

## Communication Modes

You can switch the communication mode between

"Standard" and "Plus area".

The "Standard" mode is applied at the time of purchase. If you switch the mode to "Plus area", additional charge may be applied depending on your rate plan.

- 1 From the Home screen of the product, "Communication mode" → "Communication mode" → "Standard (ST)" or "Plus area (+A)"

## Switching to English Display

- 1 From the Home screen of the product, "三" → "システム設定 (System settings)" → "言語 (Language)" → "言語を選択 (Select language)" → Select "English" → "保存 (Save)"

## For Inquiries;

### Customer Center

For general information (toll free)

Business hours 9:00 to 20:00 (7 days a week)

From au mobile phones:

From non-au mobile phones /

general subscriber phones:

**157** area code not required

 **0077-7-111**

In case above numbers are not available (for free),

 **0120-977-033**

For theft, loss, or malfunction (toll free)

Business hours 24-hour (7 days a week)

From au mobile phones:


From non-au mobile phones /

general subscriber phones:

**113** area code not required

 **0077-7-113**

In case above numbers are not available (for free),

 **0120-925-314**


### Repair and Delivery Support Center

(Service for members of Repair and Delivery Support/Security Support Pack)

For repair or replacement cell phone delivery service (toll free)

Business hours 9:00 to 20:00 (7 days a week)

From au mobile phones / non-au mobile phones / general subscriber phones:

 **0120-925-919**