


24L Thermoelectric Cooler and Warmer

SKU: IVAPC24AB Aqua Blue SKU: IVAPC24L Blue **User Guide**



Thank you for purchasing the Ivation 24 L
Thermoelectric Cooler and Warmer. This User Guide is intended to provide you with guidelines to ensure that operation of this product is safe and does not pose risk to the user. Any use that does not conform to the guidelines described in this User Guide may void the limited warranty.

Please read all directions before using the product and retain this guide for reference. This product is intended for domestic use only. It is not intended for commercial use.

This product is covered by a limited one-year warranty. Coverage is subject to limits and exclusions. See warranty for details.


INTRODUCTION	2
TABLE OF CONTENTS	3
SAFETY PRECAUTIONS	4
PACKAGE CONTENTS	5
PRODUCT OVERVIEW	5
PREP/ OPERATION INSTRUCTIONS	6
USAGE/ MAINTENANCE	7
TROUBLESHOOTING/ SPECIFICATIONS	8
LIMITED WARRANTY	9
GET IN TOUCH!	11

WARNING! For proper operation, please read the instructions carefully before using the appliance. Misuse of the appliance can cause injury to the user or damage to the product.

- Remove all packaging before using this device. Please keep all packaging materials out of reach of children and pets.
- Properly dispose of all packing materials immediately after unpacking product, as the bags used for packaging could present a suffocation or choking hazard.
- Do not allow the fan to get stuck or hooked on anything. If the fan cannot spin, it will heat up the engine and cause a fire. Objects such as towels, washcloths, and clothing items should not be placed on top of the unit.
- Please make sure that cords are safely and tightly plugged into the outlet. A loose plug may result in the cords and sockets breaking or causing a fire.
- Keep the appliance away from flammable items and dampness to prevent fires.
- Do not disassemble the appliance. There are no user serviceable parts inside.
- Do not switch between COLD and HOT mode rapidly.
- Turn the unit off first and wait 30 minutes before going to a different mode.
- Do not rinse the appliance with water.
- Do not let the appliance rest upside down.
- Handle the appliance with care. Do not drop the unit.
- Do not let children operate the appliance unless supervised by a parent or other adult responsible for their safety.
- Always place the appliance on a flat, level surface when in use.
- Keep vents clear and free from debris.

PACKAGE CONTENTS

- A 24 L thermoelectric cooler and warmer
- **B** User guide




1. Air in vent	7. Cooler lid
2. Cable storage cover	8. Fan cover
3. Control panel	9. Seal
4. Air out vent	10. Interior storage
5. Exterior cooler body	11. Cooler handle
6. Cable storage	

PREPARATION BEFORE USE

- Remove all packaging components. Properly dispose of all packing materials immediately after unpacking product.
- · Check to make sure no parts are broken or missing.
- Place the cooler in a dry, well-ventilated area on a flat, level surface.
- Clean the inside and outside of the cooler before use.


OPERATION INSTRUCTIONS

- 1. Make sure the power switch on top of the unit is in the OFF position.
- 2. Select the AC plug or DC car adapter and connect the cable to a compatible power source.
- 3. Set device to cooling or heating with the switch:
 - Cooling: set the switch to the COLD position. The green light indicator will come on, showing the unit is in cooling mode.
 - Heating: set the switch to the HOT position. The red light indicator will come on, showing the unit is in heating mode.



NOTE: To obtain an optimal cooling effect, we suggest placing pre-chilled foods and drinks in the unit. It will take about two to three (2 – 3) hours to cool food or drinks that have not been pre-chilled. The interior of the appliance is not designed to heat cold food, but to preserve hot foods at a warm temperature. If necessary, it can heat food after running continuously for more than two (2) hours. If instructions were followed properly, the temperature of foods can be maintained for hours.

Using the DC Car Adapter



- Turn on your car. 1.
- 2. Locate the DC car adapter connected to the unit.
- Insert the plug of the DC car adapter into the socket of the car. 3.
- 4. Move the power switch to choose COLD or HOT mode.

Using the AC Power Cord

- Locate the AC power cord connected to the unit.
- Insert the plug of the AC power cord into the outlet.
- Move the power switch to choose COLD or HOT mode.

RECOMMENDED USES

- Banquets
- · Picnics or camping trips
- Playgrounds
- · Dining halls
- Offices
- Road trips
- · Fishing trips or yacht outings
- Bus rides
- Household bars
- Storage for medication at a low temperature

CLEANING/MAINTENANCE

- You must disconnect the power before cleaning the appliance.
- When cleaning, ensure that water does not enter the electrical compartments of the appliance.
- Dip a soft towel in lukewarm water to clean the outside surface of the appliance.
- When cleaning door seals, wipe them with clean water and a dry cloth.
- Do not use abrasive cleaners or detergents on the appliance.
- · Do not rinse with water.

TROUBLESHOOTING

PROBLEM	POSSIBLE REASON	SOLUTION
The indicator light and fan do not turn on.	The power plug is not properly plugged in. The switch is not in the proper position.	Plug power cord into a usable power outlet. Check to make sure the switch is in the right position.
The fan is working, but the indicator light is not turning on.	Indicator light is broken.	Contact a professional electrician to replace the light.
The indicator light is on, but the fan is not working.	Fan is broken or something is stuck in the fan blades.	Contact a qualified professional to check your fan and replace it if needed.
The color of the indicator light does not correspond correctly to the position of the switch.	The polarity of the direct current supply is incorrect.	Check whether the polarity of the DC power supply is consistent with the product's power supply demands.
No cooling is happening.	The cooling plate is broken, or the lead wire of the cooling plate has come off.	Contact a qualified professional to check whether the lead wire of the cooling plate has fallen off or the cooling plate needs to be replaced.
No heating is happening.	The ventilation is blocked, or the lid cover is not closed properly.	Remove objects near the ventilation. Check whether the lid cover is properly closed.

SPECIFICATIONS

• **Dimensions:** 15.6" x 9.3" x 16.8" (39.6 x 23.7 x 42.6 cm)

• **Weight:** 7.7 lbs. (3.5 kg)

• Capacity: 6.3 gal.

Rated voltage (with DC cord): 12 V

• Rated voltage/frequency (with AC cord): 100 V - 120 V, 60 Hz

• Rated power (DC/hot mode): 40 W • Rated power (DC/cold mode): 48 W • Rated power (AC/hot mode): 48 W • Rated power (AC/cold mode): 52 W

LIMITED WARRANTY TO ORIGINAL CONSUMER

This Ivation 24 L Thermoelectric Cooler and Warmer ("Product"), including any accessories included in the original packaging, as supplied and distributed new by an authorized retailer is warranted by C&A Marketing, Inc. (the "Company") to the original consumer purchaser only, against certain defects in material and workmanship ("Warranty") as follows:

To receive Warranty service, the original consumer purchaser must contact the Company or its authorized service provider for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the Product is within the applicable Warranty period(s), MUST be presented to the Company or its authorized service provider in order to obtain the requested service.

Service options, part availability, and response times may vary and may change at any time. In accordance with applicable law, the Company may require that you furnish additional documents and/or comply with registration requirements before receiving warranty service. Please contact our customer service for details on obtaining warranty service:

Email: info@myivation.com Phone: 1-866-849-3049

Shipping expenses to the Company's Return Facility are not covered by this warranty, and must be paid by the consumer. The consumer likewise bears all risk of loss or further damage to the Product until delivery to said facility.

EXCLUSIONS AND LIMITATIONS The Company warrants the Product against defects in materials and workmanship under normal use for a period of ONE (1) YEAR from the date of retail purchase by the original end-user purchaser ("Warranty Period"). If a hardware defect arises and a valid claim is received within the Warranty Period, the Company, at its sole option and to the extent permitted by law, will either (1) repair the Product defect at no charge, using new or refurbished replacement parts, (2) exchange the Product with a Product that is new or which has been manufactured from new or serviceable used parts and is at least functionally equivalent to the original device, or (3) refund the purchase price of the Product.

A replacement Product or part thereof shall enjoy the warranty of the original Product for the remainder of the Warranty Period, or ninety (90) days from the date of replacement or repair, whichever provides you longer protection. When a Product or part is exchanged, any replacement item becomes your property, while the replaced item becomes the Company's property. Refunds can only be given if the original Product is returned.

This Warranty does not apply to:

- (a) Any non-Ivation 24 L Thermoelectric Cooler and Warmer product, hardware or software, even if packaged or sold with the Product;
- (b) Damage caused by use with non-Ivation 24 L Thermoelectric Cooler and Warmer products;
- (c) Damage caused by accident, abuse, misuse, flood, fire, earthquake, or other external causes;
- (d) Damage caused by operating the Product outside the permitted or intended uses described by the Company;
- (e) Damage caused by third party services;
- (f) A Product or part that has been modified to alter functionality or capability without the written permission of the Company;
- (g) Consumable parts, such as batteries, fuses, and bulbs;

- (h) Cosmetic damage; or
- (i) If any Ivation 24 L Thermoelectric Cooler and Warmer serial number has been removed or defaced.

This Warranty is valid only in the country where the consumer purchased the Product, and only applies to Products purchased and serviced in that country.

The Company does not warrant that the operation of the Product will be uninterrupted or error-free. The Company is not responsible for damage arising from your failure to follow instructions relating to its use.

NOTWITHSTANDING ANYTHING TO THE CONTRARY AND TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE COMPANY PROVIDES THE PRODUCT "AS-IS" AND "AS-AVAILABLE" FOR YOUR CONVENIENCE AND THE COMPANY AND ITS LICENSORS AND SUPPLIERS EXPRESSLY DISCLAIM ALL WARRANTIES AND CONDITIONS, WHETHER EXPRESSED, IMPLIED, OR STATUTORY, INCLUDING THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, TITLE, QUIET ENJOYMENT, ACCURACY, AND NON-INFRINGEMENT OF THIRD-PARTY RIGHTS. THE COMPANY DOES NOT GUARANTEE ANY SPECIFIC RESULTS FROM THE USE OF THE PRODUCT, OR THAT THE COMPANY WILL CONTINUE TO OFFER OR MAKE AVAILABLE THE PRODUCT FOR ANY PARTICULAR LENGTH OF TIME. THE COMPANY FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE.

YOU USE THE PRODUCT AT YOUR OWN DISCRETION AND RISK. YOU WILL BE SOLELY RESPONSIBLE FOR (AND THE COMPANY DISCLAIMS) ANY AND ALL LOSS, LIABILITY, OR DAMAGES RESULTING FROM YOUR USE OF THE PRODUCT.

NO ADVICE OR INFORMATION, WHETHER ORAL OR WRITTEN, OBTAINED BY YOU FROM THE COMPANY OR THROUGH ITS AUTHORIZED SERVICE PROVIDERS SHALL CREATE ANY WARRANTY.

IN NO EVENT WILL THE COMPANY'S TOTAL CUMULATIVE LIABILITY ARISING FROM OR RELATED TO THE PRODUCT, WHETHER IN CONTRACT OR TORT OR OTHERWISE EXCEED THE FEES ACTUALLY PAID BY YOU TO THE COMPANY OR ANY OF ITS AUTHORIZED RESELLERS FOR THE PRODUCT AT ISSUE IN THE LAST YEAR FROM YOUR PURCHASE. THIS LIMITATION IS CUMULATIVE AND WILL NOT BE INCREASED BY THE EXISTENCE OF MORE THAN ONE INCIDENT OR CLAIM. THE COMPANY DISCLAIMS ALL LIABILITY OF ANY KIND OF ITS LICENSORS AND SUPPLIERS. IN NO EVENT WILL THE COMPANY OR ITS LICENSORS, MANUFACTURERS, AND SUPPLIERS BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA, OR RECORDS) CAUSED BY THE USE, MISUSE, OR INABILITY TO USE THE PRODUCT.

Nothing in these terms shall attempt to exclude liability that cannot be excluded under applicable law. Some countries, states, or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so certain limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.

ivation[®]

GET IN TOUCH!

info@myivation.com

L 1-866-849-3049

IVATION is a trademark of C&A IP Holdings LLC in the US, Canada, China, and the EU.

All other products, brand names, company names, and logos are trademarks of their respective owners, used merely to identify their respective products, and are not meant to connote any sponsorship, endorsement, or approval.

Distributed by C&A Marketing, Inc., 114 Tived Lane East, Edison, NJ 08837. Made in China.

© 2023. C&A IP Holdings LLC. All Rights Reserved.