

# Wireless Doorbell

## User Manual



33  
Melodies



Memory  
function



Learn up to  
15 transmitters



volume adjusted  
4 levels



## Operation Guide



Plug the doorbell receiver into the AC outlet, the receiver rings "Dingdong" once, means that the receiver has entered working mode.



Tear off the back glue of the doorbell transmitter and stick it on the wall. Press and hold for more than 5 seconds to release it.



After confirming that the transmitter is firmly fixed, press the transmitter, the receiver will emit a melody means that the transmitter working normally.

This wireless doorbell has 4 power outage memory functions, power off and restart will remember the ringing sound of a bell for the last time.

## Setting and Adjusting



### Volume control

Press the [Volume] button to adjust the volume, with 4 levels available.

### Set up

### Select Song

Press the [Select Song] button to select a melody, with 33 songs available.

### Factory reset



Put the doorbell receiver out of the socket, press and hold the [Volume] button and insert it into the socket for 3 seconds.

The doorbell receiver will emit a beep indicating that all transmitters and detectors have been successfully deleted after factory reset, all accessories have no songs.

Note: The product has already been paired before leaving the factory, and users do not need to configure it.

## Add doorbell transmitter



Short press the [Set] button, the doorbell receiver will ring and then release your hand. Press the button on the doorbell transmitter, and the doorbell receiver will "ding dong" once, indicating successful pairing.

Short press the [Select Song] button, the transmitter can switch music at any time. But adding PIR motion sensors to the doorbell receiver is in welcome mode, and adding door and window sensors is in alarm mode. This is fixed.



Long press and hold the [Select Song] button for 3 seconds, and the doorbell receiver will emit a beep, triggering the button to learn. In this way, the accessory has music memory function. No matter how the music switches.

All accessories always keep learning songs.

If you want to learn multiple doorbell transmitters, please continue to trigger other doorbell transmitters. After learning, press the [Volume] button once to exit the learning process. After exiting, you can trigger the transmitter you just learned to test whether the learning is correct.

## Technical Parameters



1. Working voltage: AC 100-240V
2. Working Current: < 100mA
3. Wireless Frequency: 433MHz
4. Working Temperature: -10°C—50°C
5. Wireless Distance: 100meters (Open area)
6. Receiver Size: 97\*40\*17mm (Not include plug)
7. Volume Decibels: 20-105db (4 levels adjustable volume)



1. Working Voltage: 3V (CR2032 button battery)
2. Working Current: 8mA
3. Wireless Frequency: 433MHz
4. Working Temperature: -10°C—50°C
5. Transmitting Distance: 100meters (Open area)
6. Transmitter Size: 75\*40\*13mm

## Package List



Doorbell receiver

Transmitter



Adhesive patch

User manual

**FCC Caution:**

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.