

Sunco

Lighting made better.

User Manual

LED Mini Floor White Spotlight

SKU: SPL_IND-WH-3000K




support@sunco.com

PDF
44) 334-9938
Adobe



What's in the Box?

Floor Spotlight



Components List



x2

Self-Tapping Screws



x2

Plastic Anchors

Before You Start

Safety Information

To reduce the risk of fire, electric shock, or physical injury:

- Turn off circuit breaker before installing this fixture.
- This product should be installed by a person familiar with the construction and operation of the product the hazards involved. Safety eyeglasses and gloves are recommended.
- Abide by related regional and local laws or regulations.
- Proper grounding is required to ensure safety.
- Do not alter, relocate, or remove wiring during installation.
- Do not make or alter any open holes in wiring enclosure or electrical components during installation.
- Check for shipping damage before installing. If the product is damaged, do not use it.
- Keep fixture away from corrosive substances.
- Suitable for damp locations at temperature ranging from -4°F to 113°F. Not for use where directly exposed to water.
- Clean the fixture regularly to ensure proper operation. Do not clean with harsh solvents.
- Use safety precautions and abide by regional and local laws or regulations.
- This product is not compatible with 3rd party sensors.
- This product is not compatible with photo controls.
- This product is not compatible with occupancy sensors.
- This product is not compatible with timing devices.



WARNING:


Cancer & Reproductive Harm- www.P65Warnings.ca.gov

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

1.) This device may not cause harmful interference.

2.) This device must accept any interference that may cause undesired operation. Please review all instructions carefully prior to installation.

Installation Guide(Wall Mount Installation)




STEP 1

- Determine desired area to install light fixture.**
- Unscrew mounting plate screws to remove mounting accessories.**


Installation Guide (Cont.)

STEP 2



- Mark desired surface using the mounting plate as a reference.
- Drill holes on marked areas, insert expansion anchors (B), then screw self-tapping screws (A) to installation surface.

STEP 3




- Align lamp base to mounting plate, then tighten screws removed from Step 1b.

A



B


Press / Step button to toggle light switch.



STEP 4

- Once installed securely, insert plug into socket.
- Press the button with your hand or foot to power on light.


STEP 5



- Light fixture angle can be adjusted up to 90°.

Product Details

Product Size



Specifications

Voltage	120V	Average Lifetime	35,000 Hours
Wattage	3W	Lumens	300LM
Power Factor	0.9	Moisture Rating	Damp Rated
Beam Angle	30°	CRI	80+
CCT	3000K	Usage	Indoor
Housing Material	ALU + Cold Rolled Sheet	Efficacy	100LM/W
Dimmable	NO	Warranty	5 Years

Common Troubleshooting

Feeling in the dark about an issue with your product? No worries! Our troubleshooting section is here to shed some light and provide you with easy-to-follow solutions for any problem.

If you still need some assistance, please feel free to contact us with any questions. Our team of lighting experts are happy to help brighten your day.

Installation

Light isn't turning on.

Double check if fixture is properly connected and circuit breaker hasn't been tripped.

Light unexpectedly fails.

For further assistance, contact our customer support.

Flickering

Light is flickering when turning on.

Check that fixture wiring connections are secure.

Light flickering with other lights on the same circuit.

Check that the lights on the same circuit are not overloading the circuit.

Light flickering when turned on.

Verify fixture compatibility.

Light flickering when dimmed.

Product is not dimmable.

Buzzing

Fixture buzzing with power outages.

Verify light is connected to surge protector securely.


Fixture buzzing with appliances or electronic devices.

Look for nearby interferences that can cause buzzing. Such as televisions, radios, computers, etc.

Fixture buzzing when dimmed.

Product is not dimmable.

Light Distribution Angle



*Not a lighting nerd?
No worries, you can skip this page*

AVERAGE BEAM ANGLE (50%): 26.8 DEG

—	C0/180	27.1°
—	C90/270	26.5°

UNIT:cd Luminous Intensity Distribution 1

Lighting distribution angle refers to the spread of light emitted from a light source. It is an important factor to consider when selecting a fixture or bulb, as it affects the way it will illuminate an area. There are two main types of lighting distribution angles:

A symmetric lighting distribution emits light evenly in all directions, creating a cone-shaped pattern that provides a pool of light. This type of lighting is ideal for general lighting and illuminating large areas. Common applications for symmetric lighting include general area illumination, security lighting, and perimeter lighting. Symmetric lighting is also used to a certain degree in up-lighting.

An asymmetric lighting distribution angle, also known as beam angle, creates a pattern that focuses light in a specific direction. This type of lighting is ideal for task lighting as it reduces glare and light spill in other areas. Common applications include task lighting in spaces such as landscape settings, retail stores, museums, and much more.

It is important to note that the lighting distribution angle can also be affected by other factors such as the reflector design of the light source, the type of lens used, and the distance between the light source and the surface being illuminated.

Sunco

Lighting made better.

support@sunco.com
(844) 334-9938

REV11