



Wireless Numeric Keypad

BY-KB-WS-106-AC

INCLUDES:

- 1 (One) Wireless Numeric Keypad 5.2in. x 4.1in. x 1.1in. (13.2cm x 10.4cm x 2.9cm)
- 1 (One) USB Receiver .75in. x .625in. x .25in. (1.9cm x 1.6cm x .6cm)
- 1 (One) User Manual

FEATURES

- Automatic linking, plug and play.
- Responsive buttons for ultimate productivity and efficiency.
- Ergonomic design for maximum performance and comfort.
- Anti-Skid pads on bottom.

USB RECEIVER

The USB receiver can be found stored in a slot adjacent to the battery bay under the battery bay door.

-Flip the keypad over and remove the battery bay door. You will see a smooth black rectangular object to the left of the battery tray imprinted with the FCC ID number, this is the USB receiver unit.

-Remove it carefully by hooking a fingernail into the groove along the side surface that faces the battery bay and lift it up slowly to free it, being very careful not to damage or lose it.

-Store the receiver in this slot when the keypad is not in use so that it doesn't get lost or damaged. The keypad will not work without the USB Receiver.

HOW TO USE

- Insert the USB receiver into one of your computer's USB ports.
- Place 1(One) AAA 1.5V Alkaline Battery battery (not included) into the battery compartment of the keypad.
- Your computer should recognize the keypad instantly. Be sure to check your computer's settings if it is not detected.
- If the Keypad is unused for 2 seconds, it will enter sleep mode, press any key to resume.
- Please remember to remove the USB receiver from your computer's USB port when you are not using the keypad.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Keypad: FCC ID: 2AHN6-KBWS106
Dongle: FCC ID: 2AHN6-DE3

TROUBLESHOOTING

- If device won't connect, try the following:
- Be sure the USB receiver is connected to your computer.
- Be sure the USB receiver is not damaged.
- Check your computer's input settings.
- Try new battery in the keypad.
- Restart your computer.

SPECIFICATIONS:

- 2.4GHz wireless numeric keypad
- 18 keys
- Working range: up to 33 feet
- Battery: 1 (One) AAA 1.5V Alkaline Battery (not included)

UNIVERSAL COMPATIBILITY

Compatible with Windows® & Mac OS®

- ©2024 BYTECH NY INC.
- BYTECH™ is a registered trademark of Bytech NY INC.
- *All Trademarks and copyrights are the property of the respective companies.
- *Mac OS® is a registered trademark of Apple Inc.
- *Windows® is a registered trademark of Microsoft Corporation.
- *Bytech NY Inc. has no affiliation to Apple Inc. or Microsoft Corporation, Inc.
- *Photos are for illustration purposes only.

BYTECH

Contact Info:
2585 West 13th Street,
Brooklyn, NY 11223

BYTECHintl.com

© 2024 BYTECH NY INC.




WARRANTY- 12 MONTH

Please visit our website Bytechintl.com/warranty

⚠ WARNING: TO AVOID BATTERY LEAKAGE

- 1) The batteries used with this product are small parts and should be kept away from small children who still put things in their mouths. If they are swallowed, promptly see a doctor and have the doctor phone American Association of Poison Control Centers (1-800-222-1222).
- 2) Always purchase the correct size and grade of battery most suitable for intended use.
- 3) Do not mix old and new batteries, alkaline, standard (Carbon - Zinc) or rechargeable (Nickel-cadmium) batteries.
- 4) Clean the battery contacts and those of the device prior to battery installation.
- 5) Ensure the batteries are installed correctly with the regard to polarity (+ and -).
- 6) Always remove batteries if consumed or if product is to be left unused for a long time.



wireless numeric keypad

INCLUDES:

- 1 (One) Wireless Numeric Keypad 6.5in. x 3.9in. x 1.3in. (16.4cm x 9.8cm x 3.2cm)
- 1 (One) USB Receiver .75in. x .625in. x .25in. (1.9cm x 1.6cm x .6cm)
- 1 (One) User Manual

FEATURES

- Automatic linking, plug and play.
- Responsive buttons for ultimate productivity and efficiency.
- Ergonomic design for maximum performance and comfort.
- Anti-Skid pads on bottom.

USB RECEIVER

The USB receiver can be found stored in a slot adjacent to the battery bay under the battery bay door.

-Flip the keypad over and remove the battery bay door. You will see a smooth black rectangular object to the left of the battery tray imprinted with the FCC ID number, this is the USB receiver unit.

-Remove it carefully by hooking a fingernail into the groove along the side surface that faces the battery bay and lift it up slowly to free it, being very careful not to damage or lose it.

-Store the receiver in this slot when the keypad is not in use so that it doesn't get lost or damaged. The keypad will not work without the USB Receiver.

HOW TO USE

- Insert the USB receiver into one of your computer's USB ports.
- Place 1(One) AAA 1.5V Alkaline Battery battery (not included) into the battery compartment of the keypad.
- Your computer should recognize the keypad instantly. Be sure to check your computer's settings if it is not detected.
- If the Keypad is unused for 2 seconds, it will enter sleep mode, press any key to resume.
- Please remember to remove the USB receiver from your computer's USB port when you are not using the keypad.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Keypad: FCC ID: 2AHN6-KBWS106
Dongle: FCC ID: 2AHN6-DE3

TROUBLESHOOTING

- If device won't connect, try the following:
- Be sure the USB receiver is connected to your computer.
 - Be sure the USB receiver is not damaged.
 - Check your computer's input settings.
 - Try new battery in the keypad.
 - Restart your computer.

SPECIFICATIONS:

- 2.4GHz wireless numeric keypad
- 17 keys
- Working range: up to 33 feet
- Battery: 1 (One) AAA 1.5V Alkaline Battery (not included)

UNIVERSAL COMPATIBILITY

Compatible with Windows® & Mac OS®

©2024 BYTECH NY INC.
BYTECH™ is a registered trademark of Bytech NY INC.
*All Trademarks and copyrights are the property of the respective companies.
*Mac OS® is a registered trademark of Apple Inc.
*Windows® is a registered trademark of Microsoft Corporation.
*Bytech NY Inc. has no affiliation to Apple Inc. or Microsoft Corporation, Inc.
*Photos are for illustration purposes only.

BYTECH

Contact Info:
2585 West 13th Street,
Brooklyn, NY 11223

BYTECHintl.com

© 2024 BYTECH NY INC.

CE FC

WARRANTY- 12 MONTH

Please visit our website Bytechintl.com/warranty

WARNING: TO AVOID BATTERY LEAKAGE

- 1) The batteries used with this product are small parts and should be kept away from small children who still put things in their mouths. If they are swallowed, promptly see a doctor and have the doctor phone American Association of Poison Control Centers (1-800-222-1222).
- 2) Always purchase the correct size and grade of battery most suitable for intended use.
- 3) Do not mix old and new batteries, alkaline, standard (Carbon - Zinc) or rechargeable (Nickel-cadmium) batteries.
- 4) Clean the battery contacts and those of the device prior to battery installation.
- 5) Ensure the batteries are installed correctly with the regard to polarity (+ and -).
- 6) Always remove batteries if consumed or if product is to be left unused for a long time.