

PHILIPS

WiFi

Home IP Camera
3000 Series



User manual
Register your product and get support at
www.philips.com/support

Thank you for choosing Philips Home Camera!

The products are equipped with live monitoring, intelligent alarms, two-way calls, cloud security playback and other features to help you manage your home or commercial space safely and conveniently, and realize a better connection between people and home.

Packing List



Connect power supply

The camera will be connected to the power supply, wait patiently for a few seconds, the light next to the lens slightly flashing, began to welcome the use of voice prompts, at the same time the camera lens to rotate the calibration, with the end of the rotation of the lens, you can find the use of the instructions.



If you do not hear the tone, you can reset the device by long-pressing the reset button and then enter the above process again.

APP Networking Guidelines

1. Download Philips Home Camera App

Quickly download and install by scanning the QR code, or search for "Philips Home Camera" in your mobile app store to download and install.

Get Started



http://philips.to/homecam

2. Register and add devices

- Go to the "Philips Home Camera" APP and register the client with your cell phone number/email address, if you have already registered, please log in directly.
- Tap the "+" sign on the homepage of the app to add a camera.



3. Add method


- The camera is powered on and the cell phone is connected to the Wi-Fi, wait for the camera to send a notification of network allocation and then connect as follows.

Tips: In the binding process there is a system permission pop-up prompt, please allow APP to get permission, some devices do not support Bluetooth binding.

1. Bluetooth bonding



2. Connect Wi-Fi binding



3. Scan the QR code to bind



4. Hotspot Binding



If any error occurs during the binding process, the camera needs to be reset and re-bind.



Press and hold the camera reset button for about 5 seconds and wait for the voice prompt "Factory settings restored successfully."

5. Camera Features

• Home Functions



Tips: Turn on mute mode, the app will not send you any push notification, no matter turn on or off the alarm message can be viewed in the message list.

• How do I share my camera?

- You need to register your family/friends to the App account.
 - Click camera sharing and select scanning QR code.
 - Family members open the App and scan the QR code to share the device immediately.
- *You can also enter your account number directly to share your device.



Tips: Camera limit can be shared by up to 5 people, each time you share, please check the permissions you need to share.

• Fix /moveable lens position calibration

Click "Calibrate" in the camera live interface, we will automatically restore the position of the gun and dangle for you.
Note: Please don't leave the interface during the calibration process.



• Camera Alarm Settings

For a better monitoring experience, it is recommended that you can participate in the following alarm settings:

- Camera Settings -> Alarm Setting -> Push alarm: On

- Image detection mode: motion detection (motion setting triggers the alarm when it recognizes the movement, and humanoid detection triggers the alarm when it recognizes the humanoid)

- App Home -> mute mode switch off
- Mobile system settings -> Philips Home Camera App -> Enable allow notification



You can view the alarm recordings from camera on the "Alerts" page. If it shows "No Alerts," it means the device hasn't detected any motion to trigger an alert message.

• Camera playback settings

In order to get a better recording experience, it is recommended that you insert the SD card and configure the recording mode according to the following settings:

- Camera Settings -> Video recording mode -> Alarm recording
- The camera recognizes the time-of departure and instantly records to the SD card to accurately record the event without wasting the SD card capacity.




You need to insert the SD/TF card in the camera or subscribe Cloud service to view the playback video.

Micro SD Card Installation Guide

For new card insertion, please format it in APP; the formatting method is: Settings-Device Information-TF card formatting.

When the device is in power-off state, find the card slot in the camera body according to the instruction diagram, and insert the contact piece face down into the machine.




Product Installation Instructions

The camera can be placed on a flat surface such as a writing desk, dining table, coffee table, etc., or it can be installed with a wall-mounted bracket accessory for inverted fixation as follows:


- Mounting Bracket: Choose a clean, flat wall and drill two holes in the wall according to the hole spacing of the bracket. (It is recommended to mark the wall before drilling the holes)



- Drive two expansion screws into the wall according to the drilled holes.



- Align the hole of the bracket with the expansion screws, screw the hardware screws into the expansion screws and fix the bracket smoothly on the wall.



- Align the groove on the bottom of the camera with the concave part on the base, press it flat and rotate it clockwise until it is locked in place, and then adjust the angle according to the client's real-time browsing screen.



6. Common problems

Issues	Causes	Solution
Binding failed /Unable to bind	Abnormal power supply to equipment	The camera needs to use its own charging cable configuration, other charging cable power can not guarantee the normal operation of the camera
	The camera is not in a standby state	Re-binding the camera after reset
	Network anomaly	Check if the wireless network router password has special characters; please reboot the router
The live page shows "video offline"	Abnormal power supply to equipment	Re-plug the adapter or switch to a different outlet to ensure that the camera is properly energized
	Network anomaly	Always offline can not be restored please restore the camera to the factory settings and re-install
Networking failure after changing network	Need to rebind with the latest network	Delete the camera and add it again after restoring the camera to its factory settings

* If the above can not be resolved, please contact the merchant or sales to feedback.

FCC Statement

Drive This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna; Increase the separation between the equipment and receiver; Connect the equipment into an outlet on a circuit different from that to which the receiver is connected; Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.



Philips and the Philips shield emblem are registered trademarks of Koninklijke Philips N.V. and are used under license. The Philips shield emblem is used in this document under the responsibility of Philips. Philips is not responsible for any damage or loss of data or information caused by the use of this document. Philips is not responsible for any damage or loss of data or information caused by the use of this document.

© 2020 Philips